



## New and Changed Information for this Release

- [New and Changed Information for this Release, on page 1](#)

## New and Changed Information for this Release

The following table provides an overview of the significant changes to this guide for this current release. The table does not provide an exhaustive list of all changes made to this guide or of all new features in this release.

Feature	Description	Release/Date Added	Where Documented
Protected Virtual Machine Scalability	Highlighted scales on number of virtual machines supported per cluster.	4.0(2a)	<a href="#">Replication and Recovery Considerations</a>
Cisco HyperFlex HTML plug-in for VMWare vCenter plug-in	Allows you to launch HyperFlex Connect from the vSphere Client and perform management actions in the HyperFlex UI.	4.0(2a)	<a href="#">Cisco HyperFlex HTML plug-in for VMWare vCenter</a>
No Cluster Shutdown	Cluster no longer shuts down when data is no longer available due to any node/disk failure. Cluster recovers automatically when the resources are available again.	4.0(2a)	<a href="#">HX Data Platform Cluster Tolerated Failures</a>

Feature	Description	Release/Date Added	Where Documented
Recovery Settings	Provision to define the existing resources and connections of the network as recovery settings. So that, the resources mapping defined in the recovery settings is used to return the network to a known working state during recovery or test recovery.	4.0(2a)	<a href="#">Configuring the Recovery Settings</a>
Boost Mode	Allows the HyperFlex cluster to deliver higher IOPS	4.0(1b)	<a href="#">Boost Mode</a>
Other DRO Protection	Provision to protect VMs using SRM through disaster recovery orchestrator (DRO).	4.0(1a)	<ul style="list-style-type: none"> <li>• <a href="#">Creating a Replication Pair</a></li> <li>• <a href="#">Editing a Replication Pair</a></li> </ul>
Storage Replication Adapter	Provision to configure SRA and execute SRA workflows.	4.0(1a)	<ul style="list-style-type: none"> <li>• <a href="#">Managing Storage Replication Adapter</a></li> </ul>
Audit Logging	Support for configuring Audit Logging.	4.0(1a)	<ul style="list-style-type: none"> <li>• <a href="#">Audit Logging with HX Connect</a></li> <li>• <a href="#">Enabling Audit Logging</a></li> <li>• <a href="#">Disabling Audit Logging</a></li> <li>• <a href="#">Deleting Audit Logging Server Configuration</a></li> </ul>