



Overview

- [Introduction, on page 1](#)

Introduction

Cisco HyperFlex currently supports two command line interfaces (CLI):

- `hxcli`
- `stcli`

The Cisco HyperFlex `hxcli` commands are replacing `stcli` commands. When possible, use the `hxcli` commands as they perform much faster than the same `stcli` commands.

Intended Audience

The Cisco HyperFlex CLI are intended for use by customers and partners. When performing advanced operations, TAC assistance is recommended.

