



Overview

- [About this Guide, on page 1](#)

About this Guide

This guide presents an overview of the network and external storage architecture for Cisco HyperFlex Systems. It also describes network and external management procedures that are typically performed after configuration of the initial HyperFlex cluster.

This guide is for use with all supported HX versions.

