



Preface	xi
Audience	xi
Organization	xi
Conventions	xii
Safety Overview	xiv
Related Documentation	xvii
Obtaining Documentation	xvii
Cisco.com	xvii
Documentation CD-ROM	xviii
Ordering Documentation	xviii
Documentation Feedback	xviii
Obtaining Technical Assistance	xviii
Cisco TAC Website	xix
Opening a TAC Case	xix
TAC Case Priority Definitions	xix
Obtaining Additional Publications and Information	xx

CHAPTER 1

Product Overview	1-1
Features	1-2
Front Panel Description	1-5
Status LED	1-6
RJ-45 Connector	1-6
Operation	1-7
Traffic Flow	1-8

CHAPTER 2

Networking with the Content Switching Module	2-1
Configuring Modes for Networking	2-1
Configuring the Single Subnet (Bridge) Mode	2-1
Configuring the Secure (Router) Mode	2-4
CSM Networking Topologies	2-4
CSM Inline, MSFC Not Involved	2-5
CSM Inline, MSFC on Server Side	2-5
CSM Inline, MSFC on Client Side	2-6

CSM in Aggregate Mode 2-6
 Direct Server Return 2-7
 Routing with the CSM 2-7
 Protecting Against Denial-of-Service Attacks 2-8

CHAPTER 3

Getting Started 3-1

Operating System Support 3-1
 Preparing to Configure the CSM 3-1
 Using the Command-Line Interface 3-3
 Accessing Online Help 3-3
 Saving and Restoring Configurations 3-3
 Configuring SLB Modes 3-3
 Mode Command Syntax 3-4
 Migrating Between Modes 3-5
 Differences Between CSM and RP Modes 3-5
 CSM Mode 3-5
 RP Mode 3-6
 Changing Modes 3-7
 CSM Mode to RP Mode 3-7
 RP Mode to CSM Mode 3-7
 Verifying the Configuration 3-8
 Configuration Overview 3-9
 Upgrading to a New Software Release 3-11
 Upgrading from the Supervisor Engine Bootflash 3-11
 Upgrading from a PCMCIA Card 3-12
 Upgrading from an External TFTP Server 3-14

CHAPTER 4

Configuring VLANs 4-1

Configuring Client-Side VLANs 4-2
 Configuring Server-Side VLANs 4-3

CHAPTER 5

Configuring Real Servers and Server Farms 5-1

Configuring Server Farms 5-1
 Configuring Real Servers 5-2
 Configuring Dynamic Feedback Protocol 5-4
 Configuring Client NAT Pools 5-5
 Configuring Server-Initiated Connections 5-6

Configuring URL Hashing	5-6
Configuring a URL Hashing Predictor	5-6
Configuring Beginning and Ending Patterns	5-7

CHAPTER 6**Configuring Virtual Servers, Maps, and Policies** 6-1

Configuring Virtual Servers	6-1
Configuring TCP Parameters	6-4
Configuring Redirect Virtual Servers	6-5
Configuring Maps	6-8
Configuring Policies	6-11
Configuring Generic Header Parsing	6-12
Understanding Generic Header Parsing	6-12
Generic Header Parsing Configuration	6-12
Creating a Map for the HTTP Header	6-13
Specifying Header Fields and Match Values	6-14
Assigning an HTTP Header Map to a Policy	6-14
Assigning the Policy to a Virtual Server	6-15
Generic Header Parsing Example	6-15

CHAPTER 7**Configuring Redundant Connections** 7-1

Configuring Fault Tolerance	7-1
Configuring HSRP	7-5
HSRP Configuration Overview	7-5
Creating the HSRP Gateway	7-6
Creating Fault-Tolerant HSRP Configurations	7-7
Configuring Connection Redundancy	7-8
Configuring a Hitless Upgrade	7-9

CHAPTER 8**Configuring Additional Features and Options** 8-1

Configuring Sticky Groups	8-1
Configuring Route Health Injection	8-2
Understanding RHI	8-2
RHI Overview	8-2
Routing to VIP Addresses Without RHI	8-3
Routing to VIP Addresses with RHI	8-3
Understanding How the CSM Determines VIP Availability	8-3
Understanding Propagation of VIP Availability Information	8-4
Configuring RHI for Virtual Servers	8-4

- Environmental Variables 8-4
- Configuring Persistent Connections 8-8
- Configuring Global Server Load Balancing 8-8
 - Using the GSLB Advanced Feature Set Option 8-9
 - Configuring GSLB 8-9
- Configuring Network Management 8-13
 - Configuring SNMP Traps for Real Servers 8-13
 - Configuring the XML Interface 8-13

CHAPTER 9

Configuring Health Monitoring 9-1

- Configuring Probes for Health Monitoring 9-1
 - Probe Configuration Commands 9-3
 - Configuring an HTTP Probe 9-4
 - Configuring an ICMP Probe 9-5
 - Configuring a TCP Probe 9-5
 - Configuring FTP, SMTP, and Telnet Probes 9-6
 - Specifying the DNS Resolve Request 9-6
- Configuring Inband Health Monitoring 9-7
 - Understanding Inband Health Monitoring 9-7
 - Configuring Inband Health Monitoring 9-7
- Configuring HTTP Return Code Checking 9-8
 - Understanding HTTP Return Code Checking 9-8
 - Configuring HTTP Return Code Checking 9-9

CHAPTER 10

Configuring CSM Scripts 10-1

- Configuring TCL Scripts 10-1
 - Loading Scripts 10-2
 - Writing TCL Scripts 10-3
 - UDP Commands 10-4
 - Writing Health Scripts 10-5
 - Writing Standalone Scripts 10-8
 - Running TCL Scripts 10-8
 - Running Probe Scripts 10-8
 - Running Standalone TCL Scripts 10-9
 - Halting TCL Scripts 10-9
- Configuring Scripts for Health Monitoring Probes 10-10

CHAPTER 11**Configuring Firewall Load Balancing 11-1**

- Understanding How Firewalls Work 11-1
 - Firewalls Types 11-2
 - How the CSM Distributes Traffic to Firewalls 11-2
 - Supported Firewalls 11-2
 - Layer 3 Load Balancing to Firewalls 11-2
 - Types of Firewall Configurations 11-3
 - IP Reverse-Sticky for Firewalls 11-3
 - CSM Firewall Configurations 11-3
 - Fault-Tolerant CSM Firewall Configurations 11-6
- Configuring Stealth Firewall Load Balancing 11-7
 - Stealth Firewall Configuration 11-7
 - Stealth Firewall Configuration Example 11-8
 - Configuring CSM A (Stealth Firewall Example) 11-9
 - Configuring CSM B (Stealth Firewall Example) 11-12
- Configuring Regular Firewall Load Balancing 11-16
 - Packet Flow in a Regular Firewall Configuration 11-16
 - Regular Firewall Configuration Example 11-17
 - Configuring CSM A (Regular Firewall Example) 11-18
 - Configuring CSM B (Regular Firewall Example) 11-21
- Configuring Reverse-Sticky for Firewalls 11-24
 - Understanding Reverse-Sticky for Firewalls 11-24
 - Configuring Reverse-Sticky for Firewalls 11-26
- Configuring Stateful Firewall Connection Remapping 11-26

APPENDIX A**Configuration Examples A-1**

- Configuring Router Mode with the MSFC on the Client Side A-1
- Configuring Bridged Mode with the MSFC on the Client Side A-4
- Configuring Probes A-5
- Configuring Source NAT for Server-Originated Connections to the VIP A-7
- Configuring Session Persistence (Stickiness) A-9
- Direct Access to Servers in Router Mode A-10
- Server-to-Server Load Balanced Connections A-12
- Route Health Injection A-13
- Server Names A-16
- Backup Server Farm A-18
- Balancing Based on the Source IP Address A-24

Layer 7 Load Balancing **A-26**

HTTP Redirect **A-29**

APPENDIX B

Troubleshooting and System Messages B-1

Troubleshooting **B-1**

System Messages **B-1**

APPENDIX C

CSM XML Document Type Definition C-1