



## Preface

---

This document provides detailed information about the Cisco Instant Connect MIDlet. This application lets you use supported Cisco Unified Wireless IP Phone models to communicate with other Cisco IPICS users via a point-to-point or standard telephone call, and communicate via channels, VTGs, and incidents by using your phone as a push-to-talk device.

## Audience

This document is intended for administrators who will configure the Cisco Instant Connect MIDlet and for users who will run the MIDlet on a Cisco Unified Wireless IP Phone.

## Organization

This document is organized as follows:

<a href="#">Chapter 1, “Overview”</a>	Describes the Cisco Instant Connect MIDlet, explains the Cisco Unified Wireless IP Phone buttons that you can use with the MIDlet, and provides an overview of the screens that the MIDlet can display
<a href="#">Chapter 2, “System Configuration”</a>	Describes how to add the CiscoInstantConnect service to Cisco Unified Communications Manager, and how to subscribe Cisco Unified Wireless IP Phones to this service
<a href="#">Chapter 3, “Using the Cisco Instant Connect MIDlet”</a>	Describes how to use the Cisco Instant Connect MIDlet
<a href="#">Chapter 4, “System Messages”</a>	Explains the Cisco Instant Connect MIDlet system messages that can appear when a situation requires you to take corrective action

# Obtaining Documentation, Obtaining Support, and Security Guidelines

For information about obtaining documentation, obtaining support, providing documentation feedback, security guidelines, and recommended aliases and general Cisco documents, see the monthly *What's New in Cisco Product Documentation*. This publication also lists new and revised Cisco technical documentation. It is available at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>