

Finding Feature Information

Last Updated: December 20, 2011

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

© 2011 Cisco Systems, Inc. All rights reserved.





SIP Ability to Send a SIP Registration Message on a Border Element

Last Updated: December 20, 2011

The SIP: Ability to Send a SIP Registration Message on a Border Element feature allows users to register e164 numbers from the Cisco UBE without POTS dial-peers in the UP state. Registration messages can include numbers, number ranges (such as E.164-numbers), or text information.

• Configure a registrar in sip UA configuration mode.

Cisco Unified Border Element

• Cisco IOS Release 12.4(24)T or a later release must be installed and running on your Cisco Unified Border Element.

Cisco Unified Border Element (Enterprise)

 Cisco IOS XE Release 2.5 or a later release must be installed and running on your Cisco ASR 1000 Series Router.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. sip-ua
- 4. credentials username username password password realm domain-name
- 5. exit
- 6. end

DETAILED STEPS

	Command or Action	Purpose
tep 1	enable	Enables privileged EXEC mode.
		Enter your password if prompted.
	Example:	
	Router> enable	
tep 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	sip-ua	Enters sip user-agent configuration mode.
	Example:	
	Router(config)# sip-ua	
tep 4	credentials username username password password realm domain-	Enters SIP digest credentials in sip-ua configuration mode.
	name	configuration mode.
	Example:	
	Router(config-sip-ua)# credentials username alex password	
	test realm cisco.com	
tep 5	exit	Exits the current mode.
	Example:	
	Router(config-sip-ua)# exit	
tep 6	end	Returns to privileged EXEC mode.
	Example:	
	Router(config)# end	

 $[\]bullet~$ Feature Information for Sending a SIP Registration Message from a Cisco Unified Border Element, page 4

Feature Information for Sending a SIP Registration Message from a Cisco Unified Border Element

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Feature History Table entry for the Cisco Unified Border Element.

Table 1 Feature Information for Sending a SIP Registration Message from a Cisco Unified Border Element

Feature Name	Releases	Feature Information
SIP: Ability to Send a SIP Registration Message on a Border Element	12.4(24)T	Provides the ability to send a SIP Registration Message from Cisco Unified Border Element.
		The following command was modified: credentials (SIP UA)

Feature History Table entry for the Cisco Unified Border Element (Enterprise).

Table 2 Feature Information for Sending a SIP Registration Message from a Cisco Unified Border Element

Feature Name	Releases	Feature Information
SIP: Ability to Send a SIP Registration Message on a Border Element	Cisco IOS XE Release 2.5	Provides the ability to send a SIP Registration Message from Cisco Unified Border Element.
		The following command was modified: credentials (SIP UA)

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.