



LEDs

You can perform the following check on LEDs that assist you with the troubleshooting process:

- [System Control Module LEDs, on page 1](#)
- [Switch Main Board LED, on page 1](#)
- [Port Status LEDs, on page 2](#)
- [Power Module LED, on page 3](#)
- [Fan Tray LED, on page 4](#)

System Control Module LEDs

The System Control Module (SCM) LEDs are located on the front of the module.

Figure 1: SCM LEDs





Table 1: SCM LEDs

1	SCM Status
2	SMB Status
3	PSU Status
4	Fan Status
5	System Status

Switch Main Board LED

The Switch Main Board (SMB) card is in front of the chassis.


Figure 2: SMB LEDs



Port Status LEDs

Each port on the 8501-SYS-MT has two LEDs. The following table describes port status LEDs.

Figure 3: Port LEDs





Note The Port LEDs from 1 to 64 are for the OSFP ports and the port LED 65 is for PIE port.

Power Module LED

The power module LED is located on the lower right portion of the module.

Figure 4: AC Power Supply LED





Figure 5: DC Power Supply LED




1	Status
---	--------

Fan Tray LED

The fan tray LED is located on the bottom rightportion of the fan tray.

Figure 6: Fan Tray LED



1	Status
---	--------

