



APPENDIX B

Processed SNMP Traps and Corresponding Cisco netManager Events

This section lists the traps that Cisco netManager processes and the events that Cisco netManager generates for each trap. For information on Cisco netManager events, see [Appendix A, “Events Processed.”](#)

Processed Standard SNMP Traps (RFC 1215)

SNMP Trap	Corresponding Cisco netManager Event
Cold Start	Cold Start Cisco Event
Warm Start	Warm Start Cisco Events
Link Up Link Down	Flapping—Link Down trap raises the event, and the Link Up trap clears the event

Processed CISCO-UNITY-EXPRESS-MIB Traps

SNMP Trap	Corresponding Cisco netManager Event
ciscoUnityExpressApplAlert	CUE Application Status Change
ciscoUnityExpressStorageAlert	CUE Storage Issue
ciscoUnityExpressSecurityAlert	CUE Security Issue
ciscoUnityExpressCallMgrAlert	CUE CCM Connection Lost
ciscoUnityExpressRescExhausted	CUE Resource Exhausted
ciscoUnityExpressBackupAlert	CUE Backup Failed
ciscoUnityExpressNTPAlert	CUE NTP Issue

Processed CISCO-CCME-MIB Traps

SNMP Trap	Corresponding Cisco netManager Event
ccmeEPhoneDeceased	CCME Ephone Deceased
ccmeEphoneLoginFailed	CCME Ephone Login Failed
ccmeEPhoneRegFailed	CCME Ephone Registration Failed
ccmeEphoneUnRegThresholdExceed	CCME Ephone Registrations Exceeded
ccmeKeyEphoneRegChangeNotif	CCME Key Ephone Registration Change
ccmeLivefeedMohFailedNotif	CCME Livefeed MOH Failed
ccmeMaxConferenceNotif	CCME Maximum Conferences Exceeded
ccmeNightServiceChangeNotif	CCME Night Service Change
ccmeStatusChangeNotif	CCME Status Change

Processed CISCO-SRST-MIB Traps

SNMP Trap	Corresponding Cisco netManager Event
csrstFailNotif	SRST Router Failure