



# Installation Requirements

---

This chapter describes the requirements that need to be met before you install Cisco Prime NAM.

- [Nexus 1110 Virtual Services Appliance Requirements, page 1](#)
- [Configuration Requirements, page 1](#)

## Nexus 1110 Virtual Services Appliance Requirements

The Nexus 1110 appliance must have the following minimum resources available for use as a virtual blade:

- 2G RAM
- 53G disk space

## Configuration Requirements

Before you begin the software installation, ensure that the devices have been physically installed and set up for the following:

- The Nexus 1110 appliance has network connectivity through an Ethernet interface and is accessible using the serial console.
- The Cisco Prime NAM 6.1 software image is available on the Nexus 1110 appliance.
- The Nexus 1110 appliance has adequate resources available to run Cisco Prime NAM 6.1.

