



Icon Reference

The following topics describe the icons used in Cisco Prime Collaboration Manager:

- [Device State Icons, page C-1](#)
- [Fault Icons, page C-3](#)
- [Fault Icons—Device, page C-4](#)
- [Session Icons, page C-6](#)
- [Toolbar Icons, page C-7](#)

Device State Icons

Table C-1 *Device State Icons*





Device Type	Managed	Inaccessible	Other Device State
CTS 500			<ul style="list-style-type: none"> • For Managed—No outline (as shown in the Managed column). • For Inaccessible—Icon is in gray and no outline (as shown in the Inaccessible column). • For Suspended—Outline is in mustard. • For Unknown—Outline is in teal. • For Unreachable—Outline is in gray.
CTS 1000			

Table C-1 Device State Icons (continued)

















Device Type	Managed	Inaccessible	Other Device State
CTS 3000			
CTMS			
Router			
Switch			

Table C-1 Device State Icons (continued)

Device Type	Managed	Inaccessible	Other Device State
Cisco Mediatrace enabled on router			
Cisco Mediatrace enabled on switch			

Fault Icons

Table C-2 Fault Icons

Icon	Description
	Critical
	Major
	Minor
	Normal

Fault Icons—Device

Table C-3 Fault Icons—Device









Device Type	Critical	Other Severities
CTS 500		<ul style="list-style-type: none"> • For Critical—Outline is in red (as shown in the Critical column). • For Major—Outline is in orange. • For Minor—Outline is in yellow. • For Normal—Outline is in green.
CTS 1000		
CTS 3000		
CTMS		

Table C-3 *Fault Icons—Device (continued)*

Device Type	Critical	Other Severities
Router		
Switch		
Cisco Mediatrace enabled on router		
Cisco Mediatrace enabled on switch		

Session Icons

Table C-4 Session Icons


























Icon	Description
	Ad hoc session.
	Session completed.
	In-progress session.
	Static session in-progress
	Multipoint session.
	Point-to-point session.
	No show. Displayed <ul style="list-style-type: none"> • If it is a scheduled session but nobody joined the session or • When the participants joined the session but disconnected from the in-progress session.
	Scheduled session.
	Session or endpoint added to watch list.
	Session status.
	Session type.
	All sessions.
	Troubleshooting workflow in progress.
	Troubleshooting report is available.
	Session abnormally terminated because of network issue (such as huge packet loss).

Table C-4 *Session Icons*

Icon	Description
	<p>Error. This is displayed when there is a critical service infrastructure, unreachable, or inaccessible alarm.</p> <p>This icon is displayed in the Video Collaboration Service Infrastructure dashlet for application manager, multipoint switch, and call processors in the Home page.</p> <p>In the Endpoints Monitoring page, this icon represents endpoints that are not registered in Cisco Unified CM.</p>
	Suspended state.

Toolbar Icons**Table C-5** *Toolbar Icons*

Icon	Description
	Refresh
	Launch help
	E-learning VODs
	About Cisco Prime CM. Provides details on version and license.
	Filter
	Customize the table column display.
	Toggle from tabular to chart view.
	Toggle from chart to tabular view.

