

Monitoring Quality of Service

Quality of Services (QoS) is the technique of prioritizing traffic flows and specifying preferences for forwarding packets with higher priority. It prioritizes traffic flow for different applications, users, or data flows and ensures certain level of performance to a data flow. This service plays an important part when the network capacity is insufficient, especially for real time streaming multimedia applications such as VoIP, online games, and IP-TV.

In Prime Network, you can view all the services configured for the selected network element in the QoS node under logical inventory.

The QoS Node under logical inventory is made up of two sub-nodes—the Policy Container and the Class of Service container. Both these sub-nodes are explained in greater detail in the following sections.

Viewing the Service Policy and Policy Group Profiles

The Policy Container node in the logical inventory lists all the available service groups and service policies that are associated with service templates, BBA groups, and subscriber access points.

To view the service policy and policy group profiles:

- **Step 1** Right-click on the required device and choose the **Inventory** option.
- Step 2 In the Inventory window, choose Logical Inventory> QoS> Policy Container. The Policies tab is displayed by default in content pane, which lists the existing policies are displayed as shown in Figure 21-1.

Figure 21-1	Policy Container
-------------	------------------

9 01 [5M]									_ U X
▼201	[5M]	1 🕐 Pi	oll Now						
- 🗐 💎 🛛	ogical Inventory [3M]	Polici	Bolicy Groups						
	Access Lists	Fond	rolicy droups						
	ATM Traffic Profiles				-				
	Bridges	E E	na :	₩ Ž+ V Y					
	Cisco Discovery Protocol	Nan	ne 🖶 🗸	T	'De		Processing Strategy		
> T	Clock [3M]	vide	e-policy	0	5		Match All		
	Ethernet Link Aggregation	VIGC	to policy	×			Macarina		
	Ethernet LMI								
▶	IS-IS System								
	Link Layer Discovery Protocol								
)	LSEs								
	MPBGPs								
	Operating Suctors								
> 	OSPE Processes								
> Ø	Probes								
	Pseudowires								
-	QoS								
	Class of Services								
	Policy Container								
	Resilient Ethernet Protocol								
1 1	Routing Entities								
	spanning free Protocol	•							
Q Device Zoom	E Best Fit								
								L	ine 0 (Size 1)
		•							
								100	AL 🐣
									21 -
▽	Severities	•	Acknowledged State 👻	Detection Type	 Advanced Filte 	er Clear			
Severity Ticke	t ID N Last Modification Time	€v	Root Root Event Ti	me	Description	Location	Element Type	Acknowledged	Creation Ti
Tickets Netw	ork Events Provisioning Events				2				
						M	lemory: 🗾 25%	Connected	
						and the second second			

Step 3Right-click the policy and choose Properties. The Service Policy Properties window is displayed.Table 21-1 describes the fields that are displayed in the Service Policy Properties window.

Field Name	Description						
Name	The name of the policy.						
Туре	The type of policy, which defaults to QoS.						
Processing Strategy	The strategy in applying the policy, which defaults to Match All.						
Policy Rules & Actions tab							
Name	The name of the policy rule.						
Match Condition	The class of service associated to the policy. Clicking this link will take you to the relevant service under the Class of Service node in the logical inventory.						
Action Execution Strategy	 The policy execution strategy, which can be any of the following: Execute All Execute Until Success Execute Until Failure 						
Applied Interfaces tab							

Table 21-1Service Policy Properties

ſ

Field Name	Description
Interface Name	The name of the interface on which the service policy is applied.
Entity Association	The logical or physical port to which the policy is associated to. Clicking this link will display the relevant ethernet/gigabit ethernet port. Verify the Ingress Policy or Egress Policy applicable to the port.
Action Lists tab	
Sequence Number	The sequence number of the action list.
Action Type	The action taken on the entity. For example, Activate, Deactivate, Authenticate and Authorize.
Affected Entity Type	The entity type affected due to the selected action list. For example, service-policy, traffic shaping.
Affected Entity	The entity that gets affected due to the selected action.
Entity Association	The link to the entity affected due to the action. Clicking on this link will take you to the relevant entity. For example, if the associated entity is a policy, then clicking this link will take you to the relevant policy under the Policy Container node.

Table 21-1 Service Policy Properties (continued)

Step 4 Close the Service Policy Properties window.

- Step 5 In the content pane, click the Policy Group tab. A list of existing groups are displayed.
- Step 6 Right-click the policy group and choose Properties.

Table 21-2 describes the fields in the Policy Group tab.

Field Name	Description					
Name	The name of the policy group.					
Туре	The type of policy group, which can be any one of the following:					
	• Accounting					
	• Control					
	• PBR					
	Performance Traffic					
	• QoS					
	• Traffic					
	• Redirect					
	This field defaults to Control.					
Processing Strategy	The strategy in applying the policy, which defaults to Match All.					
Policies						
Name	The name of the service policy map.					
Туре	The type of policy map.					
Processing Strategy	The strategy in applying the policies on the incoming traffic.					

Table 21-2Policy Group Properties

Field Name	Description
Applied Interfaces tab	
Interface Name	The name of the interface on which the service policy is applied.
Entity Association	The logical or physical port to which the policy is associated to. Clicking this link will display the relevant logical or physical port. Verify the Ingress Policy or Egress Policy applicable to the port.

Table 21-2	Policy Group	Properties	(continued)
------------	--------------	------------	-------------

Step 7 In the **Policies** tab, Right-click the policy from the list and choose **Properties**. The Service Policy Properties dialog box is displayed. See Table 21-1 for more details.

Figure 21-2 shows the association between the policy and interface.

Figure 21-2 Policy and Interface Association

Name: MSI Processing Strategy: Mai	N_Policy_egre	ss 16 Type		
	tch All	33_10 ()poi	QoS	
Policy Rules & Actions Ap	plied Interfaces]		
Policy Rules				
Find :	_ 1 ≜↓ ¬	V 🎙 🐺 🔽 🕞	olicy Rules & Actions Applied	Interfaces
Name $\begin{array}{c} \begin{array}{c} \begin{array}{c} \end{array}{} \end{array}$	Match	Condition	Find :	▋ \$↓ ▽ ▼ ■ ■
Control	10.10	14 120 175#Control	Interface Name 🛛 🕀 /	Associated Entity
COST	10.10	14 120 175#COS1	Bundle-Ether200	10.104.120.195#Aggregation Group 200
052	10.10	4 120 175#CO52	GigabitEthernet0/1/0/8.10	10.104.120.195#0.1:GigabitEthernet0/1/0/8
C052V	10.10	14.120.175#CO52V	GigabitEthernet0/1/0/8.30: EFP	30 10.104.120.195#0.1:GigabitEthernet0/1/0/8 EFP::
C053	10.10	14.120.175#CO53	GigabitEthernet0/1/0/9	10.104.120.195#0.1:GigabitEthernet0/1/0/9
			GigabitEthernet0/1/0/14	10.104.120.195#0.1:GigabitEthernet0/1/0/14
Action Lists				
Find :	₽ ↓ ¬	v 🕆 🖩 🔽		
Sequence Number 🛛 🕀 🛆	Action Type	Affected Entity Type	Affected Entity	Entity Association
1	Set	Traffic-shaping	CIR: 20 %	
2	Set	Service-Policy	mytest123	10.104.120.175#mytest123
3	Set	Policing	CIR: 30 %	a
4	Set	COS	2	
5	Set	DSCP	cs1	

Viewing the Class of Services Profile

To view the QoS profile:

Step 1 Right-click on the device and choose the **Inventory** option.

I

- **Step 2** In the **Inventory** window, choose **Logical Inventory** > **QoS** > **Class of Services**. A list of existing policies are displayed in the content pane.
- **Step 3** Right-click a service in the list and choose **Properties**. The Class of Services Properties dialog box is displayed. You can click on the tabs to view more details.

Table 21-3 describes the fields that are displayed in the Class of Services Properties dialog box.

Table 21-3Class of Services Properties

Field Name	Description
Name	The name of the class of service.
Туре	The type of the class of service, which can be any one of the following:
	• Control
	• QoS
	• Traffic
	This field defaults to QoS.
Matching Strategy	The matching condition for the service, which can be any one of the following:
	• Match All
	• Match Any
	Match None
	This field defaults to Match All.
Match Criteria Lists	
Index	The sequential number for the match criterion.
Match Type	The type that is used to match lists. For example, Access Group, Discard-class, DSCP, MPLS, QoS-group.
Match Condition	The match condition for the class of service, which can be any one of the following:
	• available/not available
	• class
	• greater-than/not greater-than
	• greater-than-or-equal/not greater-than-or-equal
	• less-than/not less-than
	• less-than-or-equal/not less-than-or-equal
Match Value	The value associated with the match type.
Associated Entity	The entity specified in the Match Value field. Click this hyperlink to view the related record.

Viewing Ingress and Egress Speed Details

Traffic shaping technique is used to match device and link speeds, thereby controlling packet loss, variable delay, and link saturation, which can cause jitter and delay. Traffic shaping must be applied to all outgoing traffic on a physical interface or on a VLAN. Traffic shaping is implemented when packets are ready to be transmitted on an interface. Traffic shaping is applied on the subinterfaces of the layer 2 and layer 3 when QoS policy is applied.

To view the ingress and egress details when QoS policy is applied on the subinterfaces:

- Step 1 In the Inventory window, choose Physical Inventory.
- **Step 2** Select an interface in layer 2 or layer 3.
- **Step 3** Select a subinterface for which you want to view the ingress and egress speed details.
- **Step 4** Click the **EFP** tab or **Sub Interface** tab to view the speed details of the subinterface mapped on layer 2 or layer 3 respectively. Figure 21-2 shows the speed details on a subinterface.

Figure 21-3 Speed Details

A DOLLAR ALLOW								
A hos now								
Location Informati	ion							
Type:	Pluggable	Location:	1.0.Gigat	atEthernet0/1/0	/0			
Sending Alarms:	true	Status:	ОК					
Port Alas: GigabitEthernet0/1/0/0 Mana			jodi true					
🔒 Disable Send	ing Alerma							
Pluggable Transce	û-ee							
Connector Type:	Fiber Optic			Pluggable Typ	e: SFP			
Connector Descr	ption: 1000BASE-SX S	PP (DOM), MM	F, 550/220	n PID:	SEP-CE-S			
					201 F 100 D			
Connector Serial	Number: FNS15281VH4			Pluggable Par	t State: In			
Connector Serial	Number: FNS15281VH4	* 5 5		Pluggable Por	t State: In			
Connector Serial Pind : VLAN IP In	Number: FNS15281VH4	や 原 号 Binding	Is MPLS	Pluggable Por	t State: In Ingress Speed (https)	Egress Policy	Egress Speed (rbps)	Service Contr
Find :	Number: FNS15281VH4	♥ 屛 局 Binding	Is MPLS false	Pluggable Por Ingress Policy as 9k#son	t State: In Ingress Speed (12ps) B	Egress Policy asrSkafson	Egross Speed (Kbps)	Service Contr
VLAN JP IN	Namber: FNS152819H4	中 原 局 Binding	ts MPLS false false	Pluggable Por Ingress Policy ac 9k#son	t State: In Ingress Speed (12ps) B	Egress Policy asrSkafsom	Egress Speed (Kbps) B	Service Contro
VLAN 3P In	Namber: FNS152814H4	♥ 罪 局 Binding	ts MPLS false false false	Pluggable Por Ingress Policy asr9kdpolicy3	t State: In Ingress Speed (https:) 8	Egress Pokcy asr9katson asr9katpokcy3	Egress Speed (Kbps) B	Service Contra
Find : VLAN IP IN	Namber: FNS152814H4	♥ 詳 局 Binding	Ls MPLS false false false false	Pluggable Por Ingress Policy as:9k#son as:9k#son as:9k#csoo	t Sate: In Ingress Speed (12ps) 0 0	Egress Pokcy asr9k#san asr9k#pokcy3 asr9k#cis	Egress Speed (Objec) B D 22	Service Contra
Connector Serial Find : VLAN IP In	Namber: FNS152814H4	♥ 罪 畸 Binding	Ls MPLS talon talon talon falon talon	Pluggable Par Ingress Policy as 9k#son as 9k#son as 9k#cisco as 9k#cisco	t Sate: In Ingress Speed (1200) 8 0 40 40	Egress Policy acrification arrification asrification acrification	Egress Speed (Rbps) B 32 B	Service Contro

The following table provides information about the fields that are not self-explanatory.

Table 21-4 describes the fields that are not self-explanatory

Table 21-4 Traffic Shaping Details

Field Name	Description
Egress Policy	The name of the egress policy.
Egress Speed	The traffic shaping of the outgoing packets in an interface.
Ingress Policy	The name of the ingress policy.
Ingress Speed	The traffic shaping of the incoming packets in an interface.



Γ

Ingress policy, egress policy, ingress speed, and egress speed are supported in Cisco ASR 9000 devices but ingress policy and ingress speed are not supported in Cisco ASR 903 device and egress policy and egress speed are not supported in Cisco ASR 901 device



1

