



Unsupported CLI Commands for the ML-Series Card

This appendix lists some of the command-line interface (CLI) commands that are not supported in this release, either because they were not tested, or because of hardware limitations. These unsupported commands are displayed when you enter the question mark (?) at the CLI prompt. This is not a complete list. Unsupported commands are listed by command mode.

Unsupported Privileged Exec Commands

```
clear ip accounting
show controller pos pm
show controller pos [variable] pm
show ip accounting
show ip cache
show ip tcp header-compression
show ip mcache
show ip mpacket
show ons alarm defect vt
show ons alarm failure vt
```

Unsupported Global Configuration Commands

```
access-list aaa <1100-1199>
access-list aaa <200-299>
access-list aaa <700-799>
async-bootp
boot
bridge <num> acquire
bridge <num> address
```

bridge cmf
bridge <num> bitswap-layer3-addresses
bridge <num> circuit-group
bridge <num> domain
bridge <num> lat-service-filtering
bridge <num> protocol dec
bridge <num> protocol ibm
bridge <num> protocol vlan-bridge
chat-script
class-map match access-group
class-map match class-map
class-map match destination-address
class-map match mpls
class-map match protocol
class-map match qos-group
class-map match source-address
clns
define
dialer
dialer-list
downward-compatible-config
file
ip access-list log-update
ip access-list logging
ip address-pool
ip alias
ip bootp
ip gdp
ip local
ip radius nas-ip-address (Command distinguishes multiple ONS 15454 SONET/SDH ML-Series cards.)
ip reflexive-list
ip security
ip source-route
ip tcp
ipc
map-class
map-list
multilink

netbios
partition
policy-map class queue-limit
priority-list
queue-list
router iso-igrp
router mobile
service compress-config
service disable-ip-fast-frag
service exec-callback
service nagle
service old-slip-prompts
service pad
service slave-log
subscriber-policy

Unsupported POS Interface Configuration Commands

access-expression
autodetect
bridge-group x circuit-group
bridge-group x input-*
bridge-group x lat-compression
bridge-group x output-*
bridge-group x subscriber-loop-control
clock
clns
crc 32 (CRC is 32-bit size by default and not configureable on ONS 15310-CL ML-Series.)
custom-queue-list
down-when-looped
fair-queue
flowcontrol
full-duplex
half-duplex
hold-queue
ip accounting
ip broadcast-address
ip load-sharing per-packet

ip route-cache
ip security
ip tcp
ip verify
iso-igrp
loopback
multilink-group
netbios
pos flag c2
pos scramble-spe
pos vcat resequence
priority-group
pulse-time
random-detect
rate-limit
rmon
scramble
serial
service-policy history
source
timeout
transmit-interface
tx-ring-limit

Unsupported FastEthernet Interface Configuration Commands

access-expression
clns
custom-queue-list
fair-queue
hold-queue
ip accounting
ip broadcast-address
ip load-sharing per-packet
ip route-cache
ip security
ip tcp
ip verify

iso-igrp
keepalive
loopback
max-reserved-bandwidth
multilink-group
netbios
priority-group
random-detect
rate-limit
service-policy history
timeout
transmit-interface
tx-ring-limit

Unsupported Port-Channel Interface Configuration Commands

access-expression
carrier-delay
cdp
clns
custom-queue-list
duplex
down-when-looped
encapsulation
fair-queue
flowcontrol
full-duplex
half-duplex
hold-queue
iso-igrp
keepalive
max-reserved-bandwidth
multilink-group
negotiation
netbios
ppp
priority-group
rate-limit

random-detect
timeout
tx-ring-limit

Unsupported BVI Interface Configuration Commands

access-expression
carrier-delay
cdp
clns
flowcontrol
hold-queue
iso-igrp
keepalive
l2protocol-tunnel
load-interval
max-reserved-bandwidth
mode
multilink-group
netbios
ntp
mtu
rate-limit
timeout
transmit-interface
tx-ring-limit