



# CHAPTER 6

## CLR Commands

---

This chapter provides CLR (clear) commands for the Cisco ONS 15454 SDH and Cisco ONS 15600 SDH.

### 6.1 CLR-COND-SECU

(Cisco ONS 15454 SDH and ONS 15600 SDH) The Clear Security Condition (CLR-COND-SECU) command clears the specified standing condition.

---

**Usage Guidelines** In Software Release 6.0 and later, only the INTRUSION-PSWD parameter value is supported.

---

**Category** Security

---

**Security** Superuser

---

**Input Format** CLR-COND-SECU:[<TID>]::<CTAG>[::<SECUALMTYPE>];

---

**Input Example** CLR-COND-SECU:CISCO::123::INTRUSION-PSWD:

---

<b>Input Parameters</b>	<SECUALMTYPE>	(Optional) Secure alarm type. Defaults to INTRUSION-PSWD. The parameter type is SECUALMTYPE, which is the security alarm type.
	<ul style="list-style-type: none"><li>INTRUSION-PSWD</li></ul>	Condition raised after an invalid password is used during login. Condition is raised only if the password is used a specified number of times.

---

