



CHAPTER 6

CLR Commands

This chapter provides CLR (clear) commands for the Cisco ONS 15454 SDH and Cisco ONS 15600 SDH.

6.1 CLR-COND-SECU

(Cisco ONS 15454 SDH and ONS 15600 SDH) The Clear Security Condition (CLR-COND-SECU) command clears the specified standing condition.

Usage Guidelines In Software Release 6.0 and later, only the INTRUSION-PSWD parameter value is supported.

Category Security

Security Superuser

Input Format CLR-COND-SECU:[<TID>]::<CTAG>[::<SECUALMTYPE>];

Input Example CLR-COND-SECU:CISCO::123::INTRUSION-PSWD:

| | | |
|-------------------------|--|--|
| Input Parameters | <SECUALMTYPE> | (Optional) Secure alarm type. Defaults to INTRUSION-PSWD. The parameter type is SECUALMTYPE, which is the security alarm type. |
| | <ul style="list-style-type: none">INTRUSION-PSWD | Condition raised after an invalid password is used during login. Condition is raised only if the password is used a specified number of times. |
