



CHAPTER 9

DISC Commands

This chapter provides disconnect (DISC) commands for the Cisco ONS 15310-CL, Cisco ONS 15310-MA, Cisco ONS 15454, and Cisco ONS 15600.

9.1 DISC-TACC

(Cisco ONS 15310-CL, Cisco ONS 15310-MA, Cisco ONS 15454, and Cisco ONS 15600) The Disconnect Test Access (DISC-TACC) command disconnects the test access point (TAP) and puts the connection back to its original state (no splits). For more information on test access (TACC), refer to the *Cisco ONS SDH and Cisco ONS 15600 SDH TLI Reference Guide*.

Usage Guidelines

For this command to be applicable, you must first create the TAP using the ED-<MOD_PATH> command.

**Note**

If you send this command to an already disconnected TAP connection, an SADC error message is returned.

**Note**

If the system cannot release TAP, an SRTN error message is returned.

Category

Troubleshooting and Test Access

Security

Maintenance

Input Format

DISC-TACC:[<TID>]:<TAP>:<CTAG>;

Input Example

DISC-TACC:CISCO:8:123;

Input Parameters	<TAP>	The test access point number. The TAP number must be an integer with a range of 1 to 999. String Note This command only supports disconnecting one TAP at a time.
-------------------------	-------	---
