



# APPLY Commands

This chapter provides apply (APPLY) commands for the Cisco ONS 15454, Cisco ONS 15454 M2, and Cisco ONS 15454 M6.



**Note**

All commands supported on the Cisco ONS 15454 platform are also supported on Cisco ONS 15454 M2 and Cisco ONS 15454 M6 platforms.

## 3.1 APPLY

(Cisco ONS 15454, ONS 15454 M2, and ONS 15454 M6) The Apply (APPLY) command activates or reverts a software load during a software upgrade or downgrade process.

### Usage Guidelines

An error will be generated if you attempt to activate an older software load or attempt to revert to a newer software load.

### Category

File Transfer

### Security

Superuser

### Input Format

APPLY:[<TID>]::<CTAG>[::<MEM\_SW\_TYPE>];

### Input Example

APPLY:CISCO::123::ACT;

### Input Parameters

<MEM_SW_TYPE>	(Optional) Memory switch action during the software upgrade. The parameter type is DL_TYPE, which indicates the software download type. The default value is ACT.
• RVRT	Reverts to an older software load during software download.
• ACT	Activates to a new software load.

