



New and Changed Information

This table summarizes the new and changed information for Hardware Installation Guide in Release 6.1.1, and tells you where the features are documented.

Table 1: New and Changed Features - Release 6.1.1

Feature	Description	Where Documented
110 V/220 V AC PSU	NCS 1002 AC PSU supports both 110 V and 220 V. However, when the input voltage is 110 V, you cannot provision slice 2 and 3 as they are not detected. In this state, alarms are raised for slices 2 and 3.	Connect AC Power to NCS 1002
Connect an SFP to the ETH1 management port	You can connect an SFP to the ETH1 management port.	Connect to the Management Port
Pluggables	QSFP-100G-AOC pluggable is supported.	Product IDs

This table summarizes the new and changed information for Hardware Installation Guide in Release 6.0.1, and tells you where the features are documented.

Table 2: New and Changed Features - Release 6.0.1

Feature	Description	Where Documented
40G Ethernet client ports	40G Ethernet client ports are supported.	Cisco NCS 1002 Overview
Pluggables	QSFP-40G-SR-BD and QSFP-40G-LR4-S pluggables are supported.	Product IDs

Feature	Description	Where Documented
DC Power	The user can connect DC power to NCS 1002.	Connect DC Power to NCS 1002
Secure Erase	The user can securely wipe data in NCS 1002 disks using the Secure Erase feature. The Secure Erase feature is supported from BIOS version v13.10.	Wipe Data in Disk Using Secure Erase