
Numerics

4K VLANs (support for 4,096 VLANs) [2](#)

802.10 SAID (default) [6](#)

802.1Q

encapsulation [4](#)

Layer 2 protocol tunneling

See Layer 2 protocol tunneling

mapping to ISL VLANs [12](#)

trunks [2](#)

restrictions [6](#)

tunneling

configuration guidelines [4](#)

configuring tunnel ports [5](#)

overview [1](#)

802.1Q Ethertype

specifying custom [16](#)

802.1s

See MST

802.1w

See MST

802.1X

See port-based authentication

802.3ad

See LACP

802.3Z Flow Control [14](#)

using with WCCP [10](#)

access port, configuring [14](#)

ACEs and ACLs [1](#)

IPX MLS, flow masks and [3](#)

acronyms, list of [1](#)

addresses

IP, see IP addresses

MAC, see MAC addresses

advertisements, VTP [2](#)

aggregate policing

see QoS policing

aging-time

IP MLS [8,10](#)

IPX MLS [7](#)

alarms

major [4](#)

minor [4](#)

ARP throttling [5](#)

audience [21](#)

authentication

See also port-based authentication

Authentication, Authorization, and Accounting

See also AAA [1](#)

Authentication, Authorization, and Accounting (AAA) [1](#)

authorized ports with 802.1X [4](#)

auto-sync command [3,6,7](#)

auxiliary VLAN

See voice VLAN

A

AAA [1](#)

abbreviating commands [5](#)

access control entries and lists [1](#)

access lists

B

BackboneFast

See STP BackboneFast

blocking state, STP [8](#)

boot bootldr command [26, 27](#)

boot command [22](#)

boot config command [26](#)

BOOTLDR environment variable

- (example) [27](#)
- configuring [27](#)
- description [25](#)
- setting [27](#)

boot loader image [25, 27](#)

boot system command [21, 26](#)

boot system flash command [22](#)

BPDUs guard

- See STP BPDUs guard

bridge ID

- See STP bridge ID

bridge priority, STP [30](#)

bridge protocol data units

- see BPDUs

broadcast storms

- see traffic-storm control

broadcast suppression [1](#)

- enabling [3](#)

C

cache

- IP MLS
 - overview [3](#)
- IPX MLS
 - displaying entries [9](#)
 - overview [2](#)

cache engine clusters [1](#)

cache engines [1](#)

cache farms

- See cache engine clusters

cautions for passwords

- encrypting [17](#)
- TACACS+ [17](#)

CBAC [5](#)

CDP

- configuration task lists [1](#)
- enabling on an interface [2](#)
- monitoring and maintaining [3](#)
- overview [1](#)

cdp enable command [2](#)

CEF [1](#)

- configuring
 - MSFC2 [5](#)
 - supervisor engine [5](#)
- examples [3](#)
- Layer 3 switching [2](#)
- packet rewrite [2](#)

CEF for PFC2

- See CEF

CGMP [1](#)

- multicast router ports
 - specifying [12](#)

channel-group group

- command [8](#)
- command example [8](#)

checking

- configuration, system [10](#)

Cisco Cache Engines [2](#)

Cisco Discovery Protocol

- See CDP

Cisco Group Management Protocol

- See CGMP

Cisco IOS firewall feature set [5](#)

Cisco IOS Unicast Reverse Path Forwarding [19](#)

CiscoView [2](#)

CIST [15](#)

class command [43](#)

class-map command [38](#)

class map configuration [40](#)

clear cdp counters command [3](#)

clear cdp table command [3](#)

clear counters command [18](#)

- clearing IPX MLS cache entries [13](#)
 - clear interface command [19](#)
 - clear ip route command
 - IP MLS restriction [6](#)
 - clear ipx route command
 - IPX MLS restriction [5](#)
 - clear mls command
 - clearing IP MLS cache entries [12](#)
 - clear mls ip multicast statistics command
 - clearing IP MMLS statistics [19](#)
 - clear mls ipx command
 - clearing IPX MLS cache entries [13](#)
 - clear mls nde flow command [17](#)
 - CLI
 - accessing [1](#)
 - backing out one level [5](#)
 - console configuration mode [5](#)
 - getting list of commands [5](#)
 - global configuration mode [5](#)
 - history substitution [3](#)
 - interface configuration mode [5](#)
 - privileged EXEC mode [5](#)
 - ROM monitor [6](#)
 - software basics [4](#)
 - command line processing [3](#)
 - commands, getting list of [5](#)
 - Common and Internal Spanning Tree
 - See also CIST [15](#)
 - Common Spanning Tree
 - See CST
 - community ports [1](#)
 - community VLANs [2](#)
 - CONFIG_FILE environment variable
 - configuration file, viewing [26](#)
 - description [26](#)
 - config-register command [23](#)
 - config terminal command [10](#)
 - configuration
 - file, saving [11](#)
 - interfaces [8 to 10](#)
 - register
 - changing settings [23](#)
 - configuration [21 to 24](#)
 - settings at startup [22](#)
 - configuration register boot field
 - listing value [24](#)
 - modification tasks [23](#)
 - configure command [9](#)
 - configure terminal command [23, 2](#)
 - configuring [1, 5, 42](#)
 - global parameters
 - procedure [3](#)
 - sample configuration [3 to 8](#)
 - interfaces [8 to 9](#)
 - using configuration mode [10](#)
 - congestion avoidance
 - see QoS congestion avoidance
 - console configuration mode [5](#)
 - copy running-config startup-config command [11](#)
 - copy system
 - running-config nvram
 - startup-config command [26](#)
 - CoS
 - override priority [7, 8](#)
 - counters
 - clearing interface [18, 19](#)
 - CST [15](#)
 - common spanning tree [18](#)
-
- ## D
- dCEF [4, 5](#)
 - debug commands
 - IP MMLS [18](#)
 - debugging mls comand [14](#)
 - default configuration
 - 802.1X [5](#)
 - IP MLS [6](#)

- IP MMLS 7
- IPX MLS 5
- supervisor engine 1
- UDLD 3
- voice VLAN 4
- VTP 5
- default gateway, configuring 12
- default NDE configuration 7
- default VLAN 10
- denial of service protection 1
- description command 16
- destination flow mask 3
- destination-ip flow mask 3,2
- destination-source flow mask 3
- destination-source-ip flow mask 2
- differentiated services codepoint
 - See QoS DSCP
- dir command 27
- disabling
 - IP MLS
 - on router interfaces 7
 - IPX MLS
 - on switch interfaces 6
- displaying IPX MLS VLAN statistics 12
- distributed Cisco Express Forwarding
 - See dCEF
- documentation, related 23
- document organization 21
- drop thresholds
 - see QoS congestion avoidance
- DSCP
 - See QoS DSCP
- duplex command 8,9
- duplex mode
 - configuring interface 7
- redundancy 1
- Embedded CiscoView 2
- enable command 10,23
- enable mode 5
- enabling
 - IP MLS, on router interfaces 7
 - IP MMLS
 - on router interfaces 11
 - IPX MLS, on router interfaces 6
- enabling IP MLS 6
- encapsulation 4
- enhanced high system availability
 - See EHSA
- environmental monitoring
 - LED indications 4
 - SNMP traps 4
 - supervisor engine and switching modules 4
 - Syslog messages 4
 - using CLI commands 4
- environment variables
 - BOOTLDR 25
 - (example) 27
 - setting 27
 - CONFIG_FILE 26
 - controlling 26
 - viewing 26
- erase startup-config command
 - configuration files cleared with 14
- EtherChannel
 - channel-group group
 - command 8
 - command example 8
 - configuration guidelines 5
 - configuring
 - Layer 2 8
 - configuring (tasks) 6
 - DFC restriction, see CSCdt27074 in the Release Notes
 - interface port-channel
 - command example 7

E

EHSA

- interface port-channel (command) [7](#)
 - lacp system-priority
 - command example [10](#)
 - Layer 2
 - configuring [8](#)
 - load balancing
 - configuring [11](#)
 - understanding [5](#)
 - modes [3](#)
 - PAgP
 - Understanding [3](#)
 - port-channel interfaces [5](#)
 - port-channel load-balance
 - command [10,11](#)
 - command example [11](#)
 - STP [5](#)
 - understanding [1](#)
 - EtherChannel Guard
 - See STP EtherChannel Guard
 - Ethernet
 - setting port duplex [15](#)
 - examples
 - configuration
 - interface [8 to 9](#)
 - software configuration register [21 to 24](#)
 - configuring global parameters [3](#)
 - extended range VLANs [2](#)
 - See VLANs
 - Extensible Authentication Protocol over LAN [1](#)
-
- F**
- fabric switching mode
 - See switch fabric module
 - fastethernet [2](#)
 - fiber-optic, detecting unidirectional links [1](#)
 - filters
 - protocol
 - See protocol filtering
 - filters, NDE
 - clearing [17](#)
 - destination host filter, specifying [16](#)
 - destination TCP/UDP port, specifying [15](#)
 - overview [6](#)
 - protocol [16](#)
 - source host and destination TCP/UDP port [16](#)
 - firewall [5](#)
 - Flash memory
 - configuration process [25](#)
 - configuring router to boot from [25](#)
 - loading system image from [24](#)
 - security precautions [25](#)
 - write protection [25](#)
 - flow control [14](#)
 - flow masks
 - IP MLS
 - destination-ip [3,2](#)
 - destination-source-ip [2](#)
 - interface-destination-source-ip [2](#)
 - ip-flow [3](#)
 - ip-full [3](#)
 - ip-interface-full [3](#)
 - source-destination-ip [3](#)
 - IP MMLS and [3](#)
 - IPX MLS
 - destination [3](#)
 - destination-source [3](#)
 - IPX MLS entries and [3](#)
 - minimum [8,9](#)
 - modes [3](#)
 - overview [3,2](#)
 - flows
 - IP MLS [2](#)
 - IP MMLS
 - completely and partially switched [4](#)
 - IPX MLS [2](#)
 - forward-delay time, STP [32](#)
 - forwarding information base [5](#)

frame distribution

See EtherChannel load balancing

G

gateway, configuring 12

global configuration mode 5

global parameters, configuring 3

H

hardware Layer 3 switching

guidelines 4

hello time, STP 32

history

CLI 3

I

I-BPDU 16

ICMP unreachable messages 1

IEEE 802.10 SAID (default) 6

IEEE 802.1Q

See 802.1Q

IEEE 802.1Q Ethertype

specifying custom 16

IEEE 802.1s

See MST

IEEE 802.1w

See MST

IEEE 802.3ad

See LACP

IEEE 802.3Z Flow Control 14

IGMP

configuration guidelines 6

enabling 9

Internet Group Management Protocol 1

join messages 2

leave processing

enabling 11

queries 3

query interval

configuring 11

snooping

fast leave 5

joining multicast group 2

leaving multicast group 4

understanding 2

snooping querier

enabling 7

guidelines and restrictions 7

understanding 2

IGMPv3 10

IGMP v3lite 10

IGRP, configuring 7

interface

command 10

configuration 8 to 9

configuration mode 5

Layer 2 modes 4

number 2

parameters, configuring 8

interface-destination-source-ip flow mask 2

interface port-channel

command example 7

interface port-channel (command) 7

interfaces

configuring 2

configuring, duplex mode 7

configuring, speed 7

configuring, overview 1

counters, clearing 18, 19

descriptive name, adding 16

displaying information about 17

maintaining 17

monitoring 17

naming 16

- range of [4](#)
- restarting [19](#)
- shutting down
 - task [19](#)
- interfaces command [1,2](#)
- interfaces range command [4](#)
- interfaces range macro command [6](#)
- Interior Gateway Routing Protocol
 - See IGRP, configuring
- Internal Sub Tree Protocol
 - See ISTP [15](#)
- Internet Group Management Protocol
 - See IGMP
- IP
 - default gateway, configuring [12](#)
 - static routes [12](#)
- IP accounting, IP MMLS and [9](#)
- IP addresses
 - assigned by BOOTP protocol [14](#)
 - set to default [14](#)
- IP CEF
 - topology (figure) [3](#)
- ip flow-export destination command [14](#)
- ip flow-export source command [13](#)
- ip-flow flow mask [3](#)
- ip-full flow mask [3](#)
- ip http server [1](#)
- ip-interface-full flow mask [3](#)
- IP MLS
 - aging-time [8,10](#)
 - cache
 - clearing entries [11](#)
 - overview [3](#)
 - cache, displaying
 - by destination address [10](#)
 - by source address [10](#)
 - by specific flow [11](#)
 - cache entries, displaying [9](#)
 - debugging, on switch [14](#)
 - default configuration [6](#)
 - disabling
 - on router interface [7](#)
 - displaying interface configuration [7](#)
 - displaying IP MLS VLAN statistics [13](#)
 - enabling [6](#)
 - enabling on router interface [7](#)
 - flow masks
 - destination-ip [3,2](#)
 - destination-source-ip [2](#)
 - interface-destination-source-ip [2](#)
 - ip flow [3](#)
 - ip-full [3](#)
 - ip-interface-full [3](#)
 - minimum [8,9](#)
 - overview [3,2](#)
 - source-destination-ip [3](#)
- flows [2](#)
- NDE
 - See NDE
- operational overview [5](#)
- overview [2](#)
- packet rewrite [4](#)
- router
 - disabling on interfaces [7](#)
 - enabling on interfaces [7](#)
- statistics
 - displaying for MLS cache entries [12](#)
 - displaying IP MLS statistics and contention tables [12](#)
- troubleshooting [14](#)
- IP MMLS
 - cache, overview [2](#)
 - configuration guideline [8](#)
 - debug commands [18](#)
 - default configuration [7](#)
 - enabling
 - on router interfaces [11](#)
 - flow mask [3](#)
 - flows

- completely and partially switched 4
- Layer 3 MLS cache 2
- overview 2
- packet rewrite 3
- router
 - displaying interface information 14
 - enabling globally 10
 - enabling on interfaces 11
 - multicast routing table, displaying 16
 - PIM, enabling 10
- switch
 - statistics, clearing 19
- unsupported features 9
- IP multicast
 - IGMP snooping and 8
 - overview 1
- IP multicast MLS
 - See IP MMLS
- ip multicast-routing command
 - enabling IP multicast 10
- IP phone
 - configuring 5
- ip pim command
 - enabling IP PIM 10
- ip routing command
 - IP MLS restriction 6
- IPsec 6
- ip security command
 - IP MLS restriction 6
- ip wccp version command 7
- IPX MLS
 - access lists, flow masks and 3
 - aging-time 7
 - cache
 - overview 2
 - cache, displaying
 - all entries 9
 - by destination address 10
 - by source address 10
 - cache entries, displaying 9
 - clearing cache entries 13
 - configuration guidelines
 - interaction with other features 5
 - MTU 6
 - default configuration 5
 - disabling
 - on router interface 6
 - disabling on interfaces 6
 - displaying VLAN statistics 12
 - enabling 6
 - enabling on interface 6
 - enabling on interfaces 6
 - flow masks
 - access lists and 3
 - destination 3
 - destination-source 3
 - IPX MLS entries and 3
 - minimum 8
 - modes 3
 - overview 3
 - flows 2
 - operational overview 4
 - overview 2
 - packet rewrite 3
 - statistics
 - displaying for MLS cache entries 11
- ipx routing command
 - IPX MLS restriction 6
- ipx security command
 - IPX MLS restriction 6
- ISL encapsulation 4
- ISL trunks 2
- isolated port 1
- isolated VLANs 2
- ISTP 15

J

join messages, IGMP [2](#)
 jumbo frames [10](#)

K

keyboard shortcuts [3](#)

L

LACP

system ID [4](#)

Layer 2

configuring interfaces [7](#)

access port [14](#)

trunk [8](#)

defaults [5](#)

interface modes [4](#)

show interfaces [13, 14, 7, 13](#)

switching

understanding [1](#)

trunks

understanding [2](#)

VLAN

interface assignment [12](#)

Layer 2 Interfaces

configuring [1](#)

Layer 2 protocol tunneling

configuring Layer 2 tunnels [8](#)

overview [7](#)

Layer 3

IP MMLS and MLS cache [2](#)

shortcuts

See IP MLS, IP MMLS, or IPX MLS

Layer 3 switched packet rewrite

CEF [2](#)

Layer 3 switching

CEF [2](#)

Layer 4 port operations (ACLs) [3](#)

leave processing, IGMP

enabling [11](#)

link negotiation [8](#)

load balancing [15](#)

logical operation unit

See LOU

loop guard

See STP loop guard

LOU

description [4](#)

determining maximum number of [4](#)

M

MAC address

adding to BOOTP configuration file [14](#)

MAC address-based blocking [8](#)

mac move notification

configuring [22](#)

main-cpu command [3, 6, 7](#)

mapping 802.1Q VLANs to ISL VLANs [12](#)

markdown

see QoS markdown

marking

see QoS

match protocol [31](#)

maximum aging time, STP [33](#)

microflow policing rule

see QoS policing

MLS

configuring [6](#)

configuring threshold [11](#)

MSFC

threshold [11](#)

mls aging command

configuring IP MLS [11](#)

mls flow command

configuring IP MLS [8, 9, 10](#)

- mls flow ipx command
 - configuring IPX MLS flow mask [8](#)
 - mls ip multicast command
 - enabling IP MMLS [11, 12, 13, 14](#)
 - mls ipx command
 - enabling IPX MLS on a router interface [6](#)
 - mls nde flow command
 - configuring a host and port filter [16](#)
 - configuring a host flow filter [16](#)
 - configuring a port filter [15](#)
 - configuring a protocol flow filter [16](#)
 - mls nde src_address command [8](#)
 - monitoring
 - traffic suppression [5](#)
 - MST [15](#)
 - boundary ports [19](#)
 - configuration [18](#)
 - configuring [34](#)
 - edge ports [20](#)
 - enabling [34](#)
 - hop count [20](#)
 - instances [18](#)
 - interoperability [16](#)
 - interoperability with PVST+ [16](#)
 - link type [20](#)
 - master [19](#)
 - message age [20](#)
 - regions [18, 19](#)
 - MSTP
 - M-record [16](#)
 - M-tree [16](#)
 - MTU
 - IPX MLS and [6](#)
 - MTU size (default) [6](#)
 - multicast
 - broadcast suppression [3](#)
 - IGMP snooping and [8](#)
 - NetFlow statistics [1](#)
 - non-RPF [5](#)
 - overview [1](#)
 - RGMP [1](#)
 - router, specifying port for [12](#)
 - multicast, displaying routing table [16](#)
 - multicast groups
 - joining [2](#)
 - leaving [4](#)
 - multicast multilayer switching
 - See IP MMLS
 - multicast RPF [2](#)
 - multicast storms
 - see traffic-storm control
 - multilayer switch feature card
 - see MSFC
 - Multilayer Switching
 - See IP MLS, IP MMLS, or IPX MLS
 - multiple forwarding paths [15](#)
 - Multiple Spanning Tree
 - See MST
 - Multiple Spanning Tree Protocol
 - See MSTP [15](#)
-
- ## N
- native vlan [11](#)
 - NBAR [1, 31](#)
 - NDE
 - configuration, displaying [17](#)
 - displaying configuration [17](#)
 - enabling [8](#)
 - filters
 - clearing [17](#)
 - destination host, specifying [16](#)
 - destination TCP/UDP port, specifying [15](#)
 - overview [6](#)
 - protocol, specifying [16](#)
 - source host and destination TCP/UDP port, specifying [16](#)
 - multicast [1](#)

- overview [1](#)
- specifying
 - destination host filters [16](#)
 - destination TCP/UDP port filters [16](#)
 - protocol filters [16](#)
- NDE configuration, default [7](#)
- NetFlow Data Export
 - See NDE
- Network-Based Application Recognition [1](#)
- network fault tolerance [15](#)
- network management
 - configuring [1](#)
- non-RPF multicast [5](#)
- nonvolatile random-access memory
 - See NVRAM
- normal-range VLANs
 - See VLANs
- NVRAM
 - saving settings [11](#)

O

- OIR [17](#)
- online insertion and removal
 - See OIR
- operating system image
 - See system image
- out of profile
 - see QoS out of profile

P

- packet rewrite
 - CEF [2](#)
 - IP MLS and [4](#)
 - IP MMLS and [3](#)
 - IPX MLS and [3](#)
- packets

- multicast [11](#)
- PAgP
 - understanding [3](#)
- passwords
 - configuring
 - enable password [15](#)
 - enable secret [15](#)
 - line password [16](#)
 - static enable password [15](#)
 - TACACS+ [16](#)
 - TACACS+ (caution) [17](#)
 - encrypting [17](#)
 - (caution) [17](#)
 - recovering lost enable passwords [19](#)
- PBR [2](#)
- PFC2
 - NetFlow
 - table, displaying entries [6](#)
- PIM, IP MMLS and [10](#)
- police command [46](#)
- policing
 - See QoS policing
- policy [38](#)
- policy-based routing
 - See PBR
- Policy Feature Card
 - See PFC
- policy map [42](#)
 - attaching to an interface [49](#)
- policy-map command [38, 42](#)
- Port Aggregation Protocol
 - see PAgP
- port-based authentication
 - authentication server
 - defined [2](#)
 - RADIUS server [2](#)
 - client, defined [2](#)
 - configuration guidelines [6](#)
 - configuring

- initializing authentication of a client **11**
- manual reauthentication of a client **11**
- quiet period **11**
- RADIUS server **10**
- RADIUS server parameters on the switch **8**
- switch-to-authentication-server retransmission time **13**
- switch-to-client EAP-request frame retransmission time **13**
- switch-to-client frame-retransmission number **14**
- switch-to-client retransmission time **12**
- default configuration **5**
- described **1**
- device roles **2**
- displaying statistics **15**
- EAPOL-start frame **3**
- EAP-request/identity frame **3**
- EAP-response/identity frame **3**
- enabling
 - 802.1X authentication **7,8**
 - periodic reauthentication **10**
- encapsulation **2**
- initiation and message exchange **3**
- method lists **7**
- ports
 - authorization state and dot1x port-control command **4**
 - authorized and unauthorized **4**
- resetting to default values **15**
- switch
 - as proxy **2**
 - RADIUS client **2**
 - topologies, supported **4**
- port-based QoS features
 - see QoS
- port-channel
 - see EtherChannel
- port-channel load-balance
 - command **10,11**
 - command example **10,11**
- port cost, STP **29**
- port debounce timer
 - disabling **15**
 - displaying **15**
 - enabling **15**
- PortFast
 - See STP PortFast
- PortFast BPDU filtering
 - See STP PortFast BPDU filtering
- port negotiation **8**
- port priority, STP **27**
- ports
 - secure **1**
 - setting the debounce timer **15**
- port security
 - aging **4**
 - configuring **3**
 - default configuration **2**
 - described **1**
 - displaying **6**
 - violations **2**
 - with other features **2**
- power management
 - enabling/disabling redundancy **2**
 - overview **1**
 - powering modules up or down **3**
 - system power requirements, nine-slot chassis **4**
- primary VLANs **2**
- priority
 - overriding CoS **7,8**
- private VLANs **1**
 - community VLANs **2**
 - configuration guidelines **2**
 - configuring **5**
 - host ports **8**
 - promiscuous ports **9**
 - routing secondary VLAN ingress traffic **7**
 - secondary VLANs with primary VLANs **6**
 - VLANs as private **5**

- isolated VLANs [2](#)
 - ports
 - community [1](#)
 - isolated [1](#)
 - promiscuous [1](#)
 - primary VLANs [2](#)
 - secondary VLANs [2](#)
 - trunks [2](#)
 - privileged EXEC mode [5](#)
 - privileges
 - changing default [18](#)
 - configuring
 - multiple levels [17](#)
 - privilege level [18](#)
 - exiting [19](#)
 - logging in [18](#)
 - procedures
 - global parameters, configuring [3 to 8](#)
 - interfaces, configuring [8 to 9](#)
 - using configuration mode [10](#)
 - promiscuous ports [1](#)
 - protocol filtering
 - configuring [3](#)
 - overview [1](#)
 - protocol tunneling
 - See Layer 2 protocol tunneling [7](#)
 - pruning, VTP
 - See VTP, pruning
 - PVLANS
 - See private VLANs
 - PVRST
 - See Rapid-PVST [14](#)
-
- Q**
- QoS ACL [18](#)
 - attaching [21](#)
 - QoS classification (definition) [4](#)
 - QoS congestion avoidance
 - definition [4](#)
 - receive queue [14](#)
 - QoS CoS
 - and ToS final L3 Switching Engine values [21](#)
 - and ToS final values from L3 Switching Engine [21](#)
 - definition [3](#)
 - port value, configuring [54](#)
 - QoS default configuration [25](#)
 - QoS definitions [3](#)
 - QoS drop thresholds
 - see QoS congestion avoidance
 - QoS DSCP
 - definition [4](#)
 - internal values [17](#)
 - maps, configuring [66](#)
 - QoS dual transmit queue
 - thresholds
 - configuring [58](#)
 - QoS Ethernet egress port
 - feature summary [12](#)
 - scheduling [22](#)
 - scheduling, congestion avoidance, and marking [10, 21](#)
 - QoS Ethernet ingress port
 - classification, marking, scheduling, and congestion avoidance [7](#)
 - feature summary [11](#)
 - marking, scheduling, congestion avoidance, and classification [12](#)
 - scheduling [14](#)
 - scheduling and congestion avoidance [13](#)
 - QoS feature set summary [11](#)
 - QoS final L3 Switching Engine CoS and ToS values [21](#)
 - QoS internal DSCP values [17](#)
 - QoS L3 Switching Engine
 - classification, marking, and policing [8, 16](#)
 - feature summary [11](#)
 - QoS labels (definition) [3](#)
 - QoS mapping
 - CoS values to DSCP values [66](#)

- DSCP markdown values [25, 68](#)
 - DSCP values to CoS values [67](#)
 - IP precedence values to DSCP values [67](#)
 - QoS markdown [19](#)
 - QoS marking [24](#)
 - definition [4](#)
 - trusted ports [13](#)
 - untrusted ports [13](#)
 - QoS MSFC
 - marking [9](#)
 - QoS multilayer switch feature card [12](#)
 - QoS OSM egress port
 - feature summary [12](#)
 - QoS OSM ingress port
 - feature summary [11](#)
 - QoS out of profile [19](#)
 - QoS policing
 - definition [4](#)
 - microflow, enabling for nonrouted traffic [50](#)
 - QoS policing rule [19](#)
 - aggregate [19](#)
 - creating [37](#)
 - microflow [19](#)
 - QoS port
 - trust state [53](#)
 - QoS port-based or VLAN-based [51, 52](#)
 - QoS port keywords [12](#)
 - QoS queues
 - transmit, allocating bandwidth between [64](#)
 - QoS receive queue [13, 61](#)
 - drop thresholds [16](#)
 - QoS scheduling (definition) [4](#)
 - QoS single-receive, dual-transmit queue ports
 - configuring [59](#)
 - QoS statistics data export [24](#)
 - configuring [70](#)
 - configuring destination host [75](#)
 - configuring time interval [74, 77](#)
 - QoS strict priority receive queue [14](#)
 - QoS ToS
 - and CoS final values from L3 Switching Engine [21](#)
 - definition [4](#)
 - QoS traffic flow through QoS features [6](#)
 - QoS transmit queue
 - size ratio [64, 65](#)
 - thresholds
 - configuring [54](#)
 - QoS transmit queues [21, 60, 61](#)
 - QoS trust-cos
 - port keyword [11, 12](#)
 - QoS trust-dscp
 - port keyword [11, 12](#)
 - QoS trust-ipprec
 - port keyword [11, 12](#)
 - QoS untrusted port keyword [11, 12](#)
 - QoS VLAN-based or port-based [21, 51, 52](#)
 - queries, IGMP [3](#)
-
- ## R
- range
 - command [4](#)
 - macro [6](#)
 - of interfaces [4](#)
 - Rapid-PVST
 - enabling [33](#)
 - overview [14](#)
 - Rapid Spanning Tree
 - See RSTP [13](#)
 - rapid spanning tree protocol [15](#)
 - rate-limiting [5](#)
 - receive queues
 - see QoS receive queues
 - reduced MAC address [3](#)
 - redundancy
 - configuring supervisor engine [2](#)
 - displaying supervisor engine configuration [4](#)
 - EHSA [1](#)

redundancy (RPR+) [1](#)
 configuring [6](#)
 configuring supervisor engine [5](#)
 displaying supervisor engine configuration [8](#)
 redundancy command [6,7](#)
 route processor redundancy plus [2](#)
 redundancy command [3](#)
 related documentation [23](#)
 reload command [23](#)
 reserved-range VLANs
 See VLANs
 rewrite, packet
 CEF [2](#)
 IP MLS [4](#)
 IP MMLS [3](#)
 IPX MLS [3](#)
 RGMP [1](#)
 overview [1](#)
 packet types [2](#)
 RIF cache monitoring [18](#)
 rommon command [24](#)
 ROM monitor
 boot process and [20](#)
 CLI [6](#)
 root bridge, STP [25](#)
 root guard
 See STP root guard
 route processor redundancy
 See redundancy (RPR+)
 router, multicast [12](#)
 router-port group management protocol
 See RGMP
 routing table, multicast [16](#)
 RPF
 failure [5](#)
 multicast [2](#)
 non-RPF multicast [5](#)
 unicast [19](#)
 RPR+

See redundancy (RPR+)

RSTP [15](#)
 port roles [13](#)
 port states [14](#)

S

SAID [6](#)
 sample configuration [2 to 10](#)
 Sampled NetFlow
 description [6](#)
 saving the configuration file [11](#)
 scheduling
 see QoS
 secondary VLANs [2](#)
 secure ports, configuring [1](#)
 security
 configuring [1](#)
 security, port [1](#)
 security precautions with Flash memory card [25](#)
 serial interfaces
 clearing [19](#)
 synchronous
 maintaining [19](#)
 service-policy command [38](#)
 service-policy input command [49](#)
 set power redundancy enable/disable command [2](#)
 setup command [2](#)
 shortcuts, Layer 3
 See IP MLS, IP MMLS, or IPX MLS
 show boot command [26](#)
 show bootvar command [27](#)
 show catalyst6000 chassis-mac-address command [3](#)
 show cdp command [2,3](#)
 show cdp entry command [3](#)
 show cdp interface command [3](#)
 show cdp neighbors command [3](#)
 show cdp traffic command [3](#)
 show ciscoview package command [3](#)

- show ciscoview version command [3](#)
- show configuration command [16](#)
- show debugging command [3](#)
- show eobc command [18](#)
- show hardware command [3](#)
- show history command [4](#)
- show ibc command [18](#)
- show interfaces command [2, 13, 14, 16, 18, 7, 13](#)
 - clearing interface counters [18](#)
 - displaying, interface type numbers [2](#)
 - displaying, speed and duplex mode [9](#)
- show ip flow export command
 - displaying NDE export flow IP address and UDP port [14](#)
- show ip interface command
 - displaying IP MLS interface configuration [7](#)
 - displaying IP MMLS interfaces [15](#)
- show ip mroute command
 - displaying IP multicast routing table [16](#)
- show ip pim interface command
 - displaying IP MMLS router configuration [15](#)
- show ipx interface command
 - display IPX MLS interface configuration [7](#)
- show mls aging command [11](#)
- show mls entry command [6](#)
- show mls ip command
 - displaying MSFC information [9](#)
- show mls ip destination
 - displaying IP MLS destination address [10](#)
- show mls ip flow command
 - displaying IP MLS cache entries [11](#)
- show mls ip multicast group command
 - displaying IP MMLS group [17](#)
- show mls ip multicast interface command
 - displaying IP MMLS interface [17](#)
- show mls ip multicast source command
 - displaying IP MMLS source [17](#)
- show mls ip multicast statistics command
 - displaying IP MMLS statistics [17](#)
- show mls ip multicast summary
 - displaying IP MMLS configuration [17](#)
- show mls ip source command
 - displaying IP MLS source address [10](#)
- show mls ipx command
 - displaying IPX MLS cache entries [9](#)
- show mls nde command [17](#)
 - displaying NDE flow IP address [14](#)
- show mls rp command
 - displaying IP MLS configuration [9](#)
 - display IPX MLS flow mask [8](#)
- show mls table-contention command
 - displaying IP MLS contention tables [13](#)
 - displaying IPX MLS contention table [12](#)
- show mls vlan-statistics command
 - displays IPX MLS VLAN statistics [12](#)
- show module command [4, 8](#)
- show protocols command [18](#)
- show rif command [18](#)
- show running-config command [10, 16, 18](#)
- show startup-config command [11](#)
- show version command [9, 23, 24, 18](#)
- shutdown command [19](#)
- shutdown interfaces
 - result [19](#)
- Single Spanning Tree
 - See SST [15](#)
- slot number, description [1](#)
- SNMP
 - support and documentation [1](#)
- snooping
 - See IGMP snooping
- software configuration register functions [21 to 24](#)
- source-destination-ip flow mask [3](#)
- source-destination-vlan flow mask [3](#)
- source specific multicast with IGMPv3, IGMP v3lite, and URD [10](#)
- SPAN
 - configuration guidelines [5](#)

- configuring [8](#)
 - destinations [10](#)
 - sources [9](#)
 - VLAN filtering [10](#)
- overview [1](#)
- spanning-tree backbonefast
 - command [13, 14](#)
 - command example [13, 14](#)
- spanning-tree cost
 - command [29](#)
 - command example [29, 30](#)
- spanning-tree portfast
 - command [8, 9](#)
 - command example [8](#)
- spanning-tree portfast bpdu-guard
 - command [11](#)
- spanning-tree port-priority
 - command [27, 28](#)
- spanning-tree uplinkfast
 - command [12](#)
 - command example [12](#)
- spanning-tree vlan
 - command [23, 24, 26, 27, 14](#)
 - command example [23, 25, 26, 27](#)
- spanning-tree vlan cost
 - command [29](#)
- spanning-tree vlan forward-time
 - command [32](#)
 - command example [33](#)
- spanning-tree vlan hello-time
 - command [32](#)
 - command example [32](#)
- spanning-tree vlan max-age
 - command [33](#)
 - command example [33](#)
- spanning-tree vlan port-priority
 - command [27](#)
 - command example [28](#)
- spanning-tree vlan priority
 - command [31](#)
 - command example [31](#)
- speed
 - configuring interface [7](#)
- speed command [8](#)
- SST [15](#)
 - interoperability [16](#)
- static route, configuring [12](#)
- statistics
 - 802.1X [15](#)
- storm control
 - see traffic-storm control
- STP
 - configuring [22](#)
 - bridge priority [30](#)
 - enabling [23, 24](#)
 - forward-delay time [32](#)
 - hello time [32](#)
 - maximum aging time [33](#)
 - port cost [29](#)
 - port priority [27](#)
 - root bridge [25](#)
 - secondary root switch [26](#)
 - defaults [21](#)
 - EtherChannel [5](#)
 - understanding [2](#)
 - 802.1Q Trunks [12](#)
 - Blocking State [8](#)
 - BPDUs [4](#)
 - disabled state [12](#)
 - forwarding state [11](#)
 - learning state [10](#)
 - listening state [9](#)
 - overview [2](#)
 - port states [6](#)
 - protocol timers [5](#)
 - root bridge election [4](#)
 - topology [5](#)
- STP BackboneFast

- and MST [16](#)
- configuring [13](#)
- figure
 - adding a switch [7](#)
- spanning-tree backbonefast
 - command [13, 14](#)
 - command example [13, 14](#)
- understanding [4](#)
- STP BPDU Guard
 - and MST [16](#)
 - configuring [11](#)
 - spanning-tree portfast bpdu-guard
 - command [11](#)
 - understanding [2](#)
- STP bridge ID [3](#)
- STP EtherChannel guard [6](#)
- STP loop guard
 - and MST [16](#)
 - configuring [15](#)
 - overview [6](#)
- STP PortFast
 - and MST [16](#)
 - BPDU filter
 - configuring [10](#)
 - BPDU filtering [2](#)
 - configuring [8](#)
 - spanning-tree portfast
 - command [8, 9](#)
 - command example [8](#)
 - understanding [2](#)
- STP Portfast BPDU filtering
 - and MST [16](#)
- STP root guard [6, 14](#)
 - and MST [16](#)
- STP UplinkFast
 - and MST [16](#)
 - configuring [12](#)
 - spanning-tree uplinkfast
 - command [12](#)
 - command example [12](#)
 - understanding [3](#)
 - strict-priority queue
 - see QoS strict priority
- supervisor engine
 - configuring [1](#)
 - default configuration [1](#)
 - default gateways [12](#)
 - environmental monitoring [4](#)
 - redundancy [1](#)
 - ROM monitor [20](#)
 - startup configuration [20](#)
 - static routes [12](#)
 - synchronizing configurations [3, 7](#)
- supervisor engine redundancy
 - configuring [2, 5](#)
- supervisor engines
 - displaying redundancy configuration [4, 8](#)
- Switched Port Analyzer
 - See SPAN
- switch fabric module [1](#)
 - configuring [3](#)
 - monitoring [5](#)
 - slot locations [2](#)
- switchport
 - configuring [14](#)
 - example [13](#)
 - show interfaces [13, 14, 7, 13](#)
- switchport access vlan [10, 14](#)
 - example [15](#)
- switchport mode access [4, 14](#)
 - example [15](#)
- switchport mode dynamic [9](#)
- switchport mode dynamic auto [4](#)
- switchport mode dynamic desirable [4](#)
 - default [5](#)
 - example [13](#)
- switchport mode trunk [4, 9](#)
- switchport nonegotiate [4](#)

- switchport trunk allowed vlan [11](#)
- switchport trunk encapsulation [9](#)
- switchport trunk encapsulation dot1q [4](#)
 - example [13](#)
- switchport trunk encapsulation isl [4](#)
- switchport trunk encapsulation negotiate [4](#)
 - default [5](#)
- switchport trunk native vlan [11](#)
- switchport trunk pruning vlan [12](#)
- system
 - configuration register
 - configuration [21 to 24](#)
 - settings at startup [22](#)
 - configuring global parameters [3 to 8](#)
- system image
 - determining if and how to load [22](#)
 - loading from Flash [24](#)

T

- TACACS+ [1](#)
- TCP Intercept [18](#)
- Telnet
 - accessing CLI [2](#)
- thresholds
 - see QoS congestion avoidance
- traffic-storm control
 - command
 - broadcast [2](#)
 - described [1](#)
 - monitoring [4](#)
 - thresholds [1](#)
- traffic suppression
 - see traffic-storm control
- translational bridge numbers (defaults) [6](#)
- transmit queues
 - see QoS transmit queues
- troubleshooting
 - IP MLS [14](#)

- trunks [2](#)
 - 802.1Q Restrictions [6](#)
 - allowed VLANs [11](#)
 - configuring [8](#)
 - default interface configuration [7](#)
 - default VLAN [10](#)
 - different VTP domains [3](#)
 - encapsulation [4](#)
 - native vlan [11](#)
 - private VLANs [2](#)
 - to non-DTP device [5](#)
 - VLAN 1 minimization [12](#)
- trust-dscp
 - see QoS trust-dscp
- trust-ipprec
 - see QoS trust-ipprec
- tunneling, 802.1Q
 - See 802.1Q [1](#)

U

- UDLD
 - default configuration [3](#)
 - enabling
 - globally [3](#)
 - on ports [4, 5](#)
 - overview [1](#)
- unauthorized ports with 802.1X [4](#)
- unicast flood protection [21](#)
 - configuring [21](#)
- unicast RPF [19](#)
- unicast storms
 - see traffic-storm control
- UniDirectional Link Detection Protocol
 - see UDLD
- untrusted
 - see QoS trust-cos
 - see QoS untrusted
- UplinkFast

See STP UplinkFast
 URD [10](#)
 user EXEC mode [5](#)

V

VACLs [8](#)

- configuring [11](#)
 - examples [16](#)
- Layer 3 VLAN interfaces [15](#)
- Layer 4 port operations [3](#)
- logging
 - configuration example [18](#)
 - configuring [17](#)
 - restrictions [18](#)
- MAC address based [12](#)
- multicast packets [11](#)
- overview [8](#)
- SVIs [15](#)
- WAN interfaces [8](#)

virtual LAN

- See VLANs

vlan

- command [10, 12, 9](#)
- command example [11](#)

VLAN access control lists, see VACLs

vlan database

- command [10, 12, 9](#)
- example [11](#)

vlan mapping dot1q

- command [13](#)
- command example [13](#)

VLANs

- allowed on trunk [11](#)
- configuration guidelines [8](#)
- configuration options
 - global configuration mode [9](#)
 - VLAN database mode [9](#)
- configuring [1](#)

- configuring (tasks) [9](#)
- defaults [6](#)
- extended range [2](#)
- ID (default) [6](#)
- interface assignment [12](#)
- name (default) [6](#)
- normal range [2](#)
- private
 - See private VLANs
- protocol filtering and [1](#)
- reserved range [2](#)
- support for 4,096 VLANs [2](#)
- token ring [3](#)
- trunks
 - understanding [2](#)
- understanding [1](#)
- VLAN 1 minimization [12](#)
- VTP domain [3](#)

VLAN Trunking Protocol

- See VTP

voice VLAN

- Cisco 7960 phone, port connections [1](#)
- configuration guidelines [4](#)
- configuring IP phone for data traffic
 - override CoS of incoming frame [7, 8](#)
- configuring ports for voice traffic in
 - 802.1Q frames [5](#)
- connecting to an IP phone [5](#)
- default configuration [4](#)
- overview [1](#)

VTP

- advertisements [2](#)
- client, configuring [8](#)
- configuration guidelines [5](#)
- default configuration [5](#)
- disabling [8](#)
- domains [2](#)
 - VLANs [3](#)
- modes

- client [2](#)
- server [2](#)
- transparent [2](#)
- monitoring [10](#)
- overview [1](#)
- pruning
 - configuration [12](#)
 - configuring [7](#)
 - overview [3](#)
- server, configuring [8](#)
- statistics [10](#)
- transparent mode, configuring [8](#)
- version 2
 - enabling [7](#)
 - overview [3](#)

W

WCCP

- configuring on a router [2, 15](#)
- service groups [8](#)
- specifying protocol version [7](#)

web browser interface [1](#)

Web Cache Communication Protocol

- See WCCP [1](#)

web caches

- See cache engines

web cache services

- description [5](#)

web caching

- See web cache services
- See also WCCP

web scaling [1](#)

