



Preface

This guide describes how to install, configure, and use the Cisco Configuration Professional Express (Cisco CP Express) on the IR800 Series Routers.

Audience

This guide is for network administrators who use the Cisco CP Express Admin View.

Purpose

The purpose of this guide is to help administrators get started with the Cisco CP Express. It consists of these chapters:

- [Introduction](#)
- [Installing and Setting Up Cisco CP Express Admin View](#)
- [Uninstalling and Upgrading Cisco CP Express Admin View](#)

Conventions

This document uses these conventions:

Convention	Indication
bold font	Commands, keywords, and user-entered text appear in bold font .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[]	Elements in square brackets are optional.
{x y z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string, or the string will include the quotation marks.
<code>courier font</code>	Terminal sessions and information the system displays appear in <code>courier font</code> .
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

NOTE: Means *reader take note*. Notes contain helpful suggestions or references to additional information and material.

CAUTION: This symbol means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

TIP: Means *the following information will help you solve a problem*. The tip information might not be troubleshooting or even an action, but could be useful information.

WARNING: IMPORTANT SAFETY INSTRUCTIONS

Means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.