



A

About screen [1-3](#)

action

activate [2-3](#)

deactivate [2-3](#)

delete [2-3](#)

manage [2-3](#)

start [2-3](#)

stop [2-3](#)

upgrade [2-3](#)

activate action [2-3](#)

ACTIVATED status [2-2](#)

activating, app [3-2](#)

adding

app [3-2](#)

internal network [3-16](#)

Syslog server [3-18](#)

app

activating [3-2](#)

adding [3-2](#)

configuration file [2-12, 3-7](#)

console access [3-8](#)

container

managing [2-12](#)

data directory

deleting file from [3-11](#)

downloading file from [3-10](#)

uploading file to [3-10](#)

deactivating [3-4](#)

deleting [3-7](#)

deploying [3-2](#)

host system resources for [2-9](#)

lifecycle workflows [3-1](#)

log file [2-13, 3-9](#)

resource profile [2-9, 3-2](#)

starting [3-5](#)

status [2-2, 3-1](#)

stopping [3-5](#)

upgrading [3-6](#)

App-ID page

App-Config page

accessing [2-13](#)

description [2-12](#)

fields and options [2-13](#)

App-DataDir page

accessing [2-12](#)

description [2-12](#)

fields and options [2-12](#)

App-info page

accessing [2-10](#)

description [2-10](#)

fields and options [2-10](#)

description [2-8](#)

Logs page

accessing [2-13](#)

description [2-13](#)

fields and options [2-13](#)

Resources page

accessing [2-9](#)

description [2-9](#)

fields and options [2-9](#)

tabs [2-8](#)

App-ID tab

App-Config [2-8](#)

App-DataDir [2-8](#)

- App-info [2-8](#)
- description [2-2](#)
- displaying [2-9](#)
- Logs [2-8](#)
- removing from menu bar [2-2, 2-9](#)
- Resources [2-8](#)

Applications page

- accessing [2-2](#)
- description [2-1, 2-2](#)
- fields and options [2-2](#)

Applications tab, description [2-1](#)

B

browser guidelines and requirements [1-1](#)

C

cartridge

- deleting [3-13](#)
- description [2-3, 3-12](#)
- for PAAS app [2-3, 3-12](#)
- installing [3-12](#)
- viewing information about [3-13](#)

Cartridges page

- accessing [2-3](#)
- description [2-3](#)
- fields and options [2-4](#)

Cartridges tab, description [2-1](#)

Cisco Data in Motion

- description [2-7](#)
- license, uploading [3-14](#)
- starting [3-14](#)
- status [2-8](#)
- stopping [3-15](#)

Cisco IOx

- framework [1-1](#)
- network

- See* network, internal

- overview [1-1](#)

Cisco IOx Local Manager

- About screen [1-3](#)
- Cartridges [2-3, 3-12](#)
- exiting [1-3](#)
- logging in to [1-2](#)
- logging out [1-3](#)
- overview [1-1](#)
- pages
 - App-ID* [2-8](#)
 - App-ID* > App-Config [2-12](#)
 - App-ID* > App-DataDir [2-12](#)
 - App-ID* > App-info [2-10](#)
 - App-ID* > Logs [2-13](#)
 - App-ID* > Resources [2-9](#)
 - Applications [2-2](#)
 - Middleware Service [2-7, 3-13](#)
 - Setting [2-6](#)
 - System Info [2-4](#)

- starting [1-2](#)

- tabs [2-1](#)

- timeout period [1-2](#)

configuration file

- description [2-12, 3-7](#)
- package_config.ini [2-13, 3-7](#)
- updating [3-8](#)

configuring

- host system for Cisco IOx [1-2](#)
- host system log file [3-21](#)

console access, of app [3-8](#)

container of app

- managing [2-12](#)

core dump file

- deleting [2-6, 3-24](#)
- description [3-23](#)
- downloading [2-6, 3-23](#)

CPU, on host system [2-9, 3-2](#)

D

- data directory
 - deleting file from [3-11](#)
 - downloading file from [3-10](#)
 - uploading file to [3-10](#)
- deactivate action [2-3](#)
- deactivating, app [3-4](#)
- delete action [2-3](#)
- deleting
 - app [3-7](#)
 - app data directory file [3-11](#)
 - cartridge [3-13](#)
 - core dump file [3-24](#)
 - internal network [3-18](#)
 - snapshot file [3-23](#)
 - Syslog server [3-20](#)
- DEPLOYED status [2-2](#)
- deploying app [3-2](#)
- downloading
 - app log file [3-9](#)
 - core dump file [3-23](#)
 - from data directory [3-10](#)
 - host system log file [3-21](#)
 - snapshot file [3-23](#)

E

- editing, internal network [3-17](#)
- editing, Syslog server [3-19](#)
- exiting, Cisco IOx Local Manager [1-3](#)

F

- flash storage, caveat [1-2](#)

G

- generating, snapshot file [3-22](#)

H

- host system
 - CPU [2-9](#)
 - log file [2-5](#)
 - configuring [3-21](#)
 - description [3-20](#)
 - downloading [3-21](#)
 - memory [2-9](#)
 - resources [2-9](#)

I

- installing, cartridge [3-12](#)

L

- license, uploading for Cisco Data in Motion [3-14](#)
- license, uploading for middleware [3-14](#)
- log file
 - app [2-13, 3-9](#)
 - downloading app log file [3-9](#)
 - host system [2-5](#)
 - configuring [3-21](#)
 - description [3-20](#)
 - downloading [3-21](#)
- logging in, to Cisco IOx Local Manager [1-2](#)
- logging out, from Cisco IOx Local Manager [1-3](#)

M

- manage action [2-3](#)
- memory, on host system [2-9, 3-2](#)
- middleware

license, uploading [3-14](#)
 starting [3-14](#)
 status [2-8](#)
 stopping [3-15](#)

Middleware Service page

accessing [2-7](#)
 description [2-7](#)
 fields and options [2-8](#)

Middleware Service tab, description [2-1](#)

N

network, internal

adding [3-16](#)
 deleting [3-18](#)
 description [2-6, 3-15](#)
 editing [3-17](#)
 svcbr_0 [2-6, 3-18](#)
 viewing information about [3-17](#)

O

ordering information on pages [2-2](#)

P

PAAS app, cartridge for [2-3, 3-12](#)
 package_config.ini configuration file [2-13, 3-7](#)

R

refresh, information on pages [1-2](#)
 resource profile [2-9, 3-2](#)
 resources, on host system [2-9, 3-2](#)
 RUNNING status [2-2](#)

S

snapshot file

deleting [2-5, 3-23](#)
 description [2-5, 3-22](#)
 downloading [2-5, 3-23](#)
 generating [3-22](#)

start action [2-3](#)

starting

app [3-5](#)
 Cisco Data in Motion [3-14](#)
 middleware [3-14](#)

starting Cisco IOx Local Manager [1-2](#)

status

ACTIVATED [2-2](#)
 DEPLOYED [2-2](#)
 of app [2-2, 3-1](#)
 RUNNING [2-2](#)
 STOPPED [2-2](#)

stop action [2-3](#)

STOPPED status [2-2](#)

stopping

app [3-5](#)
 Cisco Data in Motion [3-15](#)
 middleware [3-15](#)

Syslog server

adding [3-18](#)
 deleting [3-20](#)
 editing [3-19](#)

System Info page

accessing [2-4](#)
 description [2-4](#)
 fields and options [2-4](#)

System Info tab, description [2-1](#)

System Setting page

accessing [2-6](#)
 description [2-6](#)
 fields and options [2-6](#)

System Setting tab, description [2-1](#)

T

tab

accessing [2-1](#)

App-ID [2-2](#)

App-ID > App-Config [2-8](#)

App-ID > App-DataDir [2-8](#)

App-ID > App-Info [2-8](#)

App-ID > Logs [2-8](#)

App-ID > Resources [2-8](#)

Applications [2-1](#)

Cartridges [2-1](#)

in Cisco IOx Local Manager [2-1](#)

Middleware Service [2-1](#)

System Info [2-1](#)

System Setting [2-1](#)

timeout period [1-2](#)

U

updating, configuration file [3-8](#)

upgrade action [2-3](#)

upgrading, app [3-6](#)

uploading, file to app data directory [3-10](#)

V

viewing cartridge information [3-13](#)

