



## Configuring 400G Digital Coherent Optics

| Feature Name   | Release Information | Description   |
|--|---------------------|---|
| Support for 3x100G Muxponder Mode on A99-10X400GE-X-SE/A99-10X400GE-X-TR Line Cards                  | Release 7.9.1       | QDD-400G-ZRP-S optical module operating in A99-10X400GE-X-SE/A99-10X400GE-X-TR line cards now supports 3x100G muxponder mode.   |
| oFEC Traffic Configuration for QDD-400G-ZRP-S  | Release 7.9.1       | QDD-400G-ZRP-S optical module can now support the following oFEC traffic configurations: <ul style="list-style-type: none"> <li>• 400G-TXP-1x1 DAC-16 QAM</li> <li>• 3x100G-MXP-1x1 DAC-8 QAM</li> </ul> This increases the interoperability of the QDD-400G-ZRP-S optical module across network components supporting these formats. |
| Support for 8 and 16 Quadrature Amplitude Modulation (QAM) Formats on QDD-400G-ZRP-S Optical Modules | Release 7.8.1       | QDD-400G-ZRP-S optical module operating in 200G interfaces now supports the 8 QAM and 16 QAM modulation formats. This increases the interoperability of the optical module across network components supporting these formats.  |

Cisco offers a range of the new 400G Digital Coherent QSFP-DD optical modules. The two optical modules that are available are:

- [QDD-400G-ZR-S](#)
- [QDD-400G-ZRP-S](#)

For more information about the optic module portfolio, see the [Cisco 400G Digital Coherent Optics QSFP-DD Optical Modules Data Sheet](#).

This chapter describes the 400G Digital Coherent QSFP-DD optical modules and their supported configurations.

The following table shows the line cards, ports, and modes that support these two optical modules.

**Table 1: Supported Line Cards, Ports, and Modes**

| Components                     | Default Port Speed | Supported Front Panel Ports | 1x400G Transponder Mode | 4x100G Muxponder Mode | 3x100G Muxponder Mode | 2x100G Muxponder Mode | 1x100G Transponder Mode |
|--------------------------------|--------------------|-----------------------------|-------------------------|-----------------------|-----------------------|-----------------------|-------------------------|
| <a href="#">A9903-20HG-EXR</a> | 1x100G             | 0, 7, 8, 12, 19             | Yes                     | Yes                   | Yes                   | Yes                   | Yes                     |
| <a href="#">A9903-20HG-PEC</a> | 1x100G             | 0, 7                        | Yes                     | Yes                   | Yes                   | Yes                   | Yes                     |
| <a href="#">A9903-20HG-EXR</a> | 1x400G             | 3, 5, 6, 7, 9               | Yes                     | Yes                   | Yes                   | Yes                   | Yes                     |
| <a href="#">A9903-20HG-PEC</a> | 1x100G             | 0, 4, 8, 12, 16             | Yes                     | Yes                   | Yes                   | Yes                   | Yes                     |
| <a href="#">ASR-9902</a>       | 1x100G             | 11, 37                      | No                      | No                    | No                    | No                    | Yes                     |

The 400G Digital Coherent QSFP-DD optical modules enable wavelength-division multiplexing (WDM) functionality in the router. These optical modules are DWDM C-band (196.1 THz to 191.3 THz) tunable optical modules. They can be used in both transponder and muxponder modes.

Cisco IOS XR software creates optics and coherent DSP controllers to configure and monitor the performance of the 400G Digital Coherent QSFP-DD optical modules. Optics controllers are used to configure and monitor optical parameters, such as frequency, chromatic dispersion, transmitted output power, and so on. Coherent DSP controllers are used to monitor network performance parameters like pre- and post-forward error correction (FEC) bit-error rate (pre-FEC BER, post-FEC BER), error corrected bits (EC-BITS), and so on. Forward error correction (FEC) is configured using optical controllers and monitored using coherent DSP controllers.

The 400G Digital Coherent QSFP-DD optical modules support traffic1 configuration and firmware download. The Cisco IOS XR software collects performance monitoring data and alarms.

Due to more power consumption by the 400G Digital Coherent QSFP-DD optical modules, the Cisco IOS XR software operates the fans at a higher speed to cool these optical modules.

Configuring frequency, chromatic dispersion, optical transmit power, digital to analog conversion (DAC) sampling rate, and FEC parameters impacts traffic. Also, configuring modulation is supported. Modulation is dependent on the mode of operation. See [Table 3: QDD-400G-ZR-S Transponder and Muxponder Configuration Values, on page 4](#) and [#unique\\_470 unique\\_470\\_Connect\\_42\\_table\\_u5x\\_f13\\_ppb, on page 5](#).

The 400G Digital Coherent QSFP-DD optical module configuration is divided into the following categories:

- Traffic configuration – Comprises configuring DAC rate, breakout, and FEC parameters. Applicable for optics controllers:
  - [Configuring DAC Rate, on page 6](#)
  - [Configuring Breakout, on page 8](#)
  - [Configuring FEC, on page 10](#)
- Optical configuration – Comprises configuring frequency, chromatic dispersion, and optical transmit power. Applicable for optics controllers:

- [Configuring Frequency, on page 11](#)
- [Configuring Chromatic Dispersion, on page 13](#)
- [Configuring Optical Transmit Power, on page 15](#)
- Performance monitoring (PM) – Enables or disables performance monitoring in optical modules. You can also configure PM parameters that comprise signal power, chromatic dispersion, optical signal-to-noise ratio (OSNR), and differential group delay (DGD). Applicable for optics controllers and coherent DSP controllers:
  - [Configuring Performance Monitoring, on page 17](#)
  - [Configuring PM Parameters, on page 17](#)
- Loopback configuration – Configures loopback. Applicable for coherent DSP controller:
  - [Configuring Loopback, on page 21](#)
- Alarms threshold configuration – Configures thresholds for monitoring alarms that include optical signal-to-noise ratio (OSNR), differential group delay (DGD), chromatic dispersion (cd high and low), and so on. Applicable for optics controllers:
  - [Configuring Alarms Threshold, on page 21](#)

The following table contains the possible traffic configuration values for the 400G Digital Coherent QSFP-DD optical modules, in the transponder and muxponder mode:

### QDD-400G-ZR-S and QDD-400G-ZRP-S FPD Upgrade

**Table 2: Feature History Table**

| Feature Name  | Release Information | Feature Description   |
|---|---------------------|---|
| FPD Upgrades Enabled for <a href="#">QDD-400G-ZR-S</a> and <a href="#">QDD-400G-ZRP-S</a> Optical Modules | Release 7.3.2       | This feature allows you to perform Field Programmable Device (FPD) upgrades on the QDD-400G-ZR-S and QDD-400G-ZRP-S optical modules to ensure they have the latest fixes and features. For more information about the optic module portfolio, see the <a href="#">Cisco 400G Digital Coherent Optics QSFP-DD Optical Modules Data Sheet</a> . |

Although an FPD upgrade is not mandatory in this release, we recommend upgrading the FPD to the latest version in the subsequent releases to ensure that all the latest fixes and features are enabled on the optical modules. Auto and parallel FPD upgrades are not supported. Only a manual FPD upgrade (one optical module at a time) using the **upgrade hw-module location node-id fpd fpd-name** command is supported.

The *fpd-name* can be obtained from the FPD description column of the **show fpd package** or the **show hw-module fpd** command. The *fpd-name* in the FPD description column displays QDD\_instance\_port-number. For example, depending on the instance and the port number, the FPD names for the QDD-400G-ZR-S and QDD-400G-ZRP-S modules will be QDD\_0\_3, QDD\_0\_0, and so on.



**Note** Only in case of Cisco ASR 9903 routers, the *fpd-name* in the FPD description column displays *QDD\_bay\_port-number*. The *bay* value for Cisco 9903 routers is always 1. Therefore, depending on the port number, the FPD names for the QDD-400G-ZR-S and QDD-400G-ZRP-S modules will be QDD\_1\_3, QDD\_1\_4, and so on.

See the “**Upgrading Field-Programmable Devices**” chapter in the *System Management Configuration Guide for Cisco ASR 9000 Series Routers* for details on the procedure to upgrade the FPD.

### QDD-400G-ZR-S Transponder and Muxponder Configuration Values

The following table contains the possible Transponder and Muxponder configuration values for the QDD-400G-ZR-S optical module:

**Table 3: QDD-400G-ZR-S Transponder and Muxponder Configuration Values**

| TXP/MXP     | Client                | Trunk         | Modulation | FEC  | DAC Rate |
|-------------|-----------------------|---------------|------------|------|----------|
| 400G-TXP    | 1 client, 400G speed  | 1 trunk, 400G | 16 QAM     | cFEC | 1x1      |
| 4x100G- MXP | 4 clients, 100G speed | 1 trunk, 400G | 16 QAM     | cFEC | 1x1      |

### QDD-400G-ZRP-S Transponder and Muxponder Configuration Values

The following table contains the possible Transponder and Muxponder configuration values for the QDD-400G-ZRP-S optical module:

**Table 4: QDD-400G-ZRP-S Transponder and Muxponder Configuration Values**

| TXP/MXP     | Client                | Trunk               | Modulation | FEC  | DAC Rate |
|-------------|-----------------------|---------------------|------------|------|----------|
| 400G-TXP    | 1 Client, 400G speed  | 1 trunk, 400G speed | 16 QAM     | oFEC | 1x1.25   |
| 400G-TXP    | 1 Client, 400G speed  | 1 trunk, 400G speed | 16 QAM     | cFEC | 1x1      |
| 400G-TXP    | 1 Client, 400G speed  | 1 trunk, 400G speed | 16 QAM     | oFEC | 1x1      |
| 4x100G- MXP | 4 clients, 100G speed | 1 trunk, 400G speed | 16 QAM     | oFEC | 1x1.25   |
| 4x100G- MXP | 4 clients, 100G speed | 1 trunk, 400G speed | 16 QAM     | cFEC | 1x1      |
| 3x100G-MXP  | 3 clients, 100G speed | 1 trunk, 300G speed | 8 QAM      | oFEC | 1x1.25   |

| <b>TXP/MXP</b> | <b>Client</b>         | <b>Trunk</b>        | <b>Modulation</b> | <b>FEC</b> | <b>DAC Rate</b> |
|----------------|-----------------------|---------------------|-------------------|------------|-----------------|
| 3x100G-MXP     | 3 clients, 100G speed | 1 trunk, 300G speed | 8 QAM             | oFEC       | 1x1             |
| 2x100G-MXP     | 2 clients, 100G speed | 1 trunk, 200G speed | QPSK              | oFEC       | 1x1.50          |
| 2x100G-MXP     | 2 clients, 100G speed | 1 trunk, 200G speed | 8 QAM             | oFEC       | 1x1.25          |
| 2x100G-MXP     | 2 clients, 100G speed | 1 trunk, 200G speed | 16 QAM            | oFEC       | 1x1.25          |
| 1x100G-MXP     | 1 client, 100G speed  | 1 trunk, 100G speed | QPSK              | oFEC       | 1x1.50          |

**DP04QSDD-HE0 Transponder and Muxponder Configuration Values**

The following table contains the possible Transponder and Muxponder configuration values for the DP04QSDD-HE0 optical module:

| <b>TXP/MXP</b> | <b>Client</b>         | <b>Trunk</b>        | <b>Modulation</b> | <b>FEC</b> | <b>DAC Rate</b> |
|----------------|-----------------------|---------------------|-------------------|------------|-----------------|
| 400G-TXP       | 1 Client, 400G speed  | 1 trunk, 400G speed | 16 QAM            | oFEC       | 1x1.25          |
| 400G-TXP       | 1 Client, 400G speed  | 1 trunk, 400G speed | 16 QAM            | cFEC       | 1x1.5           |
| 400G-TXP       | 1 Client, 400G speed  | 1 trunk, 400G speed | 16 QAM            | oFEC       | 1x1.5           |
| 4x100G- MXP    | 4 clients, 100G speed | 1 trunk, 400G speed | 16 QAM            | oFEC       | 1x1.25          |
| 4x100G- MXP    | 4 clients, 100G speed | 1 trunk, 400G speed | 16 QAM            | cFEC       | 1x1.5           |
| 4x100G-MXP     | 4 clients, 100G speed | 1 trunk, 400G speed | 16 QAM            | oFEC       | 1x1.5           |
| 3x100G-MXP     | 3 clients, 100G speed | 1 trunk, 300G speed | 8 QAM             | oFEC       | 1x1.25          |
| 3x100G-MXP     | 3 clients, 100G speed | 1 trunk, 300G speed | 8 QAM             | oFEC       | 1x1.5           |
| 2x100G-MXP     | 2 clients, 100G speed | 1 trunk, 200G speed | QPSK              | oFEC       | 1x1.5           |
| 2x100G-MXP     | 2 clients, 100G speed | 1 trunk, 200G speed | 8 QAM             | oFEC       | 1x1.25          |

| TXP/MXP    | Client                | Trunk               | Modulation | FEC  | DAC Rate |
|------------|-----------------------|---------------------|------------|------|----------|
| 2x100G-MXP | 2 clients, 100G speed | 1 trunk, 200G speed | 16 QAM     | oFEC | 1x1.25   |
| 1x100G-MXP | 1 client, 100G speed  | 1 trunk, 100G speed | QPSK       | oFEC | 1x1.5    |

- [Configuring DAC Rate, on page 6](#)
- [Configuring Breakout, on page 8](#)
- [Configuring FEC, on page 10](#)
- [Configuring Frequency, on page 11](#)
- [Configuring Chromatic Dispersion, on page 13](#)
- [Configuring Optical Transmit Power, on page 15](#)
- [Configuring Performance Monitoring, on page 17](#)
- [Configuring PM Parameters, on page 17](#)
- [Configuring Loopback, on page 21](#)
- [Configuring Alarms Threshold, on page 21](#)

## Configuring DAC Rate

You can set the DAC (digital to analog conversion) sampling rate on optics controllers. You can modify the DAC sampling rate only on the QDD-400G-ZRP-S optical module.



**Note** QDD-400G-ZR-S supports 1x1 dac-rate in cFEC mode. QDD-400G-ZRP-S supports 1x1 dac-rate in cFEC mode and 1x1.25 dac-rate in oFEC mode.

### DAC Rate Configuration Example

The following example shows how to set the DAC rate on the optics controller:

```
Router#config
Router(config)#controller optics 0/19/0/3
Router(config-Optics)#dac-rate 1x1.25
```

### Verification

This example shows the running configuration:

```
Router#show run controller optics 0/19/0/3
Thu May 13 12:52:35.020 UTC
controller Optics0/19/0/3
  DAC-Rate 1x1.25
!
```

### Verification

This example shows how to verify the configured DAC rate for the optics controller:

```
Router#show controller optics 0/19/0/3
Controller State: Up
Transport Admin State: In Service
Laser State: On
```

LED State: Green  
 FEC State: FEC OFEC  
 Optics Status  
     Optics Type: 400G QSFP-DD ZRP  
     DWDM carrier Info: C BAND, MSA ITU Channel=61, Frequency=193.10THz,  
     Wavelength=1552.524nm

Alarm Status:  
 -----  
 Detected Alarms: None  
 LOS/LOL/Fault Status:  
 Laser Bias Current = 70.9 mA  
 Actual TX Power = -7.06 dBm  
 RX Power = -7.88 dBm  
 RX Signal Power = -7.88 dBm  
 Frequency Offset = -220 MHz  
 Laser Temperature = 53.79 Celsius  
 Laser Age = 0 %  
**DAC Rate = 1x1.25**

Performance Monitoring: Enable  
 THRESHOLD VALUES  
 -----

| Parameter                | High Alarm | Low Alarm | High Warning | Low Warning |
|--------------------------|------------|-----------|--------------|-------------|
| Rx Power Threshold(dBm)  | 1.9        | -28.2     | 0.0          | -25.0       |
| Tx Power Threshold(dBm)  | 0.0        | -18.0     | -2.0         | -16.0       |
| LBC Threshold(mA)        | 0.00       | 0.00      | 0.00         | 0.00        |
| Temp. Threshold(celsius) | 80.00      | -5.00     | 75.00        | 15.00       |
| Voltage Threshold(volt)  | 3.46       | 3.13      | 3.43         | 3.16        |

LBC High Threshold = 98 %  
 Configured Tx Power = -7.00 dBm  
 Configured CD High Threshold = 80000 ps/nm  
 Configured CD lower Threshold = -80000 ps/nm  
 Configured OSNR lower Threshold = 9.00 dB  
 Configured DGD Higher Threshold = 180.00 ps  
 Baud Rate = 30.0692729950 GBd  
 Modulation Type: QPSK  
 Chromatic Dispersion -2 ps/nm  
 Configured CD-MIN -4000 ps/nm CD-MAX 4000 ps/nm  
 Second Order Polarization Mode Dispersion = 109.00 ps^2  
 Optical Signal to Noise Ratio = 32.30 dB  
 Polarization Dependent Loss = 0.05 dB  
 Polarization Change Rate = 0.00 rad/s  
 Differential Group Delay = 0.00 ps

Temperature = 48.00 Celsius  
 Voltage = 3.30 V

Transceiver Vendor Details

Form Factor : QSFP-DD  
 Optics type : QSFP-DD 400G-ZRP-S  
 Name : CISCO-ACACIA  
 OUI Number : 7c.b2.5c  
 Part Number : DP04QSDD-E30-19E  
 Rev Number : 01  
 Serial Number : ACA2503003X  
 PID : QDD-400G-ZRP-S  
 VID : ES03  
 Firmware Version : 61.20 (Build : 13)  
 Date Code (yy/mm/dd) : 21/01/22

# Configuring Breakout

| Feature Name  | Release Information | Description   |
|---|---------------------|---|
| Support for 2x100G, 3x100G and 4x100G Breakout Configurations | Release 7.8.1       | <p>This release introduces 2x100G, 3x100G and 4x100G breakout configurations on the following line cards:</p> <ul style="list-style-type: none"> <li>• A9903-20HG-PEC (2x100G, 3x100G, and 4x100G)</li> <li>• A99-10X400GE-X-SE/TR (3x100G)</li> <li>• A9K-20HG-FLEX-SE/TR (2x100G, 3x100G, and 4x100G)</li> <li>• A9K-8HG-FLEX-SE/TR (2x100G, 3x100G, and 4x100G)</li> </ul> |

Using the **hw-module location** *node-id* port *port-number* **breakout muxponder-mode** command, you can configure breakout on the ports.

For configuring breakout on Cisco ASR 9903 router, use the following command:

**hw-module location** *node-id* bay *bay-number* port *port-number* **breakout muxponder-mode**

The value for *bay-number* is always 1.

For the supported line cards, ports, and modes, see [Table 1: Supported Line Cards, Ports, and Modes, on page 2](#).

## Configuring Breakout on the Line card with Default 100G Port Speed

The ports with default 100G speed can be configured to operate at 400G port speed using the following command:

This example shows how to configure 1x400G transponder mode on a port with default 100G port speed:

- **hw-module location 0/0/CPU0 port 0 breakout 1xFourHundredGigE**

To remove the breakout configuration and revert to the default 100G port speed, use the **no** form of the command.

For example:

- **no hw-module location 0/0/CPU0 port 0 breakout 1xFourHundredGigE**



**Note** In the A9903-20HG-PEC card, to configure 1x400G transponder mode, use the **hw-module location 0/0/CPU0 bay 1 port 0 breakout 1xFourHundredGigE** command. To remove the breakout configuration and revert to the default 100G port speed, use the **no** for the command - **no hw-module location 0/0/CPU0 bay 1 port 0 breakout 1xFourHundredGigE**.



To configure 4x100G or 2x100G muxponder mode, use the 4x100G or 2x100G breakout on the supported port(s).

For example:

- **hw-module location 0/0/CPU0 port 0 breakout 4xHundredGigE**
- **hw-module location 0/0/CPU0 port 7 breakout 2xHundredGigE**
- **hw-module location 0/0/CPU0 port 7 breakout 3xHundredGigE**

To remove the breakout configuration and revert to the default 100G port speed, use the **no** form of the command.

For example:

- **no hw-module location 0/0/CPU0 port 0 breakout 4xHundredGigE**
- **no hw-module location 0/0/CPU0 port 7 breakout 2xHundredGigE**
- **no hw-module location 0/0/CPU0 port 7 breakout 3xHundredGigE**

### **Configuring Breakout on the Line card with Default 400G Port Speed**

The ports with default 400G speed can be configured to operate at 100G port speed using the following command:

This example shows how to configure 1x100G transponder mode on a port with default 400G port speed:

For example:

- **hw-module location 0/0/CPU0 port 0 breakout 1xHundredGigE**

To remove the breakout configuration and revert to the default 400G port speed, use the **no** form of the command.

For example:

- **no hw-module location 0/0/CPU0 port 0 breakout 1xHundredGigE**

To configure 4x100G or 2x100G or 3x100G muxponder mode, use the 4x100G or 2x100G or 3x100G breakout on the supported port(s).

For example:

- **hw-module location 0/0/CPU0 port 0 breakout 4xHundredGigE**
- **hw-module location 0/0/CPU0 port 7 breakout 2xHundredGigE**
- **hw-module location 0/0/CPU0 port 7 breakout 3xHundredGigE**

To remove the breakout configuration and revert to the default 400G port speed, use the **no** form of the command.

For example:

- **no hw-module location 0/0/CPU0 port 0 breakout 4xHundredGigE**
- **no hw-module location 0/0/CPU0 port 7 breakout 2xHundredGigE**

- no hw-module location 0/0/CPU0 port 7 breakout 3xHundredGigE

### Muxponder Mode Configuration Example

The following example shows how to configure muxponder mode on the optics controller:

```
Router#config
Router(config)#hw-module location 0/0/CPU0 port 3 breakout 4xHundredGigE
Router(config-Optics)#commit
Router(config-Optics)#exit
Router(config)#exit
```



**Note** In the above example, the Cisco IOS XR software creates four Ethernet clients with 100GE speed, which can be verified using the **show ipv4 interface brief location | include R/S/I/P** command.

### Running Configuration

This example shows the running configuration for the optics controller:

```
Router#show running-config | inc break
Building configuration...
hw-module location 0/1/CPU0 port 1 breakout 1xHundredGigE
hw-module location 0/1/CPU0 port 3 breakout 4xHundredGigE
hw-module location 0/1/CPU0 port 8 breakout 1xHundredGigE
!
```

### Verification

This example shows how to verify the muxponder mode configuration:

```
Router#show ipv4 interface brief location 0/1/CPU0 | inc 0/1/0/3
HundredGigE0/1/0/3/0 unassigned Shutdown Down default
HundredGigE0/1/0/3/1 unassigned Shutdown Down default
HundredGigE0/1/0/3/2 unassigned Shutdown Down default
HundredGigE0/1/0/3/3 unassigned Shutdown Down default
```

## Configuring FEC

You can configure forward error correction (FEC) only on optics controllers. You can modify FEC only on the QDD-400G-ZRP-S optical module. FEC is a feature that is used for controlling errors during data transmission. This feature works by adding data redundancy to the transmitted message using an algorithm. This redundancy allows the receiver to detect and correct a limited number of errors occurring anywhere in the message, instead of having to ask the transmitter to resend the message.



**Note** QDD-400G-ZR-S supports cFEC (concatenated forward error correction) and QDD-400G-ZRP-S supports cFEC and oFEC (open forward error correction).

### FEC Configuration Example

The following sample shows how to configure FEC on the optics controller:

```
Router#configure
Router(config)#controller optics 0/19/0/5
Router(config-Optics)#fec CFEC
```

```
Router(config-Optics)#commit
Router(config-Optics)#exit
Router(config)#exit
```

### Running Configuration

This example shows the running configuration:

```
Router#show run controllers optics 0/19/0/5
controller 0/19/0/5
  fec CFEC
!
```

### Verification

This example shows how to verify the FEC configuration for the optics controller:

```
Router#show controller coherentdsp 0/19/0/5

Port                               : CoherentDSP 0/19/0/5
Controller State                    : Up
Inherited Secondary State          : Normal
Configured Secondary State         : Normal
Derived State                       : In Service
Loopback mode                       : None
BER Thresholds                      : SF = 1.0E-5  SD = 1.0E-7
Performance Monitoring              : Enable
Bandwidth                           : 400.0Gb/s

Alarm Information:
LOS = 0 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0          SF_BER = 0
SD_BER = 0          BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0  FLEXP_GIDM = 0
FLEXP-MM = 0  FLEXP-LOM = 0  FLEXP-RDI = 0
FLEXP-LOF = 1
Detected Alarms                    : None

Bit Error Rate Information
PREFEC BER                          : 4.5E-04
POSTFEC BER                          : 0.0E+00
Q-Factor                             : 10.40 dB
Q-Margin                             : 3.20dB
OTU TTI Received

FEC mode                             : C_FEC
```

## Configuring Frequency

You can configure frequency on optics controllers. You can select any C band frequency between the range 196.1 to 191.3 THz, in both ITU and NON-ITU channels.



**Note** The 100MHz-grid keyword accepts only frequency values as user input. The 50GHz-grid keyword accepts frequency, ITU-channel, or wavelength values as user input. The Cisco IOS XR software then calculates the frequency for a given wavelength or ITU-channel.

### Frequency Configuration Example

The following example shows how to configure frequency on the optics controller:

```
Router#config
Router(config)#controller optics 0/1/0/9
Router(config-Optics)#dwdm-carrier 100MHz-grid frequency 1921500
Router(config-Optics)#commit
Router(config-Optics)#exit
Router(config)#exit
```

### Running Configuration

This example shows the running configuration:

```
Router#show run controller optics 0/1/0/9
controller Optics0/1/0/9
  dwdm-carrier 100MHz-grid frequency 1921500
  cd-low-threshold -5000
  cd-high-threshold -5000
!
```

### Verification

This example shows how to verify the frequency configuration:

```
Router#show controllers optics 0/1/0/9
Controller State: Up
Transport Admin State: In Service
Laser State: On
LED State: Green
FEC State: FEC OFEC
Optics Status

  Optics Type: 400G QSFP-DD ZRP
  DWDM carrier Info: C BAND, MSA ITU Channel=80, Frequency=192.15THz,
  Wavelength=1560.200nm

  Alarm Status:
  -----
  Detected Alarms: None
  LOS/LOL/Fault Status:

  Laser Bias Current = 52.5 mA
  Actual TX Power = -11.03 dBm
  RX Power = -12.15 dBm
  RX Signal Power = -12.15 dBm
  Frequency Offset = -140 MHz
  Laser Temperature = 52.45 Celsius
  Laser Age = 0 %
  DAC Rate = 1x1.25
  Performance Monitoring: Enable

  THRESHOLD VALUES
  -----
  Parameter                               High Alarm  Low Alarm  High Warning  Low Warning
  -----
  Rx Power Threshold(dBm)                  1.9         -23.0      0.0           -20.0
  Tx Power Threshold(dBm)                   0.0         -18.0     -2.0           -16.0
  LBC Threshold(mA)                        0.00        0.00      0.00           0.00
  Temp. Threshold(celsius)                 80.00       -5.00     75.00          15.00
  Voltage Threshold(volt)                   3.46        3.13      3.43           3.16

  LBC High Threshold = 98 %
  Configured Tx Power = -7.00 dBm
  Configured CD High Threshold = 5000 ps/nm
  Configured CD lower Threshold = -5000 ps/nm
```

```

Configured OSNR lower Threshold = 9.00 dB
Configured DGD Higher Threshold = 180.00 ps
Baud Rate = 60.1385459900 GBd
Modulation Type: 16QAM
Chromatic Dispersion 0 ps/nm
Configured CD-MIN -26000 ps/nm CD-MAX 26000 ps/nm
Second Order Polarization Mode Dispersion = 36.00 ps^2
Optical Signal to Noise Ratio = 35.80 dB
Polarization Dependent Loss = 0.08 dB
Polarization Change Rate = 0.00 rad/s
Differential Group Delay = 1.00 ps

Temperature = 54.00 Celsius
Voltage = 3.29 V

```

#### Transceiver Vendor Details

```

Form Factor : QSFP-DD
Optics type : QSFP-DD 400G-ZRP-S
Name : CISCO-ACACIA
OUI Number : 7c.b2.5c
Part Number : DP04QSDD-E30-19D
Rev Number : B0
Serial Number : ACA2440001M
PID : QDD-400G-ZRP-S
VID : VES1
Firmware Version : 61.20 (Build : 13)
Date Code(yy/mm/dd) : 20/10/02

```

## Configuring Chromatic Dispersion

You can configure chromatic dispersion on optics controllers. When you configure the maximum and minimum values for chromatic dispersion for any data rate, ensure that the minimum difference between the configured values is equal to or greater than 1000 ps/nm.

The following table lists the default CD search range:

**Table 5: Default CD Search Range**

| Muxponder Rate | FEC Value | Default CD Search Range (Min-Max) |
|----------------|-----------|-----------------------------------|
| 400            | OFEC      | -26000 to +26000                  |
| 400            | CFEC      | -2400 to +2400                    |
| 300            | OFEC      | -50000 to +50000                  |
| 200            | OFEC      | -50000 to +50000                  |
| 100            | OFEC      | -80000 to +80000                  |

### Chromatic Dispersion Configuration Example

This example shows how to configure chromatic dispersion on the optics controller:

```

Router#configure
Router(config)#controller optics 0/19/0/5
Router(config-Optics)#cd-max 2500

```

```
Router(config-Optics)#cd-min -2500
Router(config-Optics)#commit
Router(config-Optics)#exit
Router(config)#exit
```

### Running Configuration

This example shows the running configuration for the optics controller:

```
Router#show run controller optics 0/19/0/5
controller Optics0/19/0/5
  cd-min -2500
  cd-max 2500
  !
```

### Verification

This example shows how to verify the configured chromatic dispersion values for the optics controller:

```
Router#show controller optics 0/19/0/5
Controller State: Up
Transport Admin State: In Service
Laser State: On
LED State: Red
FEC State: FEC CFEC
Optics Status
```

```
Optics Type: 400G QSFP-DD ZR
DWDM carrier Info: C BAND, MSA ITU Channel=61, Frequency=193.10THz,
Wavelength=1552.524nm
```

```
Alarm Status:
```

```
-----
Detected Alarms: None
LOS/LOL/Fault Status:
Laser Bias Current = 52.5 mA
Actual TX Power = 2.02 dBm
RX Power = 0.91 dBm
RX Signal Power = -7.44 dBm
Frequency Offset = -65 MHz
Laser Temperature = 54.54 Celsius
Laser Age = 0 %
DAC Rate = 1x1
Performance Monitoring: Enable
```

```
THRESHOLD VALUES
```

```
-----
Parameter                High Alarm  Low Alarm  High Warning  Low Warning
-----
Rx Power Threshold(dBm)   1.9        -23.0     0.0           -20.0
Tx Power Threshold(dBm)   0.0        -18.0     -2.0          -16.0
LBC Threshold(mA)         0.00       0.00      0.00          0.00
Temp. Threshold(celsius) 80.00      -5.00     75.00         15.00
Voltage Threshold(volt)   3.46       3.13     3.43           3.16
```

```
LBC High Threshold = 98 %
Configured Tx Power = -7.00 dBm
Configured CD High Threshold = 80000 ps/nm
Configured CD lower Threshold = -80000 ps/nm
Configured OSNR lower Threshold = 9.00 dB
Configured DGD Higher Threshold = 180.00 ps
Baud Rate = 59.8437500000 GBd
Modulation Type: 16QAM
Chromatic Dispersion 1 ps/nm
Configured CD-MIN -2500 ps/nm CD-MAX 2500 ps/nm
```

```

Second Order Polarization Mode Dispersion = 39.00 ps^2
Optical Signal to Noise Ratio = 36.40 dB
Polarization Dependent Loss = 0.07 dB
Polarization Change Rate = 0.00 rad/s
Differential Group Delay = 5.00 ps
    
```

```

Temperature = 51.94 Celsius
Voltage = 3.31 V
    
```

Transceiver Vendor Details

```

Form Factor           : QSFP-DD
Optics type           : QSFP-DD 400G-ZR-S
Name                  : CISCO-ACACIA
OUI Number            : 7c.b2.5c
Part Number           : DP04QSDD-E20-190
Rev Number            : A
Serial Number         : ACA25220027
PID                   : QDD-400G-ZR-S
VID                   : V01
Firmware Version      : 61.20 (Build : 13)
Date Code (yy/mm/dd) : 21/06/01
    
```

# Configuring Optical Transmit Power

You can set the transmit power of the optical signal.

Each QDD-400G-ZR-S and QDD-400G-ZRP-S optical module has its own optical transmit (TX) power range. User can change the optical transmit (TX) power value based on the module capability. For "Transmitter specifications", see the [Cisco 400G Digital Coherent Optics QSFP-DD Optical Modules Data Sheet](#).

**Table 6: Optical Transmit Power Values**

| Optical Module | Trunk Speed | Optical Transmit Power (Tx) Shaping | Interval | Supported Range of Optical Transmit Power (Tx) Values (in units of 0.1dBm) <sup>1</sup> |                       |                          |
|----------------|-------------|-------------------------------------|----------|---|-----------------------|--------------------------|
|                |             |                                     |          | Minimum Value   | Maximum Typical Value | Maximum Worst Case Value |
| QDD-400G-ZR-S  | 400G        | No                                  | 1        | -150  | -100                  | -100                     |
| QDD-400G-ZRPS  | 400G        | Yes                                 | 1        | -150  | -110                  | -130                     |
|                |             |                                     |          | -150  | -104                  | -119                     |
|                |             |                                     |          | -150  | -90                   | -105                     |
|                |             |                                     |          | -150  | -59                   | -75                      |
| DP04QSDD-HE0   | 400G        | Yes                                 | 1        | -150  | 15                    | 25                       |
|                | 300G        |                                     |          |   |                       |                          |
|                | 200G        |                                     |          |   |                       |                          |
|                | 100G        |                                     |          |   |                       |                          |

1. The default optical transmit power (Tx) value is -10 dBm, however with TX shaping enabled the maximum power in 1x400G, 4x100G, 3x100G, and 2x100G modes may be less than -10 dBm.

### Transmitting Power Configuration Example

The following example shows how to configure the optical transmit (TX) power on the optics controller:

```
Router#config
Router(config)#controller optics 0/19/0/3
Router(config-Optics)#transmit-power -70
Router(config-Optics)#commit
Router(config-Optics)#exit
Router(config)#exit
```

### Running Configuration

This example shows the running configuration for the optics controller:

```
Router#show run controller optics 0/19/0/3
Thu May 13 12:52:35.020 UTC
controller Optics0/19/0/3
  cd-min -4000
  cd-max 4000
  transmit-power -70
!
```

### Verification

This example shows how to verify the configured optical transmit power for the optics controller:

```
Router#show controller optics 0/19/0/3
Controller State: Up
Transport Admin State: In Service
Laser State: On
LED State: Green
FEC State: FEC OFEC
Optics Status

    Optics Type: 400G QSFP-DD ZRP
    DWDM carrier Info: C BAND, MSA ITU Channel=61, Frequency=193.10THz,
    Wavelength=1552.524nm

    Alarm Status:
    -----
    Detected Alarms: None
    LOS/LOL/Fault Status:
    Laser Bias Current = 70.9 mA
    Actual TX Power = -7.06 dBm
    RX Power = -7.88 dBm
    RX Signal Power = -7.88 dBm
    Frequency Offset = -220 MHz
    Laser Temperature = 53.79 Celsius
    Laser Age = 0 %
    DAC Rate = 1x1.25
    Performance Monitoring: Enable

    THRESHOLD VALUES
    -----

    Parameter                               High Alarm  Low Alarm  High Warning  Low Warning
    -----
    Rx Power Threshold(dBm)                 1.9         -28.2      0.0           -25.0
    Tx Power Threshold(dBm)                 0.0         -18.0      -2.0          -16.0
    LBC Threshold(mA)                       0.00        0.00      0.00          0.00
    Temp. Threshold(celsius)                80.00       -5.00     75.00         15.00
```



```

Voltage Threshold(volt)          3.46          3.13          3.43          3.16

LBC High Threshold = 98 %
Configured Tx Power = -7.00 dBm
Configured CD High Threshold = 80000 ps/nm
Configured CD lower Threshold = -80000 ps/nm
Configured OSNR lower Threshold = 9.00 dB
Configured DGD Higher Threshold = 180.00 ps
Baud Rate = 30.0692729950 GBd
Modulation Type: QPSK
Chromatic Dispersion -2 ps/nm
Configured CD-MIN -4000 ps/nm  CD-MAX 4000 ps/nm
Second Order Polarization Mode Dispersion = 109.00 ps^2
Optical Signal to Noise Ratio = 32.30 dB
Polarization Dependent Loss = 0.05 dB
Polarization Change Rate = 0.00 rad/s
Differential Group Delay = 0.00 ps
Temperature = 48.00 Celsius
Voltage = 3.30 V
    
```

Transceiver Vendor Details

```

Form Factor           : QSFP-DD
Optics type           : QSFP-DD 400G-ZRP-S
Name                  : CISCO-ACACIA
OUI Number            : 7c.b2.5c
Part Number           : DP04QSDD-E30-19E
Rev Number            : 01
Serial Number         : ACA2503003X
PID                   : QDD-400G-ZRP-S
VID                   : ES03
Firmware Version      : 61.20 (Build : 13)
Date Code (yy/mm/dd) : 21/01/22
    
```

## Configuring Performance Monitoring

Performance monitoring (PM) parameters are used by service providers to gather, store, set thresholds for, and report performance data for early detection of problems. The user can retrieve both current and historical PM counters for the various controllers in 30-second, 15-minute, and 24-hour intervals.

Performance monitoring can be configured on optics controllers and coherent DSP controllers.

To stop performance monitoring on optics or coherent DSP controllers, use the **perf-mon disable** keyword.

## Configuring PM Parameters

The performance monitoring (PM) threshold and the threshold crossing alert (TCA) reporting status can be configured for optics controllers and coherent DSP controllers:

**Table 7: PM Thresholds and TCA Report Status for Optics Controllers**

| PM Parameters | Description   |
|---------------|---|
| CD            | Sets the CD (chromatic dispersion) threshold or TCA reporting status. |

| PM Parameters | Description   |
|---------------|---|
| DGD           | Sets the DGD (differential group delay) threshold or TCA reporting status.                    |
| LBC           | Sets the LBC (laser bias current) threshold or TCA reporting status in mA.                    |
| FREQ-OFF      | Sets the FREQ-OFF (low signal frequency offset) threshold or TCA reporting status in Mhz.     |
| OPR           | Sets the OPR (optical power RX) threshold or TCA reporting status in uW or dbm.               |
| OPT           | Sets the OPT (optical power TX) threshold or TCA reporting status in uW or dbm.               |
| OSNR          | Sets the OSNR (optical signal-to-noise ratio) threshold or TCA reporting status.              |
| PCR           | Sets the PCR (polarization change rate) threshold or TCA reporting status.                    |
| PDL           | Sets the PDL (polarization dependent loss) threshold or TCA reporting status.                 |
| RX-SIG        | Sets the RX-SIG (receiving signal power) threshold or TCA reporting status in uW or dbm.      |
| SNR           | Sets the SNR (signal-to-noise ratio) threshold or TCA reporting status.                       |
| SOPMD         | Sets the SOPMD (second order polarization mode dispersion) threshold or TCA reporting status. |

**Table 8: PM Thresholds TCA Report Status for Coherent DSP Controllers**

| PM Parameters | Description  |
|---------------|--|
| Q             | Sets the Q threshold or TCA reporting status.                              |
| Q-margin      | Sets the Q margin threshold or TCA reporting status.                       |
| EC-BITS       | Sets the EC-BITS (error corrected bits) threshold or TCA reporting status. |
| PostFEC BER   | Sets the post-FEC BER threshold or TCA reporting status.                   |
| PreFEC BER    | Sets the pre-FEC BER threshold or TCA reporting status.                    |
| UC-WORDS      | Sets the UC-WORDS (uncorrected words) threshold or TCA reporting status.   |

### Performance Monitoring Configuration Example

This example shows how to enable performance monitoring and set PM thresholds on the optics controller:

```
Router#config
Router(config)#controller optics 0/2/0/16
Router(config-Optics)#perf-mon enable
Router(config-Optics)#pm 30-sec optics threshold cd max 100
Router(config-Optics)#pm 30-sec optics threshold cd min -100
Router(config-Optics)#commit
```

### Running Configuration

This example shows the running configuration on optics controllers:

```
Router#show run controller optics 0/2/0/16
Thu May 13 20:18:55.957 UTC
controller Optics0/2/0/16
pm 30-sec optics threshold cd max 100
pm 30-sec optics threshold cd min -100
perf-mon enable
!
```

### Verification

This example shows how to verify the PM parameters on optics controllers. Verify the configuration changes in the Configured Threshold fields:

```
Router#show controller optics 0/2/0/16 pm current 30-sec optics 1
Thu May 27 17:58:49.889 UTC
Optics in the current interval [17:58:30 - 17:58:49 Thu May 27 2021]
Optics current bucket type : Valid
```

|               | MIN        | AVG    | MAX    | Operational    | Configured     | TCA   | Operational    |
|---------------|------------|--------|--------|----------------|----------------|-------|----------------|
|               | Configured | TCA    |        | Threshold(min) | Threshold(min) | (min) | Threshold(max) |
| LBC[mA]       | : 0.0      | 0.0    | 0.0    | 0.0            | NA             | NO    | 100.0          |
| OPT[dBm]      | : -9.98    | -9.98  | -9.98  | -15.09         | NA             | NO    | 0.00           |
| OPR[dBm]      | : -40.00   | -40.00 | -40.00 | -30.00         | NA             | NO    | 8.00           |
| CD[ps/nm]     | : 0        | 0      | 0      | -80000         | <b>-100</b>    | NO    | 100            |
| DGD[ps]       | : 0.00     | 0.00   | 0.00   | 0.00           | NA             | NO    | 80.00          |
| SOPMD[ps^2]   | : 0.00     | 0.00   | 0.00   | 0.00           | NA             | NO    | 2000.00        |
| OSNR[dB]      | : 0.00     | 0.00   | 0.00   | 0.00           | NA             | NO    | 40.00          |
| PDL[dB]       | : 0.00     | 0.00   | 0.00   | 0.00           | NA             | NO    | 7.00           |
| PCR[rad/s]    | : 0.00     | 0.00   | 0.00   | 0.00           | NA             | NO    | 2500000.00     |
| RX_SIG[dBm]   | : -40.00   | -40.00 | -40.00 | -30.00         | NA             | NO    | 1.00           |
| FREQ_OFF[Mhz] | : 0        | 0      | 0      | -3600          | NA             | NO    | 3600           |
| SNR[dB]       | : 0.00     | 0.00   | 0.00   | 7.00           | NA             | NO    | 100.00         |

```
Last clearing of "show controllers OPTICS" counters never
!
```

### Performance Monitoring Configuration Example

This example shows how to enable performance monitoring and set PM thresholds and TCA reporting status on the coherent DSP controller:

```
Router#config
Router(config)#controller CoherentDSP0/2/0/16
Router(config-CoDSP)#perf-mon enable
Router(config-CoDSP)#pm 30-sec fec report Q max-tca enable
Router(config-CoDSP)#pm 30-sec fec report Q-margin max-tca enable
Router(config-CoDSP)#pm 30-sec fec report Q min-tca enable
Router(config-CoDSP)#pm 30-sec fec report Q-margin min-tca enable
Router(config-CoDSP)#pm 30-sec fec threshold Q max 1200
Router(config-CoDSP)#pm 30-sec fec threshold Q-margin max 500
Router(config-CoDSP)#pm 30-sec fec threshold Q min 900
Router(config-CoDSP)#pm 30-sec fec threshold Q-margin min 280
Router(config-CoDSP)#commit
```

### Running Configuration

This example shows the running configuration on coherent DSP controllers:

```
Router#show run controller coherentdsp 0/2/0/16
Thu May 13 19:56:09.136 UTC
controller CoherentDSP0/2/0/16
  pm 30-sec fec report Q max-tca enable
  pm 30-sec fec report Q-margin max-tca enable
  pm 30-sec fec report Q min-tca enable
  pm 30-sec fec report Q-margin min-tca enable
  pm 30-sec fec threshold Q max 1200
  pm 30-sec fec threshold Q-margin max 500
  pm 30-sec fec threshold Q min 900
  pm 30-sec fec threshold Q-margin min 280
  perf-mon enable
!
```

### Verification

This example shows how to verify the PM parameters on coherent DSP controllers. Verify the configuration changes in the highlighted fields:

```
Router#show controllers coherentdsp 0/2/0/16 pm current 30-sec fec
Thu May 27 23:04:54.167 UTC
g709 FEC in the current interval [23:04:30 - 23:04:54 Thu May 27 2021]
FEC current bucket type : Valid
  EC-BITS      : 0                               Threshold : 111484000000          TCA(enable)  :
YES
  UC-WORDS    : 0                               Threshold : 5                        TCA(enable)  :
YES

  Threshold    TCA                               MIN      AVG      MAX      Threshold    TCA
  (max)        (enable)
PreFEC BER    : 0E-15 0E-15 0E-15 0E-15 0E-15 9.00 YES 120.00 YES
0E-15         NO
PostFEC BER   : 0E-15 0E-15 0E-15 0E-15 0E-15 0E-15 NO
0E-15         NO
Q[dB]         : 0.00 0.00 0.00 9.00 YES 120.00 YES
Q_Margin[dB] : 0.00 0.00 0.00 2.80 YES 5.00 YES
!
```

# Configuring Loopback

You can configure internal or line loopback on coherent DSP controllers. Loopback can be performed only in the maintenance mode.

## Loopback Configuration Example

This example shows how to enable internal loopback configuration on coherent DSP controllers:

```
Router#config
Router(config)#controller coherentDSP 0/0/0/4
Router(config-CoDSP)#secondary-admin-state maintenance
Router(config-CoDSP)#loopback internal
Router(config-CoDSP)#commit
```

## Running Configuration

This example shows the running configuration on coherent DSP controllers:

```
Router#show run controller coherentdsp 0/0/0/4
controller CoherentDSP0/0/0/4
  secondary-admin-state maintenance
  loopback internal
!
```

## Verification

This example shows how to verify the loopback configuration on coherent DSP controllers:

```
Router#show controller coherentdsp 0/0/0/4
Thu May 27 17:28:51.960 UTC
Port                               : CoherentDSP 0/0/0/4
Controller State                    : Down
Inherited Secondary State          : Normal
Configured Secondary State       : Maintenance
Derived State                       : Maintenance
Loopback mode                   : Internal
BER Thresholds                     : SF = 1.0E-5  SD = 1.0E-7
Performance Monitoring              : Enable
Bandwidth                           : 400.0Gb/s
Alarm Information:
LOS = 6 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0 FLEXP_GIDM = 0
FLEXP-MM = 0 FLEXP-LOM = 0 FLEXP-RDI = 0
FLEXP-LOF = 5
Detected Alarms                    : LOS
Bit Error Rate Information
  PREFEC BER                        : 5.0E-01
  POSTFEC BER                       : 0.0E+00
  Q-Factor                          : 0.00 dB
  Q-Margin                          : -7.20dB
  OTU TTI Received                  :
  FEC mode                          : C_FEC
```

# Configuring Alarms Threshold

The alarms threshold can be configured for monitoring alarms on optics controllers:

Table 9: Alarms Threshold Parameters for Optics Controllers

| Alarm Threshold Parameters | Description  |
|----------------------------|--|
| CD                         | Sets the CD (chromatic dispersion) alarm threshold (cd-low-threshold and cd-high-threshold). |
| DGD                        | Sets the DGD (differential group delay) alarm threshold.                                     |
| LBC                        | Sets the LBC (laser bias current) threshold in mA.   |
| OSNR                       | Sets the OSNR (optical signal-to-noise ratio) alarm threshold.                               |

### Alarm Threshold Configuration Example

This example shows how to configure alarm threshold on the optics controller:

```
Router#config
Router(config)#controller optics 0/2/0/16
Router(config-Optics)#cd-low-threshold -5000
Router(config-Optics)#cd-high-threshold 5000
Router(config-Optics)#commit
```

### Running Configuration

This example shows the running configuration on the optics controller:

```
Router#show run controller optics 0/2/0/16
controller Optics0/2/0/16
  cd-low-threshold 5000
  cd-high-threshold 5000
!
```

### Verification

This example shows how to verify the alarm threshold on optics controllers:

```
Router#show controller optics 0/2/0/16
Fri May 28 01:04:33.604 UTC
Controller State: Up
Transport Admin State: In Service
Laser State: Off
LED State: Off
FEC State: FEC OFEC
Optics Status
  Optics Type: 400G QSFP-DD ZRP
  DWDM carrier Info: C BAND, MSA ITU Channel=61, Frequency=193.10THz,
  Wavelength=1552.524nm
  Alarm Status:
  -----
  Detected Alarms: None
  LOS/LOL/Fault Status:
  Alarm Statistics:
  -----
  HIGH-RX-PWR = 0          LOW-RX-PWR = 0
  HIGH-TX-PWR = 0          LOW-TX-PWR = 0
  HIGH-LBC = 0             HIGH-DGD = 0
  OOR-CD = 0               OSNR = 0
  WV-L-OOL = 0             MEA = 0
  IMPROPER-REM = 0
  TX-POWER-PROV-MISMATCH = 0
```

Laser Bias Current = 0.0 mA  
 Actual TX Power = -40.00 dBm  
 RX Power = -40.00 dBm  
 RX Signal Power = -40.00 dBm  
 Frequency Offset = 0 MHz  
 Laser Temperature = 0.00 Celsius  
 Laser Age = 0 %  
 DAC Rate = 1x1.25  
 Performance Monitoring: Enable  
 THRESHOLD VALUES

| Parameter                | High Alarm | Low Alarm | High Warning | Low Warning |
|--------------------------|------------|-----------|--------------|-------------|
| Rx Power Threshold(dBm)  | 13.0       | -24.0     | 10.0         | -22.0       |
| Tx Power Threshold(dBm)  | 0.0        | -16.0     | -2.0         | -14.0       |
| LBC Threshold(mA)        | 0.00       | 0.00      | 0.00         | 0.00        |
| Temp. Threshold(celsius) | 80.00      | -5.00     | 75.00        | 0.00        |
| Voltage Threshold(volt)  | 3.46       | 3.13      | 3.43         | 3.16        |

LBC High Threshold = 98 %  
 Configured Tx Power = -10.00 dBm  
**Configured CD High Threshold = -5000 ps/nm**  
**Configured CD lower Threshold = -5000 ps/nm**  
 Configured OSNR lower Threshold = 9.00 dB  
 Configured DGD Higher Threshold = 80.00 ps  
 Baud Rate = 60.1385459900 GBd  
 Modulation Type: 16QAM  
 Chromatic Dispersion 0 ps/nm  
 Configured CD-MIN -26000 ps/nm CD-MAX 26000 ps/nm  
 Second Order Polarization Mode Dispersion = 0.00 ps^2  
 Optical Signal to Noise Ratio = 0.00 dB  
 Polarization Dependent Loss = 0.00 dB  
 Polarization Change Rate = 0.00 rad/s  
 Differential Group Delay = 0.00 ps  
 Temperature = 21.00 Celsius  
 Voltage = 3.42 V

Transceiver Vendor Details

Form Factor : QSFP-DD  
 Optics type : QSFP-DD 400G-ZRP-S  
 Name : CISCO-ACACIA  
 OUI Number : 7c.b2.5c  
 Part Number : DP04QSDD-E30-19E  
 Rev Number : 01  
 Serial Number : ACA2503003X  
 PID : QDD-400G-ZRP-S  
 VID : ES03  
 Firmware Version : 61.20 (Build : 13)  
 Date Code (yy/mm/dd) : 21/01/22

!

