



## INDEX

---

<b>AR</b>	Cisco ASR 9000 Series Aggregation Services Router Advanced System Command Reference
<b>HR</b>	Cisco ASR 9000 Series Aggregation Services Router Interface and Hardware Component Command Reference
<b>IR</b>	Cisco ASR 9000 Series Aggregation Services Router IP Addresses and Services Command Reference
<b>MCR</b>	Cisco ASR 9000 Series Aggregation Services Router Multicast Command Reference
<b>MNR</b>	Cisco ASR 9000 Series Aggregation Services Router System Monitoring Command Reference
<b>MPR</b>	Cisco ASR 9000 Series Aggregation Services Router MPLS Command Reference
<b>NFR</b>	Cisco ASR 9000 Series Aggregation Services Router NetFlow Command Reference
<b>QR</b>	Cisco ASR 9000 Series Aggregation Services Router Modular Quality of Service Command Reference
<b>RR</b>	Cisco ASR 9000 Series Aggregation Services Router Routing Command Reference
<b>SMR</b>	Cisco ASR 9000 Series Aggregation Services Router System Management Command Reference
<b>SR</b>	Cisco ASR 9000 Series Aggregation Services Router System Security Command Reference
<b>VPR</b>	Cisco ASR 9000 Series Aggregation Services Router L2VPN and Ethernet Services Command Reference

---

### C

cache entries command	<a href="#">NFR-6</a>
cache permanent command	<a href="#">NFR-7</a>
clear flow exporter command	<a href="#">NFR-11</a>
clear flow monitor command	<a href="#">NFR-13</a>

---

### D

destination command	<a href="#">NFR-15</a>
dscp command	<a href="#">NFR-16</a>

---

### E

exporter command	<a href="#">NFR-17</a>
------------------	------------------------

---

### F

flow command	<a href="#">NFR-19</a>
flow exporter-map command	<a href="#">NFR-21</a>
flow monitor-map command	<a href="#">NFR-23</a>

---

### O

options command	<a href="#">NFR-25</a>
-----------------	------------------------

---

### R

random 1 out-of command	<a href="#">NFR-27</a>
record ipv4 command	<a href="#">NFR-28</a>
record ipv6 command	<a href="#">NFR-30</a>
record mpls command	<a href="#">NFR-32</a>

---

### S

sampler-map command	<a href="#">NFR-34</a>
show flow exporter command	<a href="#">NFR-36</a>
show flow exporter-map command	<a href="#">NFR-38</a>
show flow monitor command	<a href="#">NFR-40</a>
show flow monitor-map command	<a href="#">NFR-44</a>
show flow platform nfea bundle	<a href="#">NFR-52</a>
show flow platform nfea chkp	<a href="#">NFR-53</a>
show flow platform nfea interface	<a href="#">NFR-49</a>
show flow platform nfea policer np	<a href="#">NFR-51</a>
show flow platform nfea sampler	<a href="#">NFR-48</a>
show flow platform nfea sp location	<a href="#">NFR-50</a>
show flow platform producer statistics location command	<a href="#">NFR-46</a>
show flow trace ea location	<a href="#">NFR-55</a>

## ***R3.9.1 Final Review Draft - Cisco Confidential***

show flow trace platform producer location [NFR-54](#)

source (NetFlow) command [NFR-56](#)

---

### **T**

template command [NFR-58](#)

transport udp command [NFR-59](#)