



INDEX

AR	Cisco IOS XR Advanced System Command Reference
HR	Cisco IOS XR Interface and Hardware Component Command Reference
IR	Cisco IOS XR IP Addresses and Services Command Reference
MCR	Cisco IOS XR Multicast Command Reference
MNR	Cisco IOS XR System Monitoring Command Reference
MPR	Cisco IOS XR MPLS Command Reference
QR	Cisco IOS XR Modular Quality of Service Command Reference
RR	Cisco IOS XR Routing Command Reference
SMR	Cisco IOS XR System Management Command Reference
SR	Cisco IOS XR System Security Command Reference
LSR	Cisco IOS XR L2VPN and Ethernet Services Command Reference

A

accept-register command [MCR-336](#)
access-group (IGMP) command [MCR-2](#)
access-group command [MCR-222](#)
accounting per-prefix command [MCR-98](#)
address-family (multicast) command [MCR-100](#)
auto-rp candidate-rp command [MCR-337](#)

B

boundary command [MCR-102](#)

C

cache-sa-holdtime command [MCR-54](#)
cache-sa-state command [MCR-55](#)
clear igmp counters command [MCR-4](#)
clear igmp group command [MCR-6](#)
clear igmp reset command [MCR-8](#)
clear igmp snooping bridge-domain command [MCR-223](#)

clear igmp snooping group command [MCR-225](#)
clear igmp snooping port command [MCR-227](#)
clear igmp snooping summary command [MCR-229](#)
clear l2vpn forwarding bridge-domain mroute ipv4 command [MCR-230](#)
clear mfib counter command [MCR-103](#)
clear mfib database command [MCR-104](#)
clear mfib hardware resource-counters command [MCR-105](#), [MCR-106](#)
clear mfib hardware route statistics command [MCR-107](#)
clear msdp peer command [MCR-57](#)
clear msdp sa-cache command [MCR-58](#)
clear msdp stats command [MCR-60](#)
clear performance traffic statistics command [MCR-436](#)
clear pim counters command [MCR-339](#)
clear pim topology command [MCR-342](#)
connect-source command [MCR-61](#)

D

default-peer command [MCR-63](#)
description (peer) command [MCR-65](#)
disable (multicast) command [MCR-109](#)
dr-priority command [MCR-344](#)

E

enable (multicast) command [MCR-111](#)
explicit-tracking command [MCR-10](#)

G

global maximum command [MCR-346](#)

group limit command [MCR-231](#)
 group policy command [MCR-233](#)

H

hello-interval (PIM) command [MCR-347](#)
 how pim rpf route-policy test command [MCR-396](#)

I

igmp snooping profile command [MCR-235](#)
 immediate-leave command [MCR-238](#)
 interface (multicast) command [MCR-113](#)
 interface (PIM) command [MCR-349](#)
 interface all enable command [MCR-115](#)
 interface-inheritance disable command [MCR-117](#)
 internal-querier command [MCR-240](#)
 internal-querier max-response-time command [MCR-242](#)
 internal-querier query-interval command [MCR-244](#)
 internal-querier robustness-variable command [MCR-246](#)
 internal-querier tcn query count command [MCR-248](#)
 internal-querier tcn query interval command [MCR-250](#)
 internal-querier timer expiry command [MCR-252](#)
 internal-querier version command [MCR-254](#)

J

join-group command [MCR-12](#)
 join-prune-interval command [MCR-351](#)

L

last-member-query count command [MCR-255](#)
 last-member-query interval command [MCR-257](#)
 log-traps command [MCR-119](#)

M

maximum disable command [MCR-120](#)
 maximum external-sa command [MCR-67](#)
 maximum groups command [MCR-14](#)
 maximum groups-per-interface command [MCR-17](#)
 maximum peer-external-sa command [MCR-69](#)
 maximum register-states command [MCR-353](#)
 maximum route-interfaces command [MCR-354](#)
 maximum routes command [MCR-355](#)
 mesh-group (peer) command [MCR-71](#)
 mhost default-interface command [MCR-121](#)
 minimum-version command [MCR-259](#)
 mofrr command [MCR-357](#)
 mrimfo command [MCR-426](#)
 mrouter command [MCR-261](#)
 mrouter port
 router guard [MCR-273](#)
 mtrace command [MCR-428](#)
 multicast-routing command [MCR-123](#)
 multipath command [MCR-124](#)

N

neighbor-check-on-recv enable command [MCR-359](#)
 neighbor-check-on-send enable command [MCR-360](#)
 neighbor-filter command [MCR-361](#)
 nsf (multicast) command [MCR-125](#)
 nsf lifetime (IGMP) [MCR-20](#)
 nsf lifetime (PIM) command [MCR-362](#)

O

old-register-checksum command [MCR-364](#)
 oom-handling command [MCR-127](#)
 originator-id command [MCR-72](#)

P

password (peer) command [MCR-73](#)
 peer (MSDP) command [MCR-75](#)

Q

querier query-interval command [MCR-263](#)
 querier robustness-variable command [MCR-265](#)
 query-interval command [MCR-22](#)
 query-max-response-time command [MCR-24](#)
 query-timeout command [MCR-26](#)

R

rate-per-route command [MCR-129](#)
 redundancy iccp-group report-standby-state disable
 command [MCR-267](#)
 remote-as (multicast) command [MCR-77](#)
 report-suppression disable command [MCR-269](#)
 robustness-count command [MCR-28](#)
 router-alert-check disable command [MCR-271](#)
 router command [MCR-29](#)
 router-guard command [MCR-273](#)
 router igmp command [MCR-31](#)
 router pim command [MCR-365](#)
 rp-address command [MCR-366](#)
 rpf topology route-policy command [MCR-368](#)
 rpf-vector command [MCR-369](#)
 rp-static-deny command [MCR-370](#)

S

sa-filter command [MCR-78](#)
 sap cache-timeout command [MCR-430](#)
 sap listen command [MCR-431](#)
 show auto-rp candidate-rp command [MCR-371](#)
 show igmp groups command [MCR-33](#)
 show igmp interface command [MCR-35](#)

show igmp nsf command [MCR-38](#)
 show igmp snooping bridge-domain command [MCR-275](#)
 show igmp snooping group command [MCR-283](#)
 show igmp snooping port command [MCR-291](#)
 show igmp snooping profile command [MCR-297, MCR-304](#)
 show igmp snooping summary command [MCR-304](#)
 show igmp snooping trace command [MCR-309](#)
 show igmp ssm map command [MCR-42](#)
 show igmp summary [MCR-40](#)
 show igmp traffic command [MCR-43](#)
 show l2vpn forwarding bridge-domain mroute
 command [MCR-311](#)
 show mfib connections command [MCR-130](#)
 show mfib counter command [MCR-132](#)
 show mfib encap-info command [MCR-134](#)
 show mfib hardware interface command [MCR-136](#)
 show mfib hardware mlc command [MCR-141](#)
 show mfib hardware resource-counters
 command [MCR-145](#)
 show mfib hardware route accept-bitmap
 command [MCR-148](#)
 show mfib hardware route internal command [MCR-150](#)
 show mfib hardware route mofrr command [MCR-155](#)
 show mfib hardware route olist command [MCR-161](#)
 show mfib hardware route statistics command [MCR-172](#)
 show mfib hardware route summary command [MCR-176](#)
 show mfib hardware table command [MCR-178](#)
 show mfib interface command [MCR-180](#)
 show mfib nsf command [MCR-182](#)
 show mfib route command [MCR-184](#)
 show mfib table-info command [MCR-191](#)
 show mhost default-interface command [MCR-193](#)
 show mhost groups command [MCR-195](#)
 show mrib client command [MCR-197](#)
 show mrib label-table-info [MCR-199](#)
 show mrib mpls forwarding command [MCR-199](#)
 show mrib mpls traffic-eng fast-reroute [MCR-199](#)
 show mrib nsf command [MCR-200](#)
 show mrib platform trace command [MCR-202](#)
 show mrib route-collapse command [MCR-207](#)

show mrib route command [MCR-204](#)
show mrib route outgoing-interface [MCR-209](#)
show mrib table-info command [MCR-211](#)
show mrib tlc command [MCR-212](#)
show msdp globals command [MCR-80](#)
show msdp peer command [MCR-82](#)
show msdp rpf command [MCR-84](#)
show msdp sa-cache command [MCR-86](#)
show msdp statistics peer command [MCR-90](#)
show msdp summary command [MCR-92](#)
show performance traffic alerts command [MCR-437](#)
show pim bsr rp-cache command [MCR-373](#)
show pim context command [MCR-373](#)
show pim context table command [MCR-374](#)
show pim df winner command [MCR-376](#)
show pim group-map command [MCR-376](#)
show pim interface command [MCR-378](#)
show pim join-prune statistics command [MCR-380](#)
show pim mstatic command [MCR-382](#)
show pim neighbor command [MCR-384](#)
show pim nsf command [MCR-386](#)
show pim range-list command [MCR-388](#)
show pim rpf command [MCR-390](#)
show pim rpf hash command [MCR-392](#)
show pim rpf route-policy statistics command [MCR-394](#)
show pim summary command [MCR-400](#)
show pim topology command [MCR-402](#)
show pim topology detail command [MCR-408](#)
show pim topology entry-flag command [MCR-411](#)
show pim topology interface-flag command [MCR-413](#)
show pim topology rpf summary command [MCR-398](#)
show pim topology summary command [MCR-416](#)
show pim traffic command [MCR-418](#)
show pim tunnel info command [MCR-420](#)
show policy-map type performance-traffic command [MCR-439](#)
show sap command [MCR-432](#)
shutdown (MSDP) command [MCR-94](#)
spt-threshold infinity command [MCR-422](#)

ssm command [MCR-423](#)
ssm map static (IGMP/MLD) command [MCR-46](#)
ssm map static command [MCR-46](#)
startup query count command [MCR-313](#)
startup query iccp-group command [MCR-314](#)
startup query interval command [MCR-316](#)
startup query max-response-time command [MCR-317](#)
startup query port-up command [MCR-318](#)
startup query process command [MCR-319](#)
startup query topology-change command [MCR-320](#)
static group command [MCR-321](#)
static-group command [MCR-47](#)
static-rpf command [MCR-214](#)
system-ip-address command [MCR-323](#)

T

tcn flood disable command [MCR-325](#)
tcn flood query count command [MCR-326](#)
tcn query solicit command [MCR-328](#)
ttl-check disable command [MCR-330](#)
ttl-threshold (MSDP) command [MCR-95](#)
ttl-threshold (multicast) command [MCR-216](#)

U

unsolicited-report-interval command [MCR-332](#)

V

version command [MCR-49](#)
vrf (igmp) command [MCR-51](#)
vrf (multicast) command [MCR-218](#)