



INDEX

HC	Cisco ASR 9000 Series Aggregation Services Router Interface and Hardware Component Configuration Guide
IC	Cisco ASR 9000 Series Aggregation Services Router IP Addresses and Services Configuration Guide
MCC	Cisco ASR 9000 Series Aggregation Services Router Multicast Configuration Guide
MNC	Cisco ASR 9000 Series Aggregation Services Router System Monitoring Configuration Guide
MPC	Cisco ASR 9000 Series Aggregation Services Router MPLS Configuration Guide
NFC	Cisco ASR 9000 Series Aggregation Services Router NetFlow Configuration Guide
QC	Cisco ASR 9000 Series Aggregation Services Router Modular Quality of Service Configuration Guide
RC	Cisco ASR 9000 Series Aggregation Services Router Routing Configuration Guide
SC	Cisco ASR 9000 Series Aggregation Services Router System Security Configuration Guide
SMC	Cisco ASR 9000 Series Aggregation Services Router System Management Configuration Guide
VPC	Cisco ASR 9000 Series Aggregation Services Router L2VPN and Ethernet Services Configuration Guide

C

cache entries command	NFC-14
cache permanent command	NFC-15
cache timeout command	NFC-15
clear flow exporter command	NFC-18
clear flow monitor command	NFC-18

D

destination command	NFC-10
dscp command	NFC-10

E

exporter command	NFC-15
exporter map	NFC-4

F

flow command	NFC-17
flow exporter-map command	NFC-9
flow exporter map configuration submode	NFC-5
flow exporter map version configuration submode	NFC-6
flow monitor-map command	NFC-9, NFC-14
flow monitor map configuration submode	NFC-6

M

monitor map	NFC-3
-------------	-----------------------

N

NetFlow	
configuring	NFC-8
exporter map	NFC-4
flow exporter map configuration submode	NFC-5
flow exporter map version configuration submode	NFC-6
flow monitor map configuration submode	NFC-6
monitor map	NFC-3
overview	NFC-1, NFC-3
restrictions	NFC-2
sampler map	NFC-4
sampler map configuration submode	NFC-6

O

options command	NFC-10
-----------------	------------------------

R

random command [NFC-12](#)

record ipv4 command [NFC-14](#)

S

sampler map [NFC-4](#)

sampler-map command [NFC-12](#)

sampler map configuration submode [NFC-6](#)

show flow exporter-map command [NFC-11](#)

show flow monitor map command [NFC-16](#)

show sampler-map command [NFC-13](#)

source command [NFC-10](#)

T

template command [NFC-10](#)

transport udp command [NFC-10](#)

Trident Netflow [NFC-23](#)

V

version v9 command [NFC-10](#)
