

New Features for Cisco IOS-XE 17.4.1

This section contains the following:

• Plug and Play (PnP) Support, on page 1

Plug and Play (PnP) Support

This release enables PnP to work the same as on the IR1101. See the IR1101 Software Configuration Guide.

PnP Overview

The out of box configuration boots the platform up to the configuration wizard. The control stops at a prompt where the user is given an option to enter the startup configuration wizard or not. If the user does not have access to the router, or does not enter any options, PnP discovery kicks in. If the PnP agent successfully establishes a connection to the PnP Server, the device configurations are pushed from the Server. The platform gets configured according to the user preference.

If PnP is not setup for the Router, the WebUI is accessible without having to access the platform console.

PnP Overview