cisco.



QoS: Congestion Avoidance Configuration Guide, Cisco IOS XE 17 (Cisco NCS 4200 Series)

DiffServ Compliant WRED2Information About DiffServ Compliant WRED2How to Configure DiffServ Compliant WRED3

Configuration Examples for DiffServ Compliant WRED 5

Revised: January 14, 2020

DiffServ Compliant WRED

DiffServ Compliant WRED extends the functionality of Weighted Random Early Detection to enable support for DiffServ and Assured Forwarding (AF) per hop behavior (PHB). This feature enables customers to implement AF PHB by coloring packets according to Differentiated Services Code Point (DSCP) values and then assigning preferential drop probabilities to those packets.



Note This feature can be used with IP packets only. It is not intended for use with Multiprotocol Label Switching (MPLS)-encapsulated packets.

Information About DiffServ Compliant WRED

Differentiated Services for WRED

Differentiated Services is a multiple service model that can satisfy differing Quality of Service (QoS) requirements. With Differentiated Services, the network tries to deliver a particular kind of service based on the QoS specified by each packet. This specification can occur in different ways. The DiffServ Compliant WRED feature enables WRED to use either the 6-bit differentiated services code point (DSCP) or the IP Precedence setting in IP packets when it calculates the drop probability for a packet. The DSCP value is the first six bits of the IP type of service (ToS) byte.

Usage Guidelines for DiffServ Compliant WRED

To configure the DiffServ Compliant WRED feature, first specify the policy map, add the class, and configure the bandwidth or shape for the class. If you want WRED to use the DSCP value when it calculates the drop probability, use the *dscp-based* argument with the **random-detect** command to specify the DSCP value and then use the **random-detect dscp** command to modify the default minimum and maximum thresholds for the DSCP value. If you want WRED to use the IP Precedence value when it calculates the drop probability, use the *precedence-based* argument with the **random-detect** command to specify the IP Precedence value. This configuration can then be applied wherever policy maps are attached (for example, at the interface level, the per-VC level, or the shaper level).

Remember the following points when using the commands included with this feature:

- If you use the dscp-based argument, WRED will use the DSCP value to calculate the drop probability.
- If you use the precedence-based argument, WRED will use the IP Precedence value to calculate the drop probability.
- The dscp-based and precedence-based arguments are mutually exclusive.
- If you do not specify either argument, WRED will use the IP Precedence value to calculate the drop probability (the default method).

How to Configure DiffServ Compliant WRED

Configuring DiffServ Compliant WRED

Procedure

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	class-map class-map-name	Specifies the name of the class map to be created and enters
	Example:	QoS class-map configuration mode.
	Device(config)# class-map cl	
Step 4	match match-criterion	Configures the match criteria for a class map.
	Example:	
	Device(config-cmap)# match any	
Step 5	policy-map policy-map-name	Creates or modifies a policy map that can be attached to
	Example:	one or more interfaces to specify a service policy, and enters QoS policy-map configuration mode.
	<pre>Device(config-cmap)# policy-map p1</pre>	
Step 6	class {class-name class-default}	Specifies the name of the class whose policy you want to
	Example:	create or change or specifies the default class (commonly known as the class-default class) before you configure its
	Device(config-pmap)# class cl	policy.
		• Enters QoS policy-map class configuration mode.
Step 7	bandwidth { <i>kbps</i> remaining <i>percentage</i> percent	Specifies the bandwidth allocated for a class belonging to
	percentage}	a policy map.
	Example:	
	Device(config-pmap-c)# bandwidth percent 30	

	Command or Action	Purpose
Step 8	random-detect [dscp-based precedence-based cos-based discard-class based]	Configures WRED to use the differentiated services code point (DSCP) value when it calculates the drop probability
	Example:	for a packet
	<pre>Device(config-pmap-c)# random-detect dscp-based</pre>	
Step 9	random-detect dscp <i>dscp-value min-threshold</i> <i>max-threshold</i> [<i>mark-probability-denominator</i>]	Changes the minimum and maximum packet thresholds for the differentiated services code point (DSCP) value.
	Example:	
	Device(config-pmap-c)# random-detect dscp af11 10000 30000 25	
Step 10	exit	Exits QoS policy-map class configuration mode.
	Example:	
	Device(config-pmap-c)# exit	
Step 11	exit	Exits QoS policy-map configuration mode.
	Example:	
	Device(config-pmap)# exit	
Step 12	interface type number [name-tag]	Configures an interface type and enters interface
	Example:	configuration mode.Enter the interface type and number.
	Device(config)# interface GigabitEthernet 0/0/0	Enter the interface type and number.
Step 13	service-policy output policy-map-name	Attaches a policy map to an output interface.
	Example:	• Enter the policy map name.
	Device(config-if)# service-policy output pl	Note Policy maps can be configured on ingress or egress routers. They can also be attached in the input or output direction of an interface. The direction (input or output) and the router (ingress or egress) to which the policy map should be attached varies according your network configuration. When using the service-policy command to attach the policy map to an interface, be sure to choose the router and the interface direction that are appropriate for your network configuration.
Step 14	end	Returns to privileged EXEC mode.
	Example:	
	Device(config-if)# end	

	Command or Action	Purpose
Step 15	show policy-map interface type number	(Optional) Displays the traffic statistics of all classes that
	Example:	are configured for all service policies either on the specified interface or subinterface or on a specific PVC on the interface.
	Device# show policy-map interface GigabitEthernet	
	0/0/0	• Enter the interface type and number.
Step 16	exit	(Optional) Exits privileged EXEC mode.
	Example:	
	Device# exit	

Configuration Examples for DiffServ Compliant WRED

Example: DiffServ compliant WRED

The following example enables WRED to use the DSCP value 8 for the class c1. The minimum threshold for the DSCP value 8 is 24 and the maximum threshold is 40. The last line attaches the traffic policy to the output interface or VC p1.

```
Device(config)# class-map c1
Device(config-cmap)# match ip precedence 1
Device(config-cmap)# policy-map p1
Device(config-pmap)# class c1
Device(config-pmap-c)# bandwidth 48
Device(config-pmap-c)# random-detect dscp-based
Device(config-pmap-c)# random-detect dscp 8 24 40 (bytes/ms)
Device(config-if)# service-policy output p1
```

uluilu cisco.

Americas Headquarters Cisco Systems, Inc. San Jose, CA 95134-1706 USA Asia Pacific Headquarters CiscoSystems(USA)Pte.Ltd. Singapore Europe Headquarters CiscoSystemsInternationalBV Amsterdam,TheNetherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.