



Track Static Routes for Service VPNs

- [Feature history of track static routes for service VPNs, on page 1](#)
- [Track static routes for service VPNs, on page 2](#)
- [Supported platforms, on page 2](#)
- [Restrictions for IPv4 static route tracking, on page 3](#)
- [Configure tracker group using a configuration group, on page 3](#)
- [Create a static route tracker, on page 4](#)
- [Configure a next hop static route with tracker, on page 6](#)
- [Monitor static route tracker configuration, on page 7](#)
- [Configure static routes using CLI, on page 7](#)
- [Configuration examples static route tracking, on page 9](#)
- [Verify static route tracking configuration, on page 10](#)

Feature history of track static routes for service VPNs

This table describes the developments of this feature, by release.

Table 1: Feature history

Feature Name	Release Information	Description
Static Route Tracker for Service VPNs	Cisco IOS XE Catalyst SD-WAN Release 17.6.1a Cisco vManage Release 20.6.1	This feature enables you to configure IPv4 static route endpoint tracking for service VPNs. For static routes, endpoint tracking determines whether the configured endpoint is reachable before adding that route to the route table of the device.
TCP/UDP Endpoint Tracker and Dual Endpoint Static Route Tracker for Cisco IOS XE Catalyst SD-WAN devices	Cisco IOS XE Catalyst SD-WAN Release 17.9.1a Cisco vManage Release 20.9.1	This feature enables you to configure the TCP/UDP static route endpoint trackers. Using this feature you can also configure IPv4, TCP/UDP dual endpoint static-route tracker groups for service VPNs to enhance the reliability of probes.

Track static routes for service VPNs

Tracking static routes for service VPNs allows you to monitor the reachability of the configured next-hop endpoint IP address. You can verify the endpoint before the device adds the static route to its routing table. This is particularly important in service VPNs where static routes are advertised over the Overlay Management Protocol (OMP). The static route tracker periodically sends Internet Control Message Protocol (ICMP) ping probes to the configured endpoint IP address. If the endpoint is unreachable (no response to probes), the static route is excluded from the routing table and is not advertised to OMP, preventing traffic blackholing. You can configure backup routes with higher administrative distance to provide alternate paths.. This mechanism enhances route reliability and network stability in SD-WAN environments. The tracker sends periodic probes (ICMP echo requests, TCP, or UDP probes) to the static route's next-hop IP address.

- If the endpoint is unreachable, the static route is removed from the routing table and not advertised to OMP.
- Configure backup static routes with higher administrative distance for failover.
- Only one endpoint tracker is supported per static route per next-hop.
- IPv6 static routes are not supported for tracking.
- You can configure dual endpoint tracker groups to enhance probe reliability.
- This feature is supported on Cisco IOS XE Catalyst SD-WAN platforms such as ASR 1000, ISR 1000 and 4000, and CSR 1000 series routers.
- This feature ensures that static routes in service VPNs are advertised only when their next-hop endpoints are reachable. As a result, it prevents traffic blackholing and improves network resilience.

From Cisco IOS XE Catalyst SD-WAN Release 17.7.1a, you can configure TCP or UDP individual endpoint trackers and configure a tracker group with dual endpoints (using two trackers), and associate the trackers and tracker group to a static route. Dual endpoints help avoid false negatives that route unavailability might introduce.

Starting with Cisco IOS XE Catalyst SD-WAN Release 17.15.1a, Cisco SD-WAN Manager reports only UP/DOWN status changes. It does not report RTT value changes. This optimization improves efficiency in extensive networks.

Supported platforms

These devices support static route tracking for service VPNs:

- Cisco ASR 1000 Series Aggregated Services Routers
- Cisco ISR 1000 Series-Integrated Services Routers
- Cisco ISR 4000 Series Integrated Services Routers
- Cisco CSR 1000 Series Cloud Service Routers

Restrictions for IPv4 static route tracking

- Only one endpoint tracker is supported per static route per next-hop address.
- IPv6 static routes are not supported.
- To configure a static route with tracker:
 1. Delete any existing static route, if it is already configured without a tracker. Plan for any connectivity downtime that might occur during this step for static route advertisement.
 2. Configure a new static route with tracker using the same prefix and next-hop as the deleted static route.
- To add a new tracker after you reach maximum tracker limit per router:
 1. Delete an old tracker and attach the template to the device.
 2. Add a new tracker and attach the device to the template again.
- UDP tracker endpoint enabled with IP SLA UDP packet responder is supported only on Cisco IOS XE Catalyst SD-WAN devices.
- You cannot link the same endpoint-tracker to static routes in different VPNs. Endpoint-tracker is identified by a name and can be used for multiple static routes in a single VPN.

Configure tracker group using a configuration group

Before you begin

On the **Configuration > Configuration Groups** page, choose **SD-WAN** as the solution type.

Procedure

Step 1 From the Cisco SD-WAN Manager menu, choose **Configuration > Configuration Groups**.

Step 2 Create and configure a tracker group in a Service Profile.

Table 2: Tracker Group

Field	Description
Tracker Elements*	This field is displayed only if you chose Tracker Type as the Tracker Group . Add the existing interface tracker names, separated with a space. When you add this tracker to the template, the tracker group is associated with these individual trackers, and you can then associate the tracker group to an interface.

Field	Description
Tracker Boolean	This field is displayed only if you chose Tracker Type as the Tracker Group. Select AND or OR. OR is the default boolean operation. An OR ensures that the transport interface status is reported as active if either one of the associated trackers of the tracker group reports that the interface is active. If you select the AND operation, the transport-interface status is reported as active if both the associated trackers of the tracker group report that the interface is active.

What to do next

Also see [Deploy a configuration group](#).

Create a static route tracker

Before you begin

Use the **System Template** to create a tracker for static routes.

Delete existing static routes, if any, before you create a static route tracker. Configure a new static route tracker using the same prefix and next hop as the deleted static route.

Procedure

- Step 1** From Cisco SD-WAN Manager menu, choose **Configuration > Templates**.
- Step 2** Click **Feature Templates**.
- Step 3** Navigate to the **Cisco System** template for the device.
For information about creating a System template, see [Create System Template](#).
- Step 4** Click **Tracker**. Click **New Endpoint Tracker** to configure the tracker parameters.

Table 3: Tracker Parameters

Field	Description
Name	Name of the tracker. The name can be up to 128 alphanumeric characters.
Threshold	Wait time for the probe to return a response before declaring that the configured endpoint is down. The range is from 100 to 1000 milliseconds. The default is 300 milliseconds.

Field	Description
Interval	Time interval between probes to determine the status of the configured endpoint. The default is 60 seconds (1 minute). The range is from 20 to 600 seconds.
Multiplier	Number of times probes are sent before declaring that the endpoint is down. The range is from 1 to 10. The default is 3.
Tracker Type	From the drop-down, choose Global. From the Tracker Type field drop-down, choose Static Route. From Cisco IOS XE Catalyst SD-WAN Release 17.7.1a, you can configure a tracker group with dual endpoints on Cisco IOS XE Catalyst SD-WAN devices. You can associate this tracker group to a static route.
Endpoint Type	Choose endpoint type IP address. Note Configuring the tracker type Static Route using endpoint URL or endpoint DNS name is not supported.
End-Point Type: IP Address	IP address of the static route end point. This is the destination on the internet to which the router sends probes to determine the status of the route.

Step 5 Click **Add**.

Step 6 Click **Save**.

Complete all mandatory actions before saving the template.

Step 7 To create a tracker group, click **Tracker Groups > New Endpoint Tracker Groups** and configure the tracker parameters. Ensure that you have created two trackers to form a tracker group.

Table 4: Tracker Group Parameters

Fields	Description
Name	Name of the tracker group.
Tracker Type	From the drop-down, choose Global . From the Tracker Type field drop-down, choose Static Route . From Cisco IOS XE Catalyst SD-WAN Release 17.7.1a, you can configure a tracker group with dual endpoints on Cisco IOS XE Catalyst SD-WAN devices and associate this tracker group to a static route.
Tracker Elements	This field is displayed only if you chose Tracker-group as the tracker type. Add the existing interface tracker names (separated by a space). When you add this tracker to the template, the tracker group is associated with these individual trackers, and you can then associate the tracker group to a static route.

Fields	Description
Tracker Boolean	From the drop-down list, choose Global. This field is displayed only if you chose tracker-group as the Tracker Type. By default, the OR option is selected. Choose AND or OR. OR ensures that the static route status is reported as active if either one of the associated trackers of the tracker group report that the route is active. If you select AND, the static route status is reported as active if both the associated trackers of the tracker group report that the route is active.

Step 8 Click **Add**.

Step 9 Click **Save**.

Complete all mandatory actions before saving the template.

Configure a next hop static route with tracker

Procedure

Step 1 From the Cisco SD-WAN Manager menu, choose **Configuration** > **Templates**.

Step 2 Click **Feature Templates** and navigate to **Cisco VPN Template** for the device.

For information about creating a VPN template, see [Create VPN Template](#).

Step 3 Enter **Template Name** and **Description** as required.

Step 4 In Basic Configuration, by default, VPN is set to 0. Set a VPN value within (1–511, 513–65530) range for service VPNs, for service-side data traffic on Cisco IOS XE Catalyst SD-WAN devices.

You can configure static route tracker only on service VPNs.

Step 5 Click **IPv4 Route** and **New IPv4 Route**.

Step 6 In the **IPv4 Prefix** field, enter a value.

Step 7 Click **Next Hop**. Click **Add Next Hop** with **Tracker** and enter values for the fields listed in the table.

Parameter Name	Description
Address	Specify the next-hop IPv4 address.
Distance	Specify the administrative distance for the route.
Tracker	Enter the name of the gateway tracker to determine whether the next hop is reachable before adding that route to the route table of the device.

Parameter Name	Description
Add Next Hop with Tracker.	Enter the name of the gateway tracker with the next hop address to determine whether the next hop is reachable before adding that route to the route table of the device.

- Step 8** Click **Add** and **Save** to create the static route with the next-hop tracker.
You need to fill all the mandatory fields in the form to save the VPN template.

Monitor static route tracker configuration

To view information about a static tracker on a transport interface:

Procedure

- Step 1** From the Cisco SD-WAN Manager menu, choose **Monitor > Devices**.
Step 2 Choose a device from the list of devices.
Step 3 Click **Real Time**.
Step 4 From the **Device Options** drop-down list, choose **Endpoint Tracker Info**.

Configure static routes using CLI

These sections provide information about how to configure static routes using the CLI.

You can configure static route tracking using the Cisco SD-WAN Manager CLI Add-on feature templates and CLI device templates. For more information on configuring using CLI templates, see [CLI Templates](#).

Configure a static route tracker

```
Device# config-transaction
Device(config)# endpoint-tracker <tracker-name>
Device(config-endpoint-tracker)# tracker-type <tracker-type>
Device(config-endpoint-tracker)# endpoint-ip <ip-address>
Device(config-endpoint-tracker)# threshold <value>
Device(config-endpoint-tracker)# multiplier <value>
Device(config-endpoint-tracker)# interval <value>
Device(config-endpoint-tracker)# exit
Device(config)# track <tracker-name> endpoint-tracker
```

Configure a static route tracker with TCP port as the endpoint

```
Device# config-transaction
Device(config)# endpoint-tracker <tracker-name>
Device(config-endpoint-tracker)# tracker-type <tracker-type>
Device(config-endpoint-tracker)# endpoint-ip <ip-address> tcp <port-number>
```

```
Device(config-endpoint-tracker)# threshold <value>
Device(config-endpoint-tracker)# multiplier <value>
Device(config-endpoint-tracker)# interval <value>
Device(config-endpoint-tracker)# exit
Device(config)# track <tracker-name> endpoint-tracker
```

Configure a static route tracker with UDP port as the endpoint

```
Device# config-transaction
Device(config)# endpoint-tracker <tracker-name>
Device(config-endpoint-tracker)# tracker-type <tracker-type>
Device(config-endpoint-tracker)# endpoint-ip <ip-address> udp <port-number>
Device(config-endpoint-tracker)# threshold <value>
Device(config-endpoint-tracker)# multiplier <value>
Device(config-endpoint-tracker)# interval <value>
Device(config-endpoint-tracker)# exit
Device(config)# track <tracker-name> endpoint-tracker
```

Configure tracker groups

You can create tracker groups to probe static routes from Cisco IOS XE Catalyst SD-WAN Release 17.7.1a and Cisco vManage Release 20.7.1.

```
Device# config-transaction
Device(config)# endpoint-tracker <tracker-name1>
Device(config-endpoint-tracker)# tracker-type <tracker-type>
Device(config-endpoint-tracker)# endpoint-ip <ip-address> tcp <port-number>
Device(config-endpoint-tracker)# threshold <value>
Device(config-endpoint-tracker)# multiplier <value>
Device(config-endpoint-tracker)# interval <value>
Device(config-endpoint-tracker)# exit
Device(config)# track <tracker-name1> endpoint-tracker
```

```
Device# config-transaction
Device(config)# endpoint-tracker <tracker-name2>
Device(config-endpoint-tracker)# tracker-type <tracker-type>
Device(config-endpoint-tracker)# endpoint-ip <ip-address> udp <port-number>
Device(config-endpoint-tracker)# threshold <value>
Device(config-endpoint-tracker)# multiplier <value>
Device(config-endpoint-tracker)# interval <value>
Device(config-endpoint-tracker)# exit
Device(config)# track <tracker-name2> endpoint-tracker
```

```
Device(config)# endpoint-tracker <static-tracker-group>
Device(config-endpoint-tracker)# tracker-type tracker-group
Device(config-endpoint-tracker)# tracker-elements <tracker-name1> <tracker-name2>
Device(config-endpoint-tracker)# boolean {and | or}
Device(config-endpoint-tracker)# exit
Device(config)# track <static-tracker-group> endpoint-tracker
```

```
Device(config)# ip route vrf <vrf-name> <prefix> <mask> <nexthop-ipaddress>
<administrative-distance> track name <static-tracker-group>
```

**Note**

- Use the **ip route** command to bind a tracker or tracker group with a static route and to configure a backup route for administrative distance that is higher than the default value of 1.
- You can apply only one tracker to an endpoint.
- A tracker group can have a mix of endpoint trackers. For example, you can create a tracker group with an IP address tracker and UDP tracker.

Configuration examples static route tracking

Configure Tracker

This example shows how to configure a single static route tracker:

```
config-transaction
!
 endpoint-tracker tracker1
!
  tracker-type static-route
  endpoint-ip 10.1.1.1
  threshold 100
  multiplier 5
  interval 20
  exit
!
track tracker1 endpoint-tracker
!
ip route vrf 1 192.168.0.0 255.255.0.0 10.1.19.16 100 track name tracker1
```

This example shows how to configure a tracker with TCP port as endpoint:

```
config-transaction
!
 endpoint-tracker tcp-10001
!
  tracker-type static-route
  endpoint-ip 10.0.0.1 tcp 10001
  threshold 100
  interval 10
  multiplier 1
  exit
!
track tcp-10001 endpoint-tracker
!
ip route vrf 1 192.168.0.0 255.255.0.0 10.1.19.16 100 track name tcp-10001
```

This example shows how to configure a tracker with UDP port as endpoint:

```
config-transaction
!
 endpoint-tracker udp-10001
!
  tracker-type static-route
  endpoint-ip 10.0.0.1 udp 10001
```

```

        threshold    100
        interval     10
        multiplier    1
        exit
!
track udp-10001 endpoint-tracker
!
ip route vrf 1 192.168.0.0 255.255.0.0 10.1.19.16 100 track name udp-10001

```

Configure Tracker Groups

This example shows how to configure a tracker group with two trackers (two endpoints). You can create tracker groups to probe static routes.

```

config-transaction
!
endpoint-tracker tcp-10001
!
    tracker-type static-route
    endpoint-ip 10.1.1.1 tcp 10001
    threshold 100
    multiplier 5
    interval 20
    track tcp-10001 endpoint-tracker
!
endpoint-tracker udp-10002
!
    tracker-type static-route
    endpoint-ip 10.2.2.2 udp 10002
    threshold 100
    multiplier 5
    interval 20
    track udp-10002 endpoint-tracker
!
endpoint-tracker static-tracker-group
!
    tracker-type tracker-group
    tracker-elements tcp-10001 udp-10002
    boolean and
    track static-tracker-group endpoint-tracker
!
ip route vrf 1 192.168.0.0 255.255.0.0 10.1.19.16 100 track name static-tracker-group

```



Note

- You must configure an administrative distance when you are configuring through CLI templates.
- Use the **ip route** command to bind the tracker or tracker group with a static route and to configure a backup route for administrative distance when it is higher than the default value of 1.
- You can apply only one tracker to an endpoint.

Verify static route tracking configuration

Use these commands to verify if the configuration is committed. The sample configuration shows tracker definition for a static route tracker and its application to an IPv4 static route:

```
Device# show running-config | sec endpoint-tracker
endpoint-tracker tracker1
endpoint-ip 10.1.1.1
interval 60
multiplier 5
tracker-type static-route
endpoint-tracker tracker2
endpoint-ip 10.1.1.12
interval 40
multiplier 2
tracker-type static-route
track tracker2 endpoint-tracker
track tracker1 endpoint-tracker
```

Use this command to verify the IPv4 route:

```
Device# show running-config | inc ip route
ip route vrf 1 10.1.1.11 255.255.0.0 10.20.2.17 track name tracker2
ip route vrf 1 10.1.1.12 255.255.0.0 10.20.24.17 track name tracker1
```

The sample output from the **show endpoint-tracker static-route** command displaying individual static route tracker status:

```
Device# show endpoint-tracker static-route
Tracker Name      Status      RTT (in msec)  Probe ID
tcp-10001         UP          3              1
udp-10002         UP          1              6
```

The sample output from the **show endpoint-tracker tracker-group** command displaying tracker group status:

```
Device# show endpoint-tracker group
Tracker Name      Element trackers name      Status      RTT in msec  Probe ID
group-tcp-10001-udp-10002  tcp-10001, udp-10002      UP(UP AND UP)  5, 1          9, 10
```

The sample output from the **show endpoint-tracker records** command displaying tracker/tracker group configuration:

```
Device# show endpoint-tracker records
Record Name      Endpoint      EndPoint Type  Threshold(ms)  Multiplier
Interval(s)  Tracker-Type
group-tcp-10001-udp-10002  tcp-10001 AND udp-10002  N/A          N/A          N/A
N/A          static-tracker-group
tcp-10001      10.1.1.1      TCP          100          1
20          static-route
udp-10002      10.2.2.2      UDP          100          1
20          static-route
```

The sample output from the **show ip static route vrf** command:

```
Device# show ip static route vrf 1
Codes: M - Manual static, A - AAA download, N - IP NAT, D - DHCP,
       G - GPRS, V - Crypto VPN, C - CASA, P - Channel interface processor,
       B - BootP, S - Service selection gateway
       DN - Default Network, T - Tracking object
       L - TL1, E - OER, I - iEdge
       D1 - Dot1x Vlan Network, K - MWAM Route
       PP - PPP default route, MR - MRIPv6, SS - SSLVPN
       H - IPe Host, ID - IPe Domain Broadcast
       U - User GPRS, TE - MPLS Traffic-eng, LI - LIIN
       IR - ICMP Redirect, Vx - VXLAN static route
       LT - Cellular LTE, Ev - L2EVPN static route
Codes in []: A - active, N - non-active, B - BFD-tracked, D - Not Tracked, P - permanent,
-T Default Track
Codes in (): UP - up, DN - Down, AD-DN - Admin-Down, DL - Deleted
```

Verify static route tracking configuration

```
Static local RIB for 1  
T 192.168.0.0 [1/0] via 10.1.19.16 [A]
```