



About this documentation

- [Document Purpose, on page 1](#)
- [Warnings and notices, on page 1](#)

Document Purpose

This configuration guide explains how to configure Active Discovery in Cisco Cyber Vision and gives details on expected results.

This documentation is applicable to **Cisco Cyber Vision Center Sensor/Center, Release 5.2.x**.

Active Discovery is **available on** the following devices:

- Cisco Catalyst IE3300 10G Rugged Series Switch
- Cisco Catalyst IE3400 Rugged Series Switch
- Cisco Catalyst IE9300 Rugged Series Switch
- Cisco Catalyst 9300 Series Switch
- Cisco Catalyst 9400 Series Switch
- Cisco IC3000 Industrial Compute Gateway
- Cisco IR8340 Integrated Services Router Rugged
- Cisco Center Active Discovery Interface

Warnings and notices

This manual contains notices you have to observe to ensure your personal safety as well as to prevent damage to property.

The notices referring to your personal safety and to your property damage are highlighted in the manual by a safety alert symbol described below. These notices are graded according to the degree of danger.

**Warning**

Indicates risks that involve industrial network safety or production failure that could possibly result in personal injury or severe property damage if proper precautions are not taken.

**Important**

Indicates risks that could involve property or equipment damage and minor personal injury if proper precautions are not taken.

**Note**

Indicates important information on the product described in the documentation to which attention should be paid.