

## **Hardware front view**

• Hardware front view, on page 1

## **Hardware front view**

Before starting, take a moment to note the following parts you're going to use during the procedure.

Cisco Cisco IR1101 Integrated Services Router Rugged:



- 1x RJ45 10/100/1000 BaseT connector (the one on the left) (1)
- 4x RJ45 10/100 BaseT connector (the ones on the right) (1)
- SFP fiber port (2)
- mini-USB console connector (3)

Hardware front view