



Preface

This preface includes the following sections:

- [Audience, page iii](#)
- [Organization, page iii](#)
- [Related Documentation, page iii](#)
- [Obtain Documentation and Submit a Service Request, page iv](#)

Audience

This troubleshooting guide is designed for users who are responsible for troubleshooting issues that arise in the Cisco Firepower eXtensible Operating System.

Organization

This reference guide is organized into the following parts and chapters:

- Cisco Firepower eXtensible Operating System Faults
 - [Chapter 1, “Introduction to Cisco Firepower eXtensible Operating System Faults”](#)
 - [Chapter 2, “FXOS Faults”](#)
 - [Chapter 3, “FSM Faults”](#)
 - [Chapter 4, “Troubleshooting Transient Faults”](#)
- Cisco Firepower eXtensible Operating System SEL Messages
 - [Chapter 5, “Introduction to System Event Log Messages”](#)
 - [Chapter 6, “Baseboard Management Controller Messages”](#)

Related Documentation

A roadmap that lists all documentation for the Cisco Firepower eXtensible Operating System is available at the following URL:

<http://www.cisco.com/go/firepower9300-docs>

Obtain Documentation and Submit a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see [What's New in Cisco Product Documentation](#).

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the [What's New in Cisco Product Documentation RSS feed](#). The RSS feeds are a free service.