

CLI Error Messages

This appendix lists the CLI error messages and CLI validation error messages. It contains the following sections:

- CLI Error Messages, page D-1
- CLI Validation Error Messages, page D-6

CLI Error Messages

Table D-1 describes CLI error messages.

Table D-1	CLI Error Messages
-----------	--------------------

Error Message	Reason	Command
getVirtualSensorStatistics : Analysis Engine is busy	Analysis Engine is busy because the virtual sensor has not finished initializing.	show statistics virtual-sensor
getVirtualSensorStatistics : Analysis Engine is busy rebuilding regex tables. This may take a while.	Analysis Engine is busy building cache files immediately after the sensor has been imaged.	show statistics virtual-sensor
editConfigDeltaSignatureDefi nition : Analysis Engine is busy rebuilding regex tables. This may take a while.	Analysis Engine is busy building cache files immediately after the sensor has been imaged.	service signature-definition
Invalid command received.	The .conf file and code are out of synchronization, which should never occur in the field.	All commands
Invalid port number was entered.	An out-of-range port number was entered in URI.	copy, upgrade, show tech-support
Invalid scheme was entered.	Internal tables are out of synchronization, which should never occur in the field.	copy, upgrade, show tech-support
Unknown scheme was entered.	An invalid scheme was entered in URI.	copy, upgrade, show tech-support

Error Message	Reason	Command
The filename <file> is not a valid upgrade file type.</file>	Attempt to install the wrong file for your platform and version.	upgrade
idsPackageMgr: digital signature of the update was not valid	The signature update or service pack is corrupt. Contact TAC.	upgrade
Cannot create a new event-action-rules configuration. "rules0" is currently the only configuration allowed.	An invalid logical instance name was entered for service event action rules. ¹	service event-action-rules
Cannot create a new signature-definition configuration. "sig0" is currently the only configuration allowed.	An invalid logical instance name was entered for service signature definition. ²	service signature-definition
Cannot create a new anomaly-detection configuration. "ad0" is currently the only configuration allowed.	An invalid logical instance name was entered for service anomaly detection. ³	service anomaly-detection
This node is Threat Profile tuned, reverting to default entirely may cause certain unexpected results. Please use ''show settings'' to know the default value for a parameter and set it to its default value.	Defaulting a particular signature that is both threat-profile tuned and custom tuned is not allowed.	service signature-definition
Configuration instance ""sig12"" does not exit. Use the global configuration command ""service signature-definition"" to create a new instance.	Cannot add a threat profile for a signature instance that does not exist.	service threat-profile
User does not exist.	The administrator is attempting to change the password for a username that does not exist in the system.	password
Incorrect password for user account.	The user entered an invalid password while attempting to change the password.	password
Empty user list.	The curUserAccountList.xml file does not contain any entries, which should never occur in the field.	username
User already exists.	An attempt to create a user that already exists in the system was made.	username
Cannot communicate with system processes. Please contact your system administrator.	One or more required applications is not responding to control transactions.	All commands

Table D-1 CLI Error Messages (continued)

Error Message	Reason	Command
Source and Destination are the same.		сору
Backup config was missing.	The user attempted to copy or erase the backup config file but no backup config file has been generated.	copy erase
Could not load CLI configuration files, can not complete request.	The .conf files could not be located, which should never occur in the field.	сору
Error writing to <url>.</url>	The URL specified in the destination could not be written.	сору
Error reading from <url>.</url>	The URL specified in the source could not be read.	сору
Packet-file does not exist.	The user attempted to copy or erase the packet-file but no packet-file has been captured.	copy erase
No downgrade available.	The user attempted to downgrade a system that has not been upgraded.	downgrade
No packet-file available.	The user attempted to display the file-info or the packet-file but no packet-file exists.	packet
Another user is currently capturing into the packet-file. Please try again later.	_	packet capture
Another CLI client is currently displaying packets from the interface.	The user must wait for the other CLI session to terminate display before this will be available. Multiple users may display the command control interface simultaneously.	packet display
Log does not exist.	The user attempted to copy or display an iplog that does not exist.	copy iplog packet display iplog
The requested IPLOG is not complete. Please try again after the IPLOG status is 'completed.'	The user attempted to copy or display an iplog that is not complete.	copy iplog
Error: Log file exists but an error occurred during read. The log file might have been overwritten.	The user was displaying or copying an iplog file that was overwritten. The partial file contents should still be viewable.	copy iplog
Error: Iplog transfer failed. The copied log file is incomplete.	Iplog transfer has failed. There may or may not be any partial copied file at remote server.	copy iplog
Could not create pipe /usr/cids/idsRoot/tmp/ pipe_cliPacket. <pid>.tmp</pid>	Could not open pipe for sending iplog file. This indicates a space or resource limitation, which should not occur in the field.	copy iplog

Table D-1 CLI Error Messages (continued)

Error Message	Reason	Command
Error: The log file might have been overwritten while the copy was in progress. The copied log file may be viewable but is incomplete.	The iplog was overwritten while it was being copied off the sensor.	copy iplog
Could not read license file.	The license file was copied but cannot be opened.	copy license-key
Could not write the temporary license file location used to copy the file off the box.	Could not open the temporary storage location /usr/cids/idsRoot/tmp/ips.lic. This indicates a space issue, which should not occur in the field.	copy license-key
Virtual sensor name does not exist.	The user attempted to start or stop an iplog on a non-existent virtual sensor.	iplog
You do not have permission to terminate the requested CLI session.	An operator or viewer user attempted to terminate a CLI session belonging to another user.	clear line
Invalid CLI ID specified, use the 'show users all' command to view the valid CLI session IDs.	The user attempted to cancel a CLI session that does not exist.	clear line
The maximum allowed CLI sessions are currently open, please try again later.	Operator or viewer user attempted to log in when the maximum number of CLI sessions were already open.	initial login
The maximum allowed CLI sessions are currently open, would you like to terminate one of the open sessions?	Administrator user attempted to log in when the maximum number of CLI sessions were already open.	initial login
Can not communicate with system processes. Please contact your system administrator.	The CLI cannot contact the applications on the sensor to retrieve start-up information. This is a fatal error that should never happen. The user has to log in to the service account and manually reboot the sensor.	initial login
The instance cannot be removed. Instance assigned to virtual sensor name.	The user attempted to remove a configuration instance that is currently assigned to a virtual sensor. Use the default service command to reset the configuration setting to default.	no service component instance
Insufficient disk space to complete request.	Not enough disk space is available to create a new instance of a configuration file.	copy instance service <i>component instance</i>

Table D-1 CLI Error Messages (continued)

1. This error only occurs on platforms that do not support virtual policies.

2. This error only occurs on platforms that do not support virtual policies.

3. This error only occurs on platforms that do not support virtual policies.

CLI Validation Error Messages

Table D-2 describes the validation error messages.

Table D-2Validation Error Messages

Error Message	Reason/Location
Interface 'name' has not been subdivided.	The physical interface or inline interface <i>name</i> subinterface type is none (service interface submode).
Interface `name' subinterface `num' does not exist.	The physical interface <i>name</i> has been subdivided into inline VLAN pairs, but the specified subinterface number does not exist (service interface submode).
Interface 'name' is the command-control interface.	The physical interface <i>name</i> is the command and control interface (service interface submode).
Interface 'name' has been subdivided.	The physical interface <i>name</i> subinterface type is inline VLAN pair or VLAN group. Or the inline interface <i>name</i> subinterface type is VLAN group (service interface submode).
Interface `name' is assigned to inline-interfaces `inlinename.'	The physical interface <i>name</i> is assigned to an inline interface entry's interface1 or interface2 (service interface submode).
Vlan 'vlannum' is assigned to subinterface 'subnum.'	The VLAN <i>vlannum</i> is already assigned to a different subinterface <i>subnum</i> entry's vlan1 or vlan2 (service interface submode).
Vlan range `vlanrange' overlaps with vlans assigned to subinterface `subnum.'	The VLAN range <i>vlanrange</i> contains values that are already used in a different subinterface <i>subnum</i> entry's <i>vlans range</i> (service interface submode).
Unassigned vlans already assigned to subinterface `subnum.'	Unassigned VLANs have already been selected in a different subinterface <i>subnum</i> entry.
Inline-interface 'inlinename' does not exist.	The inline interface <i>inlinename</i> does not exist (service interface submode).
The default-vlans for the selected interfaces do not match. interface1, 'name' default-vlan is 'vlannum,' interface2, 'name' default-vlan is 'vlannum.'	The user is trying to change the subinterface type of an inline interface to VLAN group, but the default VLANs for the two interfaces assigned to the inline interface do not match (service interface submode).
interface1 and interface2 must be set before the logical interface can be divided into subinterfaces.	The user is trying to change the subinterface type of an inline interface to VLAN group, but has not set both interface1 and interface2 (service interface submode).
Interface 'name' has not been subdivided into inline-vlan-pairs.	The physical interface <i>name</i> subinterface type is not inline VLAN pair (service interface submode).

Error Message	Reason/Location
Interface already assigned to virtual sensor 'vsname.'	The interface and optional sub-interface being added to the virtual sensor entry physical interface set has already been assigned to another virtual sensor entry.
The instance cannot be removed. Instance assigned to virtual sensor 'vsname.'	The user is trying to remove a signature definition, event action rules, or anomaly detection configuration file that is currently in use by virtual sensor <i>vsname</i> .

Table D-2 Validation Error Messages (continued)

