



INDEX

F

Fibre Channel write acceleration

- default settings [4-2](#)
- enabling [4-2](#)
- estimating number of write buffers [4-1](#)
- licensing [4-1](#)
- modifying number of write buffers [4-2](#)

default settings [2-4, 3-3](#)

enabling [3-4](#)

SCSI LUNs

discovering targets [2-3, 3-3, 4-2](#)

SSMs

disabling Intelligent Storage Services (procedure) [2-5](#)

SCSI flow services [2-1 to 2-4, ?? to 3-3](#)

SCSI flow statistics [2-1 to 2-4, ?? to 3-3](#)

I

Intelligent Storage Services

- disabling (procedure) [2-5](#)
- disabling with force option [2-6](#)
- SCSI flow services [2-1 to 2-4, ?? to 3-3](#)
- SCSI flow statistics [2-1 to 2-4, ?? to 3-3](#)

S

SCSI flow configuration clients

description [2-3, 3-3](#)

SCSI flow data path support

description [2-3, 3-3](#)

SCSI flow managers

description [2-3, 3-3](#)

SCSI flow services

- configuring (procedure) [2-5](#)
- default settings [2-4, 3-3](#)
- functional architecture (figure) [2-2](#)
- SCSI flow configuration clients [2-3, 3-3](#)
- SCSI flow data path support [2-3, 3-3](#)
- SCSI flow managers [2-3, 3-3](#)

SCSI flow statistics

Send documentation comments to dcnm-san-docfeedback@cisco.com