

*Send documentation comments to [mdfsfeedback-doc@cisco.com](mailto:mdfsfeedback-doc@cisco.com)*



## INDEX

---

### B

boot variables  
    synchronizing [2-2](#)

---

### D

documentation  
    related documents [i-viii](#)

---

### H

high availability  
    automatic synchronization [2-3](#)  
    description [2-1](#)  
    process restartability [2-1](#)  
    supervisor module switchover mechanism [2-1](#)  
    synchronizing supervisor modules [2-2](#)

---

### R

redundancy states  
    value descriptions [2-3](#)

---

### S

software images  
    synchronizing [2-2](#)  
standby supervisor modules  
    monitoring [1-1](#)  
    synchronizing [2-2](#)  
supervisor modules  
    high availability [1-1](#)

manual switchovers [2-2](#)  
standby state [2-4](#)  
state descriptions [2-3](#)  
switchover mechanisms [2-1](#)  
synchronizing [2-2](#)  
switches  
    internal states [2-4](#)  
switchovers  
    guidelines [2-2](#)  
    initiating manually [2-2](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***