INDEX

Symbols

^Z 2-4

C

CLI
command modes 2-2
command prompt 2-1
setting delay time 2-13
CLI variables
persistent variables 2-10
session-only variables 2-9
system-defined variables 2-11
using in command scripts 2-12
command form
no 2-8
command modes
global configuration 2-3
summary table 2-5
user EXEC 2-3
commands
execution 2-3
command scripts
using CLI variables 2-12
context-sensitive help
syntax checking 2-13

D

documentation
additional publications 1-iii

E

end command 2-4
EXEC
commands
user level 2-3
exit 2-4

G

global configuration mode
description 2-3
entering 2-3
exiting 2-3
summary 2-5

I

interface configuration mode
summary 2-5

M

modes
See command modes

N

no command form 2-8

P

privileged EXEC mode

Send document comments to nexus1k-docfeedback@cisco.com.

summary 2-5
prompts
system 2-5

R

related documents 1-iii
roles
network administrator 1-4
server administrator 1-4

S

syntax checking
See context-sensitive help

T

time
setting delay in CLI 2-13

U

user EXEC mode
commands 2-3
description 2-3