



New or Changed Commands

This section lists the new and changed information in this document by release and where it is located.

This section includes the following topics:

- [New and Changed Information in Release 4.2\(1\)SP\(4\)](#).
- [New and Changed Information in Release 4.2\(1\)SP1\(3\)](#).

[Table 1](#) lists and describes new and changed commands in Release 4.2(1)SP(4).

Table 1 *New and Changed Information in Release 4.2(1)SP(4)*

New or Changed Command	Added	Changed	Removed	Feature	Configuration Document
control uplink	X			Uplinks	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
channel-group	X			Uplinks	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
interface GigabitEthernet	X			Uplinks	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
interface PortChannel	X			Uplinks	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
interface uplink	X			Uplinks	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
management uplink	X			Uplinks	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
network-uplink type		X		Uplinks	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>

Send document comments to nexus1k-docfeedback@cisco.com.

Table 1 New and Changed Information in Release 4.2(1)SP(4) (continued)

New or Changed Command	Added	Changed	Removed	Feature	Configuration Document
native VLAN	X			Native VLAN	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
show network port-channel summary	X			Uplinks	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>

Table 2 lists and describes new and changed commands in Release 4.2(1)SP(3).

Table 2 New and Changed Information in Release 4.2(1)SP1(3)

New or Changed Command	Added	Changed	Removed	Feature	Configuration Document
export	X			Virtual Service Blade	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
import	X			Virtual Service Blade	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
interface VsbEthernet	X			Virtual Service Blade	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
show network cdp neighbors	X			CDP	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
show network cdp neighbors detail	X			CDP	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
show virtual-service-blade		X		Virtual Service Blade	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>
shutdown (interface)	X			Virtual Service Blade	<i>Cisco Nexus Virtual Services Appliance Software Configuration Guide, Release 4.2(1)SP1(5.1)</i>