



X Commands

- [xml](#), on page 2
- [xml](#), on page 3
- [xml server max-session](#), on page 4
- [xml server terminate session](#), on page 5
- [xml server timeout](#), on page 6
- [xml server validate](#), on page 7
- [xml server xml-debug](#), on page 8
- [xmlin](#), on page 9
- [xmlin](#), on page 10
- [xmlin](#), on page 11
- [xmlin](#), on page 12
- [xmlout](#), on page 13

xml

| xml

Syntax Description

	Pipe command output to filter
xml	output in xml format (according to .xsd definitions)

Command Mode

- /output

xml

| xml

Syntax Description

	Pipe command output to filter
xml	output in xml format (according to .xsd definitions)

Command Mode

- /output

xml server max-session

[no] xml server max-session <number>

Syntax Description

no	(Optional) Negate a command or set its defaults
xml	xml agent
server	xml agent server
max-session	configure maximum number of xml sessions allowed
<i>number</i>	number of the sessions

Command Mode

- /exec/configure

xml server terminate session

xml server terminate session <session_id>

Syntax Description

xml	xml agent
server	xml agent server
terminate	command to terminate an XML session
session	terminate an XML session
<i>session_id</i>	sessions number

Command Mode

- /exec

xml server timeout

[no] xml server timeout <value> [<session_id>]

Syntax Description

no	(Optional) Negate a command or set its defaults
xml	xml agent
server	xml agent server
timeout	configure xml agent session timeout
<i>value</i>	timeout in seconds
<i>session_id</i>	(Optional) xml agent session id

Command Mode

- /exec/configure

xml server validate

[no] xml server validate { all | <session_id> }

Syntax Description

no	(Optional) Negate a command or set its defaults
xml	xml agent
server	xml agent server
validate	command to validate an XML session
all	all sessions
<i>session_id</i>	session number

Command Mode

- /exec/configure

xml server xml-debug

[no] xml server xml-debug

Syntax Description

no	(Optional) Negate a command or set its defaults
xml	xml agent
server	xml server
xml-debug	xml server xml-debug

Command Mode

- /exec/configure

xmlin

| xmlin

Syntax Description

	Pipe command output to filter
xmlin	Convert CLI show commands to their XML formats

Command Mode

- /output

xmlin

xmlin

Syntax Description

xmlin	Convert CLI commands to their XML formats
-------	-------------------------------------------

Command Mode

- /exec

xmlin

xmlin

Syntax Description

xmlin	Convert CLI commands to their XML formats
-------	-------------------------------------------

Command Mode

- /exec

xmlin

| xmlin

Syntax Description

	Pipe command output to filter
xmlin	Convert CLI show commands to their XML formats

Command Mode

- /output

xmlout

| xmlout

Syntax Description

	Pipe command output to filter
xmlout	output in xml format (according to the latest .xsd version)

Command Mode

- /output

