

Send comments to nexus5k-docfeedback@cisco.com



W Commands

This chapter describes the basic Cisco NX-OS system commands that begin with W.

Send comments to nexus5k-docfeedback@cisco.com

write erase

To erase configurations in persistent memory areas, use the **write erase** command.

```
write erase [boot | debug]
```

| Syntax Description | boot | (Optional) Erases only the boot configuration. |
|--------------------|-------|---|
| | debug | (Optional) Erases only the debug configuration. |

Command Default Erases all configuration in persistent memory.

Command Modes EXEC mode

| Command History | Release | Modification |
|-----------------|--------------|------------------------------|
| | 4.0(0)N1(1a) | This command was introduced. |

Usage Guidelines You can use this command to erase the startup configuration in the persistent memory when information is corrupted or otherwise unusable. Erasing the startup configuration returns the switch to its initial state.

Examples This example shows how to erase the startup configuration:

```
switch# write erase
```

This example shows how to erase the debug configuration in the persistent memory:

```
switch# write erase debug
```

| Related Commands | Command | Description |
|------------------|------------------------------------|--|
| | copy running-config startup-config | Copies the running configuration to the startup configuration. |
| | show running-config | Displays the startup configuration. |