



M Commands

This chapter describes the Cisco NX-OS interface commands that begin with M.

management

To configure a switch virtual interface (SVI) that should be used for in-band management, use the **management** command. To remove the in-band management access to a VLAN interface IP address, use the **no** form of this command.

management

no management

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Interface configuration mode
Switch profile configuration mode

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines You can use this command on a VLAN interface.

Examples This example shows how to configure a VLAN interface to allow in-band management access:

```
switch# configure terminal
switch(config)# interface vlan 5
switch(config-if)# management
switch(config-if)#
```

This example shows how to remove the in-band management access to a VLAN interface:

```
switch# configure terminal
switch(config)# interface vlan 5
switch(config-if)# no management
switch(config-if)#
```

Command	Description
show running-config interface	Displays the running configuration information for an interface.
