



## New and Changed Information

---

This chapter provides release-specific information for each new and changed feature in the *Cisco Nexus 6000 Series NX-OS Multicast Routing Configuration Guide, Release 7.x*. The latest version of this document is available at the following Cisco website:

[http://www.cisco.com/en/US/partner/products/ps12806/products\\_installation\\_and\\_configuration\\_guides\\_list.html](http://www.cisco.com/en/US/partner/products/ps12806/products_installation_and_configuration_guides_list.html)

To check for additional information about Cisco NX-OS Release 7.x, see the *Cisco Nexus 6000 Series NX-OS Release Notes, Release 7.x* available at the following Cisco website:

[http://www.cisco.com/en/US/products/ps12806/prod\\_release\\_notes\\_list.html](http://www.cisco.com/en/US/products/ps12806/prod_release_notes_list.html)

**Table 1** summarizes the new and changed features for the *Cisco Nexus 6000 Series NX-OS Multicast Routing Configuration Guide, Release 7.x*, and tells you where they are documented.

**Table 1** *New and Changed Features for Release 7.x*

<b>Feature</b>	<b>Description</b>	<b>Changed in Release</b>	<b>Where Documented</b>
PIM SSM on vPC	Added support for PIM SSM on vPC	7.3(0)N1(1)	Chapter 1, “Configuring SSM,”
ip pim spt-threshold infinity command	This command was introduced for PIM.	7.0(0)N1(1)	Chapter 1, “Configuring PIM,” Configuring PIM Sparse Mode, page 13

