



Commands with XML/JSON Support

- [XML Support for Show Commands, on page 2](#)

XML Support for Show Commands

Table 1:

| Show Commands | XML Support |
|--|-------------|
| show aaa accounting | yes |
| show aaa authentication | yes |
| show aaa authentication login | yes |
| show aaa authentication login ascii-authentication | yes |
| show aaa authentication login error-enable | yes |
| show aaa authentication login invalid-username-log | yes |
| show aaa authorization | yes |
| show aaa bypass-user | yes |
| show aaa client radius statistics | yes |
| show aaa groups | yes |
| show aaa local user blocked | yes |
| show aaa server radius statistics | yes |
| show aaa user default-role | yes |
| show access-list | yes |
| show access-list database | yes |
| show access-list resource | yes |
| show access-lists | yes |
| show accounting log | yes |
| show accounting log all | yes |
| show accounting log last-index | yes |
| show accounting log nvram | yes |
| show accounting log nvram last-index | yes |
| show accounting log nvram start-seqnum | yes |
| show accounting log start-seqnum | yes |
| show acl status | yes |

| Show Commands | XML Support |
|------------------------------------|--------------------|
| show amt process | yes |
| show amt vrf all | yes |
| show archive log config | yes |
| show arp access-lists | yes |
| show background | yes |
| show banner exec | yes |
| show banner motd | yes |
| show bash-shell | yes |
| show bfd addrmap | yes |
| show bfd clients | yes |
| show bfd discrmap | yes |
| show bfd intfipmap | yes |
| show bfd neighbors | yes |
| show bfd scalar | yes |
| show bfd session | yes |
| show bfd-app session status | no |
| show bgp | no |
| show bgp | yes |
| show bgp bmp server | yes |
| show bgp community | yes |
| show bgp convergence | yes |
| show bgp convergence private | no |
| show bgp dampening dampened | yes |
| show bgp dampening flap-statistics | yes |
| show bgp dampening parameters | yes |
| show bgp event-history | no |
| show bgp evi | yes |
| show bgp extcommunity | yes |

| Show Commands | XML Support |
|------------------------------------|-------------|
| show bgp l3vpn | yes |
| show bgp neighbors | yes |
| show bgp neighbors commands | yes |
| show bgp neighbors flap-statistics | yes |
| show bgp neighbors paths | yes |
| show bgp paths | yes |
| show bgp peer | yes |
| show bgp peer-template | yes |
| show bgp prefix-list | yes |
| show bgp private | no |
| show bgp private attr | no |
| show bgp private damp | no |
| show bgp private debug history | no |
| show bgp process | yes |
| show bgp received-paths | yes |
| show bgp regexp | yes |
| show bgp self-originated | yes |
| show bgp sessions | yes |
| show bgp statistics | yes |
| show bgp summary | yes |
| show boot | yes |
| show boot auto-copy | yes |
| show boot auto-copy list | yes |
| show boot current | yes |
| show boot mode | yes |
| show boot order | yes |
| show boot timings | no |
| show boot variables | yes |

| Show Commands | XML Support |
|---|--------------------|
| show callhome | yes |
| show callhome destination-profile | yes |
| show callhome destination-profile profile | yes |
| show callhome destination-profile profile CiscoTAC-1 | yes |
| show callhome destination-profile profile full-txt-destination | yes |
| show callhome destination-profile profile short-txt-destination | yes |
| show callhome transport | yes |
| show callhome transport-email | yes |
| show callhome user-def-cmds | yes |
| show catena | yes |
| show catena analytics | yes |
| show cdp | yes |
| show cdp all | yes |
| show cdp global | yes |
| show cdp neighbors | yes |
| show cdp neighbors detail | yes |
| show cdp traffic interface2 | yes |
| show cdp traffic interface2 all | yes |
| show cfs application | yes |
| show cfs lock | yes |
| show cfs merge status | yes |
| show cfs peers | yes |
| show cfs regions | yes |
| show cfs status | yes |
| show checkpoint | yes |
| show checkpoint summary | yes |
| show class-map | yes |
| show class-map type control-plane | yes |

| Show Commands | XML Support |
|---|-------------|
| show class-map type network-qos | yes |
| show cli alias | yes |
| show cli dynamic integers | yes |
| show cli dynamic strings | yes |
| show cli dynamic-cmd | no |
| show cli history | no |
| show cli interface table | no |
| show cli list | no |
| show cli syntax | no |
| show cli variables | yes |
| show clock | yes |
| show config-profile | yes |
| show config-profile applied | yes |
| show config-replace log exec | yes |
| show config-replace status | yes |
| show config-template | yes |
| show configuration session | yes |
| show configuration session global-info | yes |
| show configuration session status | yes |
| show configuration session summary | yes |
| show consistency-checker copp | no |
| show consistency-checker egress-xlate private-vlan | no |
| show consistency-checker fex-interfaces fex | no |
| show consistency-checker forwarding ipv6 | yes |
| show consistency-checker forwarding show forwarding inconsistency | yes |
| show consistency-checker forwarding single-route ipv4 vrf | no |
| show consistency-checker gwmacdb | no |
| show consistency-checker hardware-telemetry inband brief | no |

| Show Commands | XML Support |
|---|-------------|
| show consistency-checker hardware-telemetry postcard brief | no |
| show consistency-checker kim | no |
| show consistency-checker kim interface | no |
| show consistency-checker l2 multicast group source vlan | no |
| show consistency-checker l2-tahoe mac-address | no |
| show consistency-checker l2-tahoe module | no |
| show consistency-checker l2-tahoe switchport interface | no |
| show consistency-checker l3 multicast source vrf | no |
| show consistency-checker l3-interface module | no |
| show consistency-checker link-state fabric-ieth | no |
| show consistency-checker link-state module | no |
| show consistency-checker membership port-channels | no |
| show consistency-checker membership vlan | no |
| show consistency-checker pacl extended ingress ip interface | no |
| show consistency-checker pacl extended ingress ip module | no |
| show consistency-checker pacl extended ingress ipv6 interface | no |
| show consistency-checker pacl extended ingress ipv6 module | no |
| show consistency-checker pacl extended ingress mac interface | no |
| show consistency-checker pacl extended ingress mac module | no |
| show consistency-checker pacl module | no |
| show consistency-checker pacl port-channels | no |
| show consistency-checker port-state | no |
| show consistency-checker port-state fabric-ieth | no |
| show consistency-checker racl extended egress ip interface | no |
| show consistency-checker racl extended egress ipv6 interface | no |
| show consistency-checker racl extended ingress ip interface | no |
| show consistency-checker racl extended ingress ip module | no |
| show consistency-checker racl extended ingress ipv6 interface | no |

| Show Commands | XML Support |
|--|-------------|
| show consistency-checker racl extended ingress ipv6 module | no |
| show consistency-checker racl module | no |
| show consistency-checker racl port-channels | no |
| show consistency-checker racl svi interface | no |
| show consistency-checker segment-routing mpls ip mask vrf | no |
| show consistency-checker selective-qinq | no |
| show consistency-checker selective-qinq interface | no |
| show consistency-checker stp-state vlan | no |
| show consistency-checker vacl | no |
| show consistency-checker vacl extended ingress ip vlan | no |
| show consistency-checker vacl extended ingress ipv6 vlan | no |
| show consistency-checker vacl extended ingress mac vlan | no |
| show consistency-checker vpc | no |
| show consistency-checker vxlan config-check | no |
| show consistency-checker vxlan flood_list | no |
| show consistency-checker vxlan infra | no |
| show consistency-checker vxlan l2 module | no |
| show consistency-checker vxlan l3 vrf start | no |
| show consistency-checker vxlan mh mac-addresses | no |
| show consistency-checker vxlan mh pathlist | no |
| show consistency-checker vxlan pv | no |
| show consistency-checker vxlan qinq-qinvni | no |
| show consistency-checker vxlan selective-qinvni | no |
| show consistency-checker vxlan selective-qinvni interface | no |
| show consistency-checker vxlan vlan | no |
| show consistency-checker vxlan xconnect | no |
| show controller accounting log | no |
| show copp diff profile profile2 | no |

| Show Commands | XML Support |
|---|-------------|
| show copp profile | yes |
| show copp status | yes |
| show copyright | yes |
| show cores | yes |
| show crypto ca certificates | yes |
| show crypto ca certstore | yes |
| show crypto ca crl | yes |
| show crypto ca remote-certstore | yes |
| show crypto ca trustpoints | yes |
| show crypto ca trustpool | yes |
| show crypto ca trustpool last download status | yes |
| show crypto ca trustpool policy | yes |
| show crypto certificatemap | yes |
| show crypto key mypubkey rsa | yes |
| show crypto ssh-auth-map | yes |
| show cts | yes |
| show current | no |
| show dampening interface | yes |
| show diagnostic bootup level | yes |
| show diagnostic content module | yes |
| show diagnostic description module test all | yes |
| show diagnostic events | yes |
| show diagnostic ondemand setting | yes |
| show diagnostic result module | yes |
| show diagnostic result module all | yes |
| show diagnostic simulation module | yes |
| show diagnostic status module | yes |
| show diff rollback-patch | yes |

| Show Commands | XML Support |
|--|-------------|
| show dot1q-tunnel | yes |
| show dot1q-tunnel interface | yes |
| show dot1x | yes |
| show dot1x all | yes |
| show dot1x all details | yes |
| show dot1x all statistics | yes |
| show dot1x all summary | yes |
| show dot1x interface | yes |
| show dot1x interface client statistics | yes |
| show dot1x interface client statistics address | yes |
| show dot1x supplicant interface | no |
| show ecp | yes |
| show elam report | no |
| show email | yes |
| show encryption service stat | yes |
| show environment | yes |
| show errdisable detect | yes |
| show errdisable flap | no |
| show evb | yes |
| show evb hosts | yes |
| show evb vsi | yes |
| show event manager environment | yes |
| show event manager event-types | yes |
| show event manager events action-log | yes |
| show event manager history events | yes |
| show event manager policy-state | yes |
| show event manager script system | yes |
| show event manager system-policy | yes |

| Show Commands | XML Support |
|--------------------------------------|-------------|
| show fabric database dci | yes |
| show fabric database host | yes |
| show fabric database host statistics | yes |
| show fabric database host summary | yes |
| show fabric database profile-map | yes |
| show fabric database static-host | yes |
| show fabric database statistics | yes |
| show fabric forwarding host-db | yes |
| show fabric forwarding ip local | yes |
| show fabric forwarding ipv6 local | yes |
| show fabric multicast | yes |
| show fabric multicast event-history | no |
| show fabric multicast globals | yes |
| show fabric multicast ipv4 l2 vni | yes |
| show fabric multicast ipv4 rp | no |
| show fabric multicast statistics | no |
| show fabric multicast vrf | yes |
| show fc2 bind | yes |
| show fc2 classf | yes |
| show fc2 exchange | yes |
| show fc2 exchresp | yes |
| show fc2 flogi | yes |
| show fc2 nport | yes |
| show fc2 plogi | yes |
| show fc2 plogi_pwwn | yes |
| show fc2 port brief | yes |
| show fc2 port drops | yes |
| show fc2 port state | yes |

| Show Commands | XML Support |
|---------------------------------|-------------|
| show fc2 socket | yes |
| show fc2 sockexch | yes |
| show fc2 socknotify | yes |
| show fc2 socknport | yes |
| show fc2 vsan | yes |
| show fcdroplateny | yes |
| show fcoe | yes |
| show fcoe database | yes |
| show fcoe-npv issu-impact | yes |
| show fctimer | yes |
| show fctimer D_S_TOV | yes |
| show fctimer E_D_TOV | yes |
| show fctimer F_S_TOV | yes |
| show fctimer last action status | yes |
| show fctimer pending | yes |
| show fctimer pending-diff | yes |
| show fctimer R_A_TOV | yes |
| show fctimer session status | yes |
| show fctimer status | yes |
| show fctimer vsan | yes |
| show feature | yes |
| show feature-set | yes |
| show feature-set services | yes |
| show fhrp | yes |
| show fhrp verbose | yes |
| show file | yes |
| show fips status | yes |
| show flow cache | yes |

| Show Commands | XML Support |
|---|-------------|
| show flow exporter | yes |
| show flow filter | yes |
| show flow interface | yes |
| show flow monitor | yes |
| show flow profile | yes |
| show flow record | yes |
| show flow rtp | yes |
| show flow rtp timeout | yes |
| show flow system | yes |
| show flow timeout | yes |
| show flow tracer | yes |
| show forwarding | no |
| show forwarding adjacency | yes |
| show forwarding distribution clients | yes |
| show forwarding distribution fib-state | yes |
| show forwarding distribution ip igmp snooping | yes |
| show forwarding distribution ipv6 multicast route | yes |
| show forwarding distribution l2 multicast | yes |
| show forwarding distribution lisp counters | yes |
| show forwarding distribution lisp vrf enabled | yes |
| show forwarding distribution multicast | yes |
| show forwarding distribution multicast client | yes |
| show forwarding distribution multicast client-ack-db | yes |
| show forwarding distribution multicast download | no |
| show forwarding distribution multicast mfib | yes |
| show forwarding distribution multicast outgoing-interface-list | yes |
| show forwarding distribution multicast outgoing-interface-list L2_PRIME | yes |
| show forwarding distribution multicast resp-ack-timer-msgs | no |

| Show Commands | XML Support |
|---|-------------|
| show forwarding distribution multicast route | yes |
| show forwarding distribution multicast vxlan dsg-db | no |
| show forwarding distribution nve overlay-vlan | yes |
| show forwarding distribution peer-id | yes |
| show forwarding distribution trace | no |
| show forwarding ecmp | yes |
| show forwarding ecmp recursive | yes |
| show forwarding interfaces | yes |
| show forwarding ipv6 adjacency | yes |
| show forwarding ipv6 inconsistency | yes |
| show forwarding ipv6 multicast route | yes |
| show forwarding ipv6 route | yes |
| show forwarding kvfib cache on | no |
| show forwarding l2 multicast | yes |
| show forwarding l2vpn label vpls | yes |
| show forwarding l2vpn label xconnect | yes |
| show forwarding l2vpn vlan | yes |
| show forwarding mpls | yes |
| show forwarding mpls drop-stats | yes |
| show forwarding mpls ecmp | yes |
| show forwarding mpls eompls | yes |
| show forwarding mpls eompls ir | yes |
| show forwarding mpls option_b | yes |
| show forwarding mpls srte module | yes |
| show forwarding mpls summary | yes |
| show forwarding multicast outgoing-interface-list | yes |
| show forwarding multicast route | yes |
| show forwarding multicast-sr loopback interface | yes |

| Show Commands | XML Support |
|--|-------------|
| show forwarding nve l2 ingress-replication-peers | yes |
| show forwarding nve l3 adjacency tunnel | yes |
| show forwarding nve l3 adjacency v6-tunnel | yes |
| show forwarding nve l3 ecmp | yes |
| show forwarding nve l3 peers | yes |
| show forwarding nve underlay-interfaces | yes |
| show forwarding otv | yes |
| show forwarding security group-tag | yes |
| show forwarding security mac | yes |
| show forwarding trace | yes |
| show forwarding trace profile | no |
| show forwarding trace profile funcstats | yes |
| show fte event | yes |
| show fte exporter | yes |
| show fte monitor | yes |
| show fte record | yes |
| show guestshell | yes |
| show hardware | yes |
| show hardware access-list lou resource threshold | yes |
| show hardware access-list resource pooling | yes |
| show hardware access-list tcam | yes |
| show hardware capacity | no |
| show hardware capacity eobc | yes |
| show hardware capacity fabric-utilization | yes |
| show hardware capacity forwarding | no |
| show hardware capacity interface | yes |
| show hardware capacity module | yes |
| show hardware capacity power | yes |

| Show Commands | XML Support |
|--|-------------|
| show hardware fabricpath mac-learning module | yes |
| show hardware feature-capability | yes |
| show hardware flow aging | no |
| show hardware flow entry address type | no |
| show hardware flow etrap | yes |
| show hardware flow ip | no |
| show hardware flow ipv6 | no |
| show hardware flow l2 | no |
| show hardware flow mpls | no |
| show hardware flow sampler | no |
| show hardware flow utilization | no |
| show hardware forwarding interface statistics mode | yes |
| show hardware forwarding memory health detail | yes |
| show hardware forwarding memory health summary | yes |
| show hardware ip verify | yes |
| show hardware profile buffer monitor show hardware profile buffer monitor internal | yes |
| show hardware profile forwarding-mode | no |
| show hardware profile latency monitor sampling show hardware profile latency monitor | yes |
| show hardware profile module | yes |
| show hardware profile packet-drop | yes |
| show hardware profile status | yes |
| show hardware profile tcam region | yes |
| show hardware qos afd profile | yes |
| show hardware qos burst-detect max-records | yes |
| show hardware qos eoq stats-class | yes |
| show hardware qos include ipg | yes |
| show hardware qos ing-pg-hdrm-reserve | yes |
| show hardware qos ing-pg-no-min | yes |

| Show Commands | XML Support |
|---|-------------|
| show hardware qos ing-pg-share | yes |
| show hardware qos min-buffer | yes |
| show hardware qos ns-buffer-profile | yes |
| show hardware qos ns-mcq3-alias | yes |
| show hardware rate-limiter | yes |
| show hardware rate-limiter span-egress | yes |
| show hardware rl snmp class-id | yes |
| show hardware rl snmp global class-id | yes |
| show hardware rl snmp local snmp-index class-id | yes |
| show hostname | yes |
| show hosts | yes |
| show hsrp | yes |
| show hsrp anycast | no |
| show hsrp anycast interface vlan | no |
| show hsrp anycast remote-db | no |
| show hsrp anycast summary | no |
| show hsrp bfd-sessions | yes |
| show hsrp delay | yes |
| show hsrp mgo | yes |
| show hsrp summary | yes |
| show icam entries acl module inst | yes |
| show icam health | yes |
| show icam itd | yes |
| show icam prediction entries acl module inst | yes |
| show icam prediction resource acl_team mod inst trend | yes |
| show icam prediction resource module inst | yes |
| show icam prediction scale | yes |
| show icam resource module inst | yes |

| Show Commands | XML Support |
|-------------------------------------|-------------|
| show icam scale | yes |
| show ieth-header-decode | no |
| show imp client | no |
| show imp client sa | no |
| show inband-telemetry exporter | yes |
| show inband-telemetry flow-profile | yes |
| show inband-telemetry monitor | yes |
| show inband-telemetry queue-profile | yes |
| show inband-telemetry record | yes |
| show inband-telemetry sessions | yes |
| show inband-telemetry watchlist | yes |
| show incompatibility system | yes |
| show incompatibility-all system | yes |
| show install | yes |
| show install all failed-standby | yes |
| show install all failure-reason | yes |
| show install all impact | no |
| show install all impact epld | yes |
| show install all status | no |
| show install all time-stats | no |
| show install epld status | yes |
| show install log | yes |
| show install mode | yes |
| show install packages | yes |
| show install patches | yes |
| show interface | yes |
| show interface bbcredit | yes |
| show interface brief | yes |

| Show Commands | XML Support |
|---|-------------|
| show interface cable-diagnostics-tdr | yes |
| show interface capabilities | yes |
| show interface counters | yes |
| show interface counters brief | yes |
| show interface counters detailed | yes |
| show interface counters detailed all | yes |
| show interface counters detailed all | no |
| show interface counters detailed all | yes |
| show interface counters detailed cached | yes |
| show interface counters details | yes |
| show interface counters errors | yes |
| show interface counters errors | no |
| show interface counters snmp | yes |
| show interface counters storm-control | yes |
| show interface counters table | yes |
| show interface counters table verbose | yes |
| show interface counters trunk | yes |
| show interface dampening | yes |
| show interface debounce | yes |
| show interface description | yes |
| show interface detail-counters | yes |
| show interface eltm lif-info | no |
| show interface fcoe | yes |
| show interface fec | yes |
| show interface flowcontrol | yes |
| show interface hardware-mappings | no |
| show interface mac-address | yes |
| show interface priority-flow-control | yes |

| Show Commands | XML Support |
|---------------------------------------|-------------|
| show interface private-vlan mapping | yes |
| show interface pruning | yes |
| show interface snmp-ifindex | yes |
| show interface status | yes |
| show interface status err-disabled | yes |
| show interface status err-vlans | yes |
| show interface switchport | yes |
| show interface switchport backup | yes |
| show interface transceiver | yes |
| show interface transceiver fex-fabric | yes |
| show interface trunk | yes |
| show interface trunk vsan | yes |
| show interface untagged-cos | yes |
| show interface vlan mapping | yes |
| show inventory | yes |
| show ip adjacency | yes |
| show ip amt relay | yes |
| show ip amt route | yes |
| show ip amt tunnel | yes |
| show ip arp | yes |
| show ip arp anycast topo-info | yes |
| show ip arp client | yes |
| show ip arp controller-statistics | yes |
| show ip arp esi | yes |
| show ip arp inspection | yes |
| show ip arp inspection interfaces | yes |
| show ip arp inspection log | yes |
| show ip arp inspection statistics | yes |

| Show Commands | XML Support |
|--|-------------|
| show ip arp inspection vlan | yes |
| show ip arp l2 statistics interface | yes |
| show ip arp multihoming-statistics | yes |
| show ip arp off-list | yes |
| show ip arp open-flow error-statistics | yes |
| show ip arp statistics | yes |
| show ip arp suppression topo-info | yes |
| show ip arp suppression-cache | yes |
| show ip arp tunnel-statistics | yes |
| show ip arp vpc-statistics | yes |
| show ip as-path-access-list | yes |
| show ip client | yes |
| show ip community-list | yes |
| show ip debug | no |
| show ip dhcp global statistics | yes |
| show ip dhcp option82 suboption info interface | yes |
| show ip dhcp relay | yes |
| show ip dhcp relay address | yes |
| show ip dhcp relay information trusted-sources | yes |
| show ip dhcp relay statistics | yes |
| show ip dhcp snooping | yes |
| show ip dhcp snooping binding | no |
| show ip dhcp snooping statistics | no |
| show ip dhcp status | yes |
| show ip dns source-interface | yes |
| show ip dns source-interface vrf all | yes |
| show ip eigrp | yes |
| show ip eigrp accounting | yes |

| Show Commands | XML Support |
|--|-------------|
| show ip eigrp detail | no |
| show ip eigrp event-history | no |
| show ip eigrp event-history bfd | no |
| show ip eigrp interfaces | yes |
| show ip eigrp route-map statistics | yes |
| show ip eigrp traffic | yes |
| show ip extcommunity-list | yes |
| show ip fib adjacency | yes |
| show ip fib distribution | no |
| show ip fib distribution capture | yes |
| show ip fib distribution clients | yes |
| show ip fib distribution mroute | yes |
| show ip fib distribution multicast | yes |
| show ip fib distribution multicast outgoing-interface-list | yes |
| show ip fib distribution state | yes |
| show ip ftp source-interface | yes |
| show ip ftp source-interface vrf all | yes |
| show ip http source-interface | yes |
| show ip http source-interface vrf all | yes |
| show ip igmp event-history | no |
| show ip igmp groups | yes |
| show ip igmp interface | yes |
| show ip igmp local-groups | yes |
| show ip igmp policy statistics reports | yes |
| show ip igmp snooping | yes |
| show ip igmp snooping event-history | no |
| show ip igmp snooping explicit-tracking | yes |
| show ip igmp snooping filter details | yes |

| Show Commands | XML Support |
|---|--------------------|
| show ip igmp snooping groups | yes |
| show ip igmp snooping lookup-mode | yes |
| show ip igmp snooping mac-oif | yes |
| show ip igmp snooping mrouter | yes |
| show ip igmp snooping pw vlan brief | yes |
| show ip igmp snooping querier | yes |
| show ip igmp snooping report statistics | yes |
| show ip igmp snooping statistics | yes |
| show ip igmp vrf all | yes |
| show ip interface | yes |
| show ip lisp | no |
| show ip lisp data-cache | no |
| show ip lisp locator-hash | no |
| show ip lisp map-cache | no |
| show ip lisp statistics | no |
| show ip lisp translate-cache | no |
| show ip load-sharing | yes |
| show ip local policy | yes |
| show ip logging | yes |
| show ip mbgp | no |
| show ip mbgp community | no |
| show ip mbgp dampening | no |
| show ip mbgp extcommunity | no |
| show ip mbgp flap-statistics | no |
| show ip mbgp neighbors | no |
| show ip mbgp nexthop | no |
| show ip mbgp nexthop-database | no |
| show ip mbgp prefix-list | no |

| Show Commands | XML Support |
|---|-------------|
| show ip mbgp received-paths | no |
| show ip mroute | yes |
| show ip msdp count | yes |
| show ip msdp event-history | no |
| show ip msdp mesh-group | yes |
| show ip msdp peer | yes |
| show ip msdp policy statistics sa-policy in | yes |
| show ip msdp rpf | yes |
| show ip msdp sa | yes |
| show ip msdp sources | yes |
| show ip msdp statistics | yes |
| show ip msdp summary | yes |
| show ip nat max | yes |
| show ip nat statistics | yes |
| show ip nat timeout | yes |
| show ip nat translations | yes |
| show ip nat-alias | yes |
| show ip ospf | yes |
| show ip ospf border-routers | yes |
| show ip ospf database | yes |
| show ip ospf database database-summary | yes |
| show ip ospf database detail | yes |
| show ip ospf event-history | no |
| show ip ospf event-history detail | no |
| show ip ospf interface | yes |
| show ip ospf interface brief | yes |
| show ip ospf lsa-content-changed-list | yes |
| show ip ospf neighbors | yes |

| Show Commands | XML Support |
|---|-------------|
| show ip ospf neighbors detail | yes |
| show ip ospf neighbors summary | yes |
| show ip ospf policy statistics | yes |
| show ip ospf request-list | yes |
| show ip ospf retransmission-list | yes |
| show ip ospf route | yes |
| show ip ospf route summary | yes |
| show ip ospf segment-routing adj-sid-database | yes |
| show ip ospf segment-routing global-block | yes |
| show ip ospf segment-routing sid-database | yes |
| show ip ospf sham-links | yes |
| show ip ospf sham-links brief | yes |
| show ip ospf statistics | yes |
| show ip ospf summary-address | yes |
| show ip ospf traffic | yes |
| show ip ospf virtual-links | yes |
| show ip ospf virtual-links brief | yes |
| show ip pim config-sanity | yes |
| show ip pim df | yes |
| show ip pim event-history | no |
| show ip pim fabric info | yes |
| show ip pim fabric legacy-vlans | yes |
| show ip pim group-range | yes |
| show ip pim host-proxy | yes |
| show ip pim interface | yes |
| show ip pim mdt | yes |
| show ip pim mdt bgp | yes |
| show ip pim mdt history interval | yes |

| Show Commands | XML Support |
|--|-------------|
| show ip pim mdt receive | yes |
| show ip pim mdt send | yes |
| show ip pim neighbor | yes |
| show ip pim oif-list | yes |
| show ip pim policy statistics | yes |
| show ip pim policy statistics jp | yes |
| show ip pim route | yes |
| show ip pim rp | yes |
| show ip pim rp-hash | yes |
| show ip pim statistics | yes |
| show ip pim vrf | yes |
| show ip ping source-interface | yes |
| show ip ping source-interface vrf all | yes |
| show ip policy | yes |
| show ip prefix-list | yes |
| show ip process | yes |
| show ip rip | yes |
| show ip rip interface | yes |
| show ip rip neighbor | yes |
| show ip rip policy statistics redistribute | yes |
| show ip rip route | yes |
| show ip rip statistics | yes |
| show ip route | yes |
| show ip rsvp | yes |
| show ip sla application | yes |
| show ip sla configuration | yes |
| show ip sla enhanced-history collection-statistics | yes |
| show ip sla enhanced-history distribution-statistics | yes |

| Show Commands | XML Support |
|---|-------------|
| show ip sla group schedule | yes |
| show ip sla history | yes |
| show ip sla reaction-configuration | yes |
| show ip sla reaction-trigger | yes |
| show ip sla responder | yes |
| show ip sla statistics | yes |
| show ip sla twamp connection detail | yes |
| show ip sla twamp connection requests | yes |
| show ip sla twamp session | yes |
| show ip sla twamp standards | yes |
| show ip ssh source-interface | yes |
| show ip ssh source-interface vrf all | yes |
| show ip static-route | yes |
| show ip tcp mss | yes |
| show ip telnet source-interface | yes |
| show ip telnet source-interface vrf all | yes |
| show ip tftp source-interface | yes |
| show ip tftp source-interface vrf all | yes |
| show ip traceroute source-interface | yes |
| show ip traceroute source-interface vrf all | yes |
| show ip traffic | yes |
| show ip udp relay | yes |
| show ip udp relay interface | yes |
| show ip udp relay object-group | yes |
| show ip verify source | yes |
| show ipv6 adjacency | yes |
| show ipv6 adjacency aggregate-prefix | yes |
| show ipv6 adjacency subnet-prefix | yes |

| Show Commands | XML Support |
|--------------------------------------|-------------|
| show ipv6 amt tunnel | yes |
| show ipv6 bgp | no |
| show ipv6 bgp community | no |
| show ipv6 bgp dampening | no |
| show ipv6 bgp extcommunity | no |
| show ipv6 bgp flap-statistics | no |
| show ipv6 bgp neighbors | no |
| show ipv6 bgp nexthop | no |
| show ipv6 bgp nexthop-database | no |
| show ipv6 bgp received-paths | no |
| show ipv6 bgp regexp | no |
| show ipv6 bgp summary | no |
| show ipv6 client | yes |
| show ipv6 dhcp guard policy | yes |
| show ipv6 dhcp relay | yes |
| show ipv6 dhcp relay statistics | yes |
| show ipv6 eigrp route-map statistics | yes |
| show ipv6 fragments | yes |
| show ipv6 icmp | yes |
| show ipv6 icmp global traffic | yes |
| show ipv6 icmp interface | yes |
| show ipv6 icmp l2 statistics | yes |
| show ipv6 icmp nd local-proxy stats | yes |
| show ipv6 icmp off-list | yes |
| show ipv6 icmp vaddr | yes |
| show ipv6 icmp vpc-statistics | yes |
| show ipv6 interface | yes |
| show ipv6 lisp data-cache | no |

| Show Commands | XML Support |
|------------------------------------|-------------|
| show ipv6 local policy | yes |
| show ipv6 mld groups | yes |
| show ipv6 mld local-groups | yes |
| show ipv6 mroute | yes |
| show ipv6 mtu | yes |
| show ipv6 nd ra dns search-list | yes |
| show ipv6 nd ra dns server | yes |
| show ipv6 nd rguard policy | yes |
| show ipv6 neighbor binding | no |
| show ipv6 neighbor binding mac | no |
| show ipv6 neighbor static | yes |
| show ipv6 pim df | yes |
| show ipv6 pim event-history | no |
| show ipv6 pim fabric info | yes |
| show ipv6 pim fabric legacy-vlans | yes |
| show ipv6 pim group-range | yes |
| show ipv6 pim interface | yes |
| show ipv6 pim neighbor | yes |
| show ipv6 pim oif-list | yes |
| show ipv6 pim policy statistics jp | yes |
| show ipv6 pim route | yes |
| show ipv6 pim rp | yes |
| show ipv6 pim rp-hash | yes |
| show ipv6 pim statistics | yes |
| show ipv6 pim vrf | yes |
| show ipv6 policy | yes |
| show ipv6 prefix-list | yes |
| show ipv6 process | yes |

| Show Commands | XML Support |
|--|-------------|
| show ipv6 rguard statistics | yes |
| show ipv6 rip policy statistics redistribute | yes |
| show ipv6 route | yes |
| show ipv6 routers | yes |
| show ipv6 snooping capture-policy | yes |
| show ipv6 snooping counters vlan | yes |
| show ipv6 snooping events | yes |
| show ipv6 snooping features | yes |
| show ipv6 snooping messages | yes |
| show ipv6 snooping policies | yes |
| show ipv6 snooping policy | yes |
| show ipv6 snooping pss database | yes |
| show ipv6 static-route | yes |
| show ipv6 traffic | yes |
| show isis | yes |
| show isis adjacency | yes |
| show isis csnp | yes |
| show isis database | yes |
| show isis distribute-ls | yes |
| show isis dynamic-flooding | yes |
| show isis event-history | no |
| show isis hostname | yes |
| show isis interface | yes |
| show isis ipv6 redistribute route | yes |
| show isis ipv6 route | yes |
| show isis ipv6 route-map statistics | yes |
| show isis ipv6 summary-address | yes |
| show isis lslib | no |

| Show Commands | XML Support |
|---------------------------------------|--------------------|
| show isis lsp free-list | no |
| show isis mesh-group | yes |
| show isis non tlv overflow-list | no |
| show isis redistribute route | yes |
| show isis route | yes |
| show isis route-map statistics | yes |
| show isis rrm | yes |
| show isis segment-routing mapcache | yes |
| show isis segment-routing remote-srgb | yes |
| show isis segment-routing sids | yes |
| show isis spf-log | yes |
| show isis srm | yes |
| show isis ssn | yes |
| show isis statistics | yes |
| show isis summary-address | yes |
| show isis topology | yes |
| show isis traffic | yes |
| show itd | yes |
| show itd session device-group | yes |
| show itd statistics | yes |
| show itd vrf | yes |
| show key chain | yes |
| show key chain mode decrypt | yes |
| show keystore | yes |
| show kim inconsistency | no |
| show kubernetes containers | no |
| show l2 mroute | yes |
| show l2 multicast ftag | yes |

| Show Commands | XML Support |
|--|-------------|
| show l2 multicast trees | yes |
| show l2 route | yes |
| show l2fwder l2rib info | no |
| show l2fwder statistics | no |
| show l2rib clients | yes |
| show l2rib producers | yes |
| show l2rib registrations | yes |
| show l2route cmcast topology | yes |
| show l2route evpn ead all | yes |
| show l2route evpn ethernet-segment esi | yes |
| show l2route evpn fl all | yes |
| show l2route evpn fl evi | yes |
| show l2route evpn imet all | yes |
| show l2route evpn imet evi | yes |
| show l2route evpn mac all | yes |
| show l2route evpn mac evi | yes |
| show l2route evpn mac-ip all | yes |
| show l2route evpn mac-ip evi | yes |
| show l2route evpn path-list all | yes |
| show l2route evpn startup-route all | yes |
| show l2route evpn startup-route evi | yes |
| show l2route fl topology | yes |
| show l2route peerid | yes |
| show l2route summary | yes |
| show l2route topology | yes |
| show lacp counters | yes |
| show lacp interface | yes |
| show lacp issu-impact | yes |

| Show Commands | XML Support |
|--------------------------------------|-------------|
| show lacp neighbor | yes |
| show lacp port-channel | yes |
| show lacp system-identifier | yes |
| show lcmd stats interface | no |
| show ldap-search-map | yes |
| show ldap-server | yes |
| show ldap-server groups | yes |
| show ldap-server statistics | yes |
| show license | yes |
| show license brief | yes |
| show license default | yes |
| show license feature package mapping | yes |
| show license file | yes |
| show license host-id | yes |
| show license tech support | no |
| show license usage | yes |
| show line | yes |
| show line console | yes |
| show line console connected | yes |
| show line console user-input-string | yes |
| show lisp ddt | no |
| show lisp ddt queue | no |
| show lisp ddt referral-cache | no |
| show lisp dynamic-eid | no |
| show lisp elp | no |
| show lisp negative-prefix | no |
| show lisp proxy-itr | no |
| show lisp site | no |

| Show Commands | XML Support |
|------------------------------------|-------------|
| show lisp site instance-id | no |
| show lldp all | yes |
| show lldp dcba interface | yes |
| show lldp entry | yes |
| show lldp interface | yes |
| show lldp neighbors | yes |
| show lldp neighbors detail | yes |
| show lldp neighbors system-detail | yes |
| show lldp portid-subtype | yes |
| show lldp timers | yes |
| show lldp tlv-select | yes |
| show lldp traffic | yes |
| show lldp traffic interface | yes |
| show lldp traffic interface all | yes |
| show locator-led status | yes |
| show logging | no |
| show logging console | no |
| show logging dropcount | no |
| show logging info | yes |
| show logging ip access-list cache | yes |
| show logging ip access-list status | yes |
| show logging last | no |
| show logging level | yes |
| show logging level | no |
| show logging level aaa | no |
| show logging level acllog | no |
| show logging level aclmgr | no |
| show logging level adbm | no |

| Show Commands | XML Support |
|--|--------------------|
| show logging level adjmgr | no |
| show logging level amt | no |
| show logging level arp | no |
| show logging level ascii-cfg | no |
| show logging level assoc_mgr | no |
| show logging level backup | no |
| show logging level bfd | no |
| show logging level bgp | no |
| show logging level bloggerd | no |
| show logging level bootvar | no |
| show logging level callhome | no |
| show logging level capability | no |
| show logging level catena | no |
| show logging level cdp | no |
| show logging level cert_enroll | no |
| show logging level cfs | no |
| show logging level clis | no |
| show logging level clk_mgr | no |
| show logging level confcheck | no |
| show logging level copp | no |
| show logging level core | no |
| show logging level cts | no |
| show logging level dhcp_snoop | no |
| show logging level diagnostic diagclient | no |
| show logging level diagnostic diagmgr | no |
| show logging level dot1x | no |
| show logging level ecp | no |
| show logging level eigrp | no |

| Show Commands | XML Support |
|---|-------------|
| show logging level eltm | no |
| show logging level epp | no |
| show logging level ethdstats | no |
| show logging level ethpm | no |
| show logging level evb | no |
| show logging level evmc | no |
| show logging level evmed | no |
| show logging level evms | no |
| show logging level fabric forwarding | no |
| show logging level fabricpath isis | no |
| show logging level fabricpath switch-id | no |
| show logging level fcoe_mgr | no |
| show logging level feature-mgr | no |
| show logging level fs-daemon | no |
| show logging level gpixm | no |
| show logging level hardware-telemetry | no |
| show logging level hsrp | no |
| show logging level icam | no |
| show logging level im | no |
| show logging level imp | no |
| show logging level interface-vlan | no |
| show logging level ip igmp | no |
| show logging level ip msdp | no |
| show logging level ip sla responder | no |
| show logging level ip sla sender | no |
| show logging level ip sla twamp-server | no |
| show logging level ipconf | no |
| show logging level ipfib | no |

| Show Commands | XML Support |
|-------------------------------------|-------------|
| show logging level ipqos | no |
| show logging level ipv6 icmp | no |
| show logging level iscm | no |
| show logging level isis | no |
| show logging level keystore | no |
| show logging level l2fm | no |
| show logging level l3vm | no |
| show logging level lacp | no |
| show logging level ldap | no |
| show logging level license | no |
| show logging level lim | no |
| show logging level lisp | no |
| show logging level lldp | no |
| show logging level m2rib | no |
| show logging level mfdm | no |
| show logging level mfw | no |
| show logging level mmode | no |
| show logging level module | no |
| show logging level monitor | no |
| show logging level mpls ldp | no |
| show logging level mpls manager | no |
| show logging level mpls switching | no |
| show logging level mpls traffic-eng | no |
| show logging level mvsh | no |
| show logging level nat | no |
| show logging level nbm | no |
| show logging level netstack | no |
| show logging level nfm | no |

| Show Commands | XML Support |
|-----------------------------------|-------------|
| show logging level ngmvpn | no |
| show logging level ngoam | no |
| show logging level npv | no |
| show logging level ntp | no |
| show logging level nve | no |
| show logging level nxsdk | no |
| show logging level openflow | no |
| show logging level ospf | no |
| show logging level ospfv3 | no |
| show logging level otv | no |
| show logging level pfstat | no |
| show logging level pim | no |
| show logging level pixm | no |
| show logging level pktmgr | no |
| show logging level platform | no |
| show logging level plbm | no |
| show logging level plcmgr | no |
| show logging level pltfm_config | no |
| show logging level plugin | no |
| show logging level poap | no |
| show logging level poed | no |
| show logging level port | no |
| show logging level port-channel | no |
| show logging level port-profile | no |
| show logging level port-resources | no |
| show logging level port-security | no |
| show logging level private-vlan | no |
| show logging level ptp | no |

| Show Commands | XML Support |
|---|--------------------|
| show logging level radius | no |
| show logging level res_mgr | no |
| show logging level rip | no |
| show logging level routing ipv6 multicast | no |
| show logging level routing multicast | no |
| show logging level rpm | no |
| show logging level rsvp | no |
| show logging level sal | no |
| show logging level san-port-channel | no |
| show logging level scheduler | no |
| show logging level security | no |
| show logging level segment-routing | no |
| show logging level session-mgr | no |
| show logging level sflow | no |
| show logging level smartc | no |
| show logging level smm | no |
| show logging level snmpd | no |
| show logging level snmpmib_proc | no |
| show logging level spanning-tree | no |
| show logging level spm | no |
| show logging level stripcl | no |
| show logging level sysmgr | no |
| show logging level tacacs | no |
| show logging level telemetry | no |
| show logging level template_manager | no |
| show logging level track | no |
| show logging level tunnel | no |
| show logging level u2rib | no |

| Show Commands | XML Support |
|------------------------------------|-------------|
| show logging level u6rib | no |
| show logging level udld | no |
| show logging level ufdm | no |
| show logging level urib | no |
| show logging level vdc_mgr | no |
| show logging level virtual-service | no |
| show logging level vlan_mgr | no |
| show logging level vmm | no |
| show logging level vmtracker | no |
| show logging level vpc | no |
| show logging level vrrp-cfg | no |
| show logging level vrrp-eng | no |
| show logging level vrrpv3 | no |
| show logging level vsan | no |
| show logging level vshd | no |
| show logging level vtp | no |
| show logging level wwn | no |
| show logging level xbar | no |
| show logging logfile | no |
| show logging logfile duration | no |
| show logging logfile last-index | no |
| show logging logfile start-seqn | no |
| show logging logfile start-time | no |
| show logging loopback | no |
| show logging module | no |
| show logging monitor | no |
| show logging nvram | yes |
| show logging onboard | no |

| Show Commands | XML Support |
|--|-------------|
| show logging onboard kernel-trace | no |
| show logging origin-id | no |
| show logging pending | no |
| show logging pending-diff | no |
| show logging rate-limit | no |
| show logging rfc-strict | no |
| show logging server | yes |
| show logging session status | no |
| show logging source-interface | no |
| show logging status | no |
| show logging timestamp | no |
| show login on-failure log | yes |
| show login on-successful log | yes |
| show mac address-table | yes |
| show mac address-table aging-time | yes |
| show mac address-table count | yes |
| show mac address-table count es | yes |
| show mac address-table learning-mode | yes |
| show mac address-table limit | yes |
| show mac address-table limit user-defined | yes |
| show mac address-table loop-detect | yes |
| show mac address-table multicast | yes |
| show mac address-table notification mac-move | yes |
| show mac scalar | yes |
| show mac-list | yes |
| show macsec mka | yes |
| show macsec mka session | yes |
| show macsec mka statistics | yes |

| Show Commands | XML Support |
|--|-------------|
| show macsec policy | yes |
| show macsec secy statistics | yes |
| show maintenance maint-delay | yes |
| show maintenance on-reload reset-reasons | yes |
| show maintenance profile | yes |
| show maintenance snapshot-delay | yes |
| show maintenance timeout | yes |
| show module | yes |
| show module bandwidth-fairness | yes |
| show module uptime | yes |
| show monitor | yes |
| show monitor session | yes |
| show mpls extended-ecmp | no |
| show mpls forwarding statistics | yes |
| show mpls interfaces | yes |
| show mpls interfaces detail | yes |
| show mpls interfaces statistics | yes |
| show mpls ip bindings | yes |
| show mpls ip bindings summary | yes |
| show mpls ip ttl | yes |
| show mpls label range | yes |
| show mpls load-sharing | yes |
| show mpls oam echo statistics | yes |
| show mpls static binding | yes |
| show mpls static trace | no |
| show mpls strip labels | yes |
| show mpls switching | yes |
| show mpls switching clients | yes |

| Show Commands | XML Support |
|---------------------------------------|-------------|
| show mvpn bgp mdt | yes |
| show mvpn mdt encap | yes |
| show mvpn mdt route | yes |
| show mvr groups | yes |
| show mvr interface | yes |
| show mvr members | yes |
| show mvr members count | yes |
| show mvr members vlan | yes |
| show mvr receiver-ports | yes |
| show mvr source-ports | yes |
| show nat itd | yes |
| show nbm defaults | yes |
| show nbm flow-policy | yes |
| show nbm flows | yes |
| show nbm flows static | yes |
| show nbm flows statistics | yes |
| show nbm flows summary | yes |
| show nbm host-policy all | yes |
| show nbm host-policy applied receiver | yes |
| show nbm host-policy applied sender | yes |
| show nbm interface bandwidth | yes |
| show ngoam interface statistics | yes |
| show ngoam loopback | yes |
| show ngoam mct-stats | yes |
| show ngoam pathtrace | yes |
| show ngoam probe | yes |
| show ngoam traceroute statistics | yes |
| show ngoam xconnect session | yes |

| Show Commands | XML Support |
|-----------------------------------|-------------|
| show npv external-interface-usage | yes |
| show npv flogi-table | yes |
| show npv status | yes |
| show npv traffic-map | yes |
| show ntp access-groups | yes |
| show ntp authentication-keys | yes |
| show ntp authentication-status | yes |
| show ntp information | yes |
| show ntp logging-status | yes |
| show ntp peer-status | yes |
| show ntp peers | yes |
| show ntp rts-update | yes |
| show ntp session status | yes |
| show ntp source | yes |
| show ntp source-interface | yes |
| show ntp statistics | yes |
| show ntp status | yes |
| show ntp trusted-keys | yes |
| show nve adjacency mpls | yes |
| show nve bfd neighbors | yes |
| show nve core-links | yes |
| show nve ethernet-segment | yes |
| show nve evi | yes |
| show nve interface | yes |
| show nve mpls | yes |
| show nve multisite dci-links | yes |
| show nve multisite fabric-links | yes |
| show nve peers | yes |

| Show Commands | XML Support |
|---------------------------------------|-------------|
| show nve peers interface counters | yes |
| show nve peers mpls | yes |
| show nve peers vni interface counters | yes |
| show nve replication-servers | yes |
| show nve vni | yes |
| show nve vni counters | yes |
| show nve vni ingress-replication | yes |
| show nve vni peer-vtep | yes |
| show nve vrf | yes |
| show nve vxlan-params | yes |
| show nxapi | yes |
| show nxapi syntax | no |
| show nxapi-server logs | no |
| show object-group | yes |
| show openflow hardware capabilities | no |
| show openflow switch | yes |
| show openflow switch flows | no |
| show ospfv3 | yes |
| show ospfv3 border-routers | yes |
| show ospfv3 database | yes |
| show ospfv3 database database-summary | yes |
| show ospfv3 database detail | yes |
| show ospfv3 event-history | no |
| show ospfv3 event-history detail | no |
| show ospfv3 interface | yes |
| show ospfv3 interface brief | yes |
| show ospfv3 neighbors | yes |
| show ospfv3 neighbors detail | yes |

| Show Commands | XML Support |
|---------------------------------|-------------|
| show ospfv3 neighbors summary | yes |
| show ospfv3 policy statistics | no |
| show ospfv3 request-list | yes |
| show ospfv3 retransmission-list | yes |
| show ospfv3 route | yes |
| show ospfv3 route summary | yes |
| show ospfv3 statistics | yes |
| show ospfv3 summary-address | yes |
| show ospfv3 traffic | yes |
| show ospfv3 virtual-links | yes |
| show ospfv3 virtual-links brief | yes |
| show otv | no |
| show param-list | yes |
| show password secure-mode | yes |
| show password strength-check | yes |
| show plb | yes |
| show plb analytics | yes |
| show plb vrf | yes |
| show pmap-int | no |
| show pmap-int-br interface br | yes |
| show pnp lease | no |
| show pnp posix_pi configs | no |
| show pnp posix_pi tech-support | no |
| show pnp profiles | no |
| show pnp status | no |
| show pnp summary | no |
| show pnp version | no |
| show policy-map | yes |

| Show Commands | XML Support |
|--|-------------|
| show policy-map interface control-plane | yes |
| show policy-map system | yes |
| show policy-map type control-plane | yes |
| show policy-map type network-qos | yes |
| show port naming | no |
| show port-channel capacity | yes |
| show port-channel compatibility-parameters | yes |
| show port-channel database | yes |
| show port-channel fast-convergence | yes |
| show port-channel load-balance | yes |
| show port-channel load-balance forwarding-path interface | yes |
| show port-channel load-balance forwarding-path1 interface src-interface | yes |
| show port-channel load-balance hardware forwarding-path interface source | yes |
| show port-channel rbh-distribution | yes |
| show port-channel scale-fanout | yes |
| show port-channel summary | yes |
| show port-channel traffic | yes |
| show port-channel usage | yes |
| show port-license | yes |
| show port-profile | yes |
| show port-profile brief | yes |
| show port-profile expand-interface | yes |
| show port-profile sync-status | yes |
| show port-profile usage | yes |
| show port-security | yes |
| show port-security address | yes |
| show port-security address interface | yes |
| show port-security interface | yes |

| Show Commands | XML Support |
|---------------------------------------|-------------|
| show port-security state | yes |
| show postcard-telemetry exporter | yes |
| show postcard-telemetry flow-profile | yes |
| show postcard-telemetry monitor | yes |
| show postcard-telemetry queue-profile | yes |
| show postcard-telemetry sessions | yes |
| show postcard-telemetry watchlist | yes |
| show power inline | yes |
| show power inline police | yes |
| show power inline priority | yes |
| show privilege | yes |
| show processes | yes |
| show processes cpu | yes |
| show processes cpu history | no |
| show processes cpu history data | yes |
| show processes cpu module | yes |
| show processes log | yes |
| show processes log details | yes |
| show processes log pid | yes |
| show processes log vdc-all | yes |
| show processes memory | yes |
| show processes memory physical | yes |
| show processes memory shared | yes |
| show processes vdc | yes |
| show processes vdc cpu | yes |
| show processes vdc log | yes |
| show processes vdc log details | no |
| show processes vdc log pid | no |

| Show Commands | XML Support |
|--|--------------------|
| show processes vdc memory | yes |
| show processes version | yes |
| show pss debug | no |
| show ptp brief | yes |
| show ptp clock | yes |
| show ptp clock foreign-masters record | yes |
| show ptp corrections | yes |
| show ptp cost | yes |
| show ptp counters interface | yes |
| show ptp delay summary | yes |
| show ptp domain data | yes |
| show ptp interface domain | yes |
| show ptp packet-trace | yes |
| show ptp parent | yes |
| show ptp port interface | yes |
| show ptp time-property | yes |
| show qos dcbxp incompatibility interface | yes |
| show qos dcbxp info | yes |
| show qos dcbxp interface | yes |
| show qos shared-policer | yes |
| show queuing | yes |
| show queuing burst-detect | yes |
| show queuing pfc-queue | yes |
| show queuing pfc-queue interface snmp watchdogIfQueueTable ifIndex | yes |
| show queuing pfc-queue snmp ifIndex | yes |
| show queuing tabular | yes |
| show queuing tah-pfc-queue | yes |
| show radius status | yes |

| Show Commands | XML Support |
|-------------------------------------|-------------|
| show radius-cfs | yes |
| show radius-server | yes |
| show radius-server directed-request | yes |
| show radius-server groups | yes |
| show radius-server sorted | yes |
| show radius-server statistics | yes |
| show redundancy status | yes |
| show regexp | no |
| show reload | yes |
| show resource | yes |
| show rmon | yes |
| show role | yes |
| show role feature | yes |
| show role feature-group | yes |
| show rollback log exec | yes |
| show rollback status | yes |
| show route-map | yes |
| show route-map pbr-statistics | yes |
| show router-guard | yes |
| show routing | yes |
| show routing clients | yes |
| show routing event-history | no |
| show routing hash | yes |
| show routing hidden-nh | yes |
| show routing ipv6 | yes |
| show routing ipv6 clients | yes |
| show routing ipv6 event-history | no |
| show routing ipv6 hash | yes |

| Show Commands | XML Support |
|---|-------------|
| show routing ipv6 hidden-nh | yes |
| show routing ipv6 memory estimate | yes |
| show routing ipv6 memory statistics | yes |
| show routing ipv6 multicast | yes |
| show routing ipv6 multicast clients | yes |
| show routing ipv6 multicast event-history | no |
| show routing ipv6 multicast memory estimate | yes |
| show routing ipv6 nexthop info | no |
| show routing ipv6 nhlfe | yes |
| show routing ipv6 recursive-next-hop | yes |
| show routing memory estimate | yes |
| show routing memory statistics | yes |
| show routing multicast | yes |
| show routing multicast clients | yes |
| show routing multicast event-history | no |
| show routing multicast lisp encap | yes |
| show routing multicast mdt encapsulation | yes |
| show routing multicast memory estimate | yes |
| show routing multicast sr | yes |
| show routing nhlfe | yes |
| show routing recursive-next-hop | yes |
| show routing unresolved-next-hop | no |
| show routing vxlan-hash peer-ip | no |
| show routing vxlan-hash peer-ipv6 | no |
| show routing-context | yes |
| show running-config | no |
| show running-config aaa | no |
| show running-config aclog | no |

| Show Commands | XML Support |
|-------------------------------------|-------------|
| show running-config aclmgr | no |
| show running-config aclmgr active | no |
| show running-config adjmgr | no |
| show running-config all | no |
| show running-config analytics | no |
| show running-config arp | no |
| show running-config assoc | no |
| show running-config backup | no |
| show running-config bfd | no |
| show running-config bgp | no |
| show running-config bloggerd | no |
| show running-config callhome | no |
| show running-config catena | no |
| show running-config cdp | no |
| show running-config cert-enroll | no |
| show running-config cfs | no |
| show running-config clock_manager | no |
| show running-config config-profile | no |
| show running-config config-template | no |
| show running-config controller | no |
| show running-config copp | no |
| show running-config dhcp | no |
| show running-config diagnostic | no |
| show running-config diff | no |
| show running-config dot1x | no |
| show running-config ecp | no |
| show running-config eem | no |
| show running-config eigrp | no |

| Show Commands | XML Support |
|---|-------------|
| show running-config eltm | no |
| show running-config evb | no |
| show running-config exclude fabricpath | no |
| show running-config expand-port-profile | no |
| show running-config fabric forwarding | no |
| show running-config fabric multicast | no |
| show running-config fabricpath | no |
| show running-config fabricpath domain default | no |
| show running-config fabricpath switch-id | no |
| show running-config fabricpath topology | no |
| show running-config fcoe_mgr | no |
| show running-config hardware-telemetry | no |
| show running-config hsrp | no |
| show running-config icam | no |
| show running-config icmpv6 | no |
| show running-config igmp | no |
| show running-config imp | no |
| show running-config interface | no |
| show running-config interface explicit | no |
| show running-config ip | no |
| show running-config ipqos | no |
| show running-config ipqos active | no |
| show running-config ipv6 | no |
| show running-config isis | no |
| show running-config l3vm | no |
| show running-config ldap | no |
| show running-config license | no |
| show running-config lisp | no |

| Show Commands | XML Support |
|--------------------------------------|-------------|
| show running-config lldp | no |
| show running-config macsec | no |
| show running-config mmode | no |
| show running-config monitor | no |
| show running-config mpls ldp | no |
| show running-config mpls static | no |
| show running-config mpls strip | no |
| show running-config mpls traffic-eng | no |
| show running-config msdp | no |
| show running-config mts | no |
| show running-config nat | no |
| show running-config nbm | no |
| show running-config netflow | no |
| show running-config ngoam | no |
| show running-config ntp | no |
| show running-config nv overlay | no |
| show running-config nxsdk | no |
| show running-config openflow | no |
| show running-config ospf | no |
| show running-config ospfv3 | no |
| show running-config otn | no |
| show running-config otn-isis | no |
| show running-config param-list | no |
| show running-config pim | no |
| show running-config pim6 | no |
| show running-config plb-services | no |
| show running-config poe | no |
| show running-config port-profile | no |

| Show Commands | XML Support |
|--|-------------|
| show running-config port-security | no |
| show running-config ptp | no |
| show running-config radius | no |
| show running-config rip | no |
| show running-config routing ip multicast | no |
| show running-config routing ipv6 multicast | no |
| show running-config rpm | no |
| show running-config rsvp | no |
| show running-config scheduler | no |
| show running-config section | no |
| show running-config security | no |
| show running-config segment-routing | no |
| show running-config services | no |
| show running-config sflow | no |
| show running-config sla responder | no |
| show running-config sla sender | no |
| show running-config sla twamp-server | no |
| show running-config smart-channel | no |
| show running-config snmp | no |
| show running-config spanning-tree | no |
| show running-config srte | no |
| show running-config switch | no |
| show running-config tacacs | no |
| show running-config telemetry | no |
| show running-config track | no |
| show running-config udd | no |
| show running-config vdc | no |
| show running-config vdc-all | no |

| Show Commands | XML Support |
|---|-------------|
| show running-config virtual-service | no |
| show running-config vlan | no |
| show running-config vmtracker | no |
| show running-config vpc | no |
| show running-config vrf | no |
| show running-config vrf default | no |
| show running-config vrrp | no |
| show running-config vrrpv3 | no |
| show running-config vshd | no |
| show running-config vtp | no |
| show running-config wwnm | no |
| show san-port-channel compatibility-parameters | yes |
| show san-port-channel consistency | yes |
| show san-port-channel consistency detail | yes |
| show san-port-channel database | yes |
| show san-port-channel summary | yes |
| show san-port-channel usage | yes |
| show scheduler config | yes |
| show scheduler job | yes |
| show scheduler logfile | yes |
| show scheduler schedule | yes |
| show segment-routing | yes |
| show segment-routing clients | yes |
| show segment-routing ipv4 connected-prefix-sid-map | yes |
| show segment-routing mpls | yes |
| show segment-routing mpls clients | yes |
| show segment-routing mpls ipv4 connected-prefix-sid-map | yes |
| show sflow | yes |

| Show Commands | XML Support |
|-----------------------------------|--------------------|
| show sflow statistics | yes |
| show smart-channel | yes |
| show snapshots | yes |
| show snapshots compare | yes |
| show snapshots compare ipv4routes | yes |
| show snapshots compare ipv6routes | yes |
| show snapshots compare summary | yes |
| show snapshots dump | yes |
| show snapshots sections | yes |
| show snmp | yes |
| show snmp community | yes |
| show snmp context | yes |
| show snmp engineID | yes |
| show snmp group | yes |
| show snmp host | yes |
| show snmp nms-statistics | yes |
| show snmp oid-statistics | yes |
| show snmp pss | no |
| show snmp roleddebug | no |
| show snmp sessions | yes |
| show snmp source-interface | yes |
| show snmp trap | yes |
| show snmp user | yes |
| show sockets client | yes |
| show sockets connection | yes |
| show sockets local-port-range | yes |
| show sockets ns-port-kiosk | yes |
| show sockets statistics | yes |

| Show Commands | XML Support |
|---|-------------|
| show sockets tcp keychain binding | yes |
| show spanning-tree | yes |
| show spanning-tree blockedports | yes |
| show spanning-tree bridge | yes |
| show spanning-tree inconsistentports | yes |
| show spanning-tree interface | yes |
| show spanning-tree issu-impact | yes |
| show spanning-tree mst | yes |
| show spanning-tree mst configuration | yes |
| show spanning-tree mst configuration digest | yes |
| show spanning-tree mst interface | yes |
| show spanning-tree pathcost method | yes |
| show spanning-tree root | yes |
| show spanning-tree summary | yes |
| show spanning-tree summary totals | yes |
| show sprom | yes |
| show srte pce ipv4 peer | yes |
| show srte policy | yes |
| show srte policy fh | yes |
| show ssh key | yes |
| show ssh server | yes |
| show ssx details | yes |
| show ssx exporter | yes |
| show ssx monitor | yes |
| show ssx record | yes |
| show startup-config | no |
| show startup-config aaa | no |
| show startup-config aclog | no |

| Show Commands | XML Support |
|---|--------------------|
| show startup-config aclmgr | no |
| show startup-config adjmgr | no |
| show startup-config analytics | no |
| show startup-config arp | no |
| show startup-config assoc | no |
| show startup-config backup | no |
| show startup-config bfd | no |
| show startup-config bgp | no |
| show startup-config bloggerd | no |
| show startup-config callhome | no |
| show startup-config catena | no |
| show startup-config cdp | no |
| show startup-config cert-enroll | no |
| show startup-config cfs | no |
| show startup-config config-profile | no |
| show startup-config copp | no |
| show startup-config dhcp | no |
| show startup-config diagnostic | no |
| show startup-config dot1x | no |
| show startup-config ecp | no |
| show startup-config eem | no |
| show startup-config eigrp | no |
| show startup-config eltm | no |
| show startup-config evb | no |
| show startup-config exclude | no |
| show startup-config expand-port-profile | no |
| show startup-config fabric forwarding | no |
| show startup-config fabric multicast | no |

| Show Commands | XML Support |
|---|-------------|
| show startup-config fabricpath | no |
| show startup-config fabricpath domain default | no |
| show startup-config fabricpath switch-id | no |
| show startup-config fabricpath topology | no |
| show startup-config fcoe_mgr | no |
| show startup-config glbp | no |
| show startup-config hardware-telemetry | no |
| show startup-config hsrp | no |
| show startup-config icam | no |
| show startup-config icmpv6 | no |
| show startup-config igmp | no |
| show startup-config imp | no |
| show startup-config interface | no |
| show startup-config ip | no |
| show startup-config ipqos | no |
| show startup-config ipv6 | no |
| show startup-config isis | no |
| show startup-config l3vm | no |
| show startup-config ldap | no |
| show startup-config license | no |
| show startup-config lisp | no |
| show startup-config lldp | no |
| show startup-config log | no |
| show startup-config macsec | no |
| show startup-config mmode | no |
| show startup-config monitor | no |
| show startup-config mpls ldp | no |
| show startup-config mpls static | no |

| Show Commands | XML Support |
|--|-------------|
| show startup-config mpls strip | no |
| show startup-config mpls traffic-eng | no |
| show startup-config msdp | no |
| show startup-config mts | no |
| show startup-config nat | no |
| show startup-config nbm | no |
| show startup-config netflow | no |
| show startup-config ngoam | no |
| show startup-config ntp | no |
| show startup-config nv overlay | no |
| show startup-config nx sdk | no |
| show startup-config openflow | no |
| show startup-config ospf | no |
| show startup-config ospfv3 | no |
| show startup-config otv | no |
| show startup-config otv-isis | no |
| show startup-config param-list | no |
| show startup-config pim | no |
| show startup-config pim6 | no |
| show startup-config plb-services | no |
| show startup-config poe | no |
| show startup-config port-profile | no |
| show startup-config port-security | no |
| show startup-config ptp | no |
| show startup-config radius | no |
| show startup-config rip | no |
| show startup-config routing ip multicast | no |
| show startup-config routing ipv6 multicast | no |

| Show Commands | XML Support |
|--------------------------------------|-------------|
| show startup-config rpm | no |
| show startup-config rsvp | no |
| show startup-config scheduler | no |
| show startup-config security | no |
| show startup-config segment-routing | no |
| show startup-config services | no |
| show startup-config sflow | no |
| show startup-config sla responder | no |
| show startup-config sla sender | no |
| show startup-config sla twamp-server | no |
| show startup-config smart-channel | no |
| show startup-config snmp | no |
| show startup-config srte | no |
| show startup-config switch | no |
| show startup-config tacacs | no |
| show startup-config telemetry | no |
| show startup-config track | no |
| show startup-config udd | no |
| show startup-config vdc | no |
| show startup-config vdc-all | no |
| show startup-config virtual-service | no |
| show startup-config vlan | no |
| show startup-config vmtracker | no |
| show startup-config vpc | no |
| show startup-config vrf | no |
| show startup-config vrf default | no |
| show startup-config vrrpv3 | no |
| show startup-config vshd | no |

| Show Commands | XML Support |
|---|-------------|
| show startup-config vtp | no |
| show startup-config wwnm | no |
| show summary | no |
| show switch-profile | yes |
| show switch-profile buffer | yes |
| show switch-profile peer | yes |
| show switch-profile status | yes |
| show switch-scope controller | no |
| show switching-mode | yes |
| show switching-mode fabric-speed | yes |
| show system acl | yes |
| show system auto-collect tech-support | yes |
| show system boottime | yes |
| show system clis event-history | no |
| show system config reload-pending | yes |
| show system cores | yes |
| show system default switchport | yes |
| show system dme status | yes |
| show system error-id | yes |
| show system exception-info | yes |
| show system fabric-mode | yes |
| show system fast-reload stabilization-timer | yes |
| show system image-verification | yes |
| show system inband queuing statistics | yes |
| show system inband queuing status | yes |
| show system login | yes |
| show system login failures | yes |
| show system memory-thresholds | yes |

| Show Commands | XML Support |
|-------------------------------------|-------------|
| show system mode | yes |
| show system nve infra-vlans | yes |
| show system poap | yes |
| show system pss shrink status | yes |
| show system redundancy ha status | yes |
| show system redundancy status | yes |
| show system reset-reason | yes |
| show system reset-reason module | yes |
| show system resources | no |
| show system resources | yes |
| show system resources all-modules | yes |
| show system routing mode | yes |
| show system security | yes |
| show system simulate fan-presence | no |
| show system standby manual-boot | yes |
| show system switch-mode | yes |
| show system uptime | yes |
| show system verify bios flash | yes |
| show system vlan reserved | yes |
| show table-map | yes |
| show tacacs-server | yes |
| show tacacs-server directed-request | yes |
| show tacacs-server groups | yes |
| show tacacs-server sorted | yes |
| show tacacs-server statistics | yes |
| show tech-support | no |
| show tech-support aaa | no |
| show tech-support aclmgr | no |

| Show Commands | XML Support |
|-------------------------------------|--------------------|
| show tech-support aclmgr compressed | no |
| show tech-support aclqos | no |
| show tech-support aclqos compressed | no |
| show tech-support adjmgr | no |
| show tech-support all | no |
| show tech-support all binary | no |
| show tech-support analytics | no |
| show tech-support arp | no |
| show tech-support ascii-cfg | no |
| show tech-support assoc_mgr | no |
| show tech-support backup | no |
| show tech-support bcm | no |
| show tech-support bfd | no |
| show tech-support bgp | no |
| show tech-support biosd | no |
| show tech-support bloggerd | no |
| show tech-support bloggerd-all | no |
| show tech-support bootvar | no |
| show tech-support brief | no |
| show tech-support callhome | no |
| show tech-support cdp | no |
| show tech-support cert-enroll | no |
| show tech-support cfs | no |
| show tech-support cli | no |
| show tech-support clis | no |
| show tech-support clock_manager | no |
| show tech-support commands | no |
| show tech-support controller | no |

| Show Commands | XML Support |
|--|-------------|
| show tech-support copp | no |
| show tech-support dcbx | no |
| show tech-support details | no |
| show tech-support dhclient | no |
| show tech-support dhcp | no |
| show tech-support dme | no |
| show tech-support dot1x | no |
| show tech-support ecp | no |
| show tech-support eem | no |
| show tech-support eigrp | no |
| show tech-support eltm | no |
| show tech-support ethpm | no |
| show tech-support ethport | no |
| show tech-support evb | no |
| show tech-support fabric forwarding | no |
| show tech-support fabric multicast | no |
| show tech-support fabricpath isis | no |
| show tech-support fabricpath topology | no |
| show tech-support fast-reload | no |
| show tech-support fc2 | no |
| show tech-support fcoe | no |
| show tech-support fips | no |
| show tech-support forwarding l2 multicast | no |
| show tech-support forwarding l2 multicast vdc-all | no |
| show tech-support forwarding l2 unicast | no |
| show tech-support forwarding l3 multicast | no |
| show tech-support forwarding l3 multicast detail | no |
| show tech-support forwarding l3 multicast detail vdc-all | no |

| Show Commands | XML Support |
|--|-------------|
| show tech-support forwarding l3 multicast vdc-all | no |
| show tech-support forwarding l3 unicast | no |
| show tech-support forwarding l3 unicast detail | no |
| show tech-support forwarding l3 unicast detail vdc-all | no |
| show tech-support forwarding l3 unicast vdc-all | no |
| show tech-support forwarding mpls | no |
| show tech-support forwarding multicast | no |
| show tech-support gold | no |
| show tech-support gpixm | no |
| show tech-support ha | no |
| show tech-support ha module | no |
| show tech-support ha standby | no |
| show tech-support ha_short | no |
| show tech-support hardware-telemetry | no |
| show tech-support hsrp | no |
| show tech-support hsrp brief | no |
| show tech-support icam | no |
| show tech-support icmpv6 | no |
| show tech-support im | no |
| show tech-support imp | no |
| show tech-support inband counters | no |
| show tech-support include-time | no |
| show tech-support install | no |
| show tech-support interface-vlan | no |
| show tech-support ip | no |
| show tech-support ip igmp | no |
| show tech-support ip igmp snooping | no |
| show tech-support ip msdp | no |

| Show Commands | XML Support |
|----------------------------------|-------------|
| show tech-support ip pim | no |
| show tech-support ip rsvp | no |
| show tech-support ipqos | no |
| show tech-support ipv6 | no |
| show tech-support ipv6 mld | no |
| show tech-support ipv6 multicast | no |
| show tech-support ipv6 pim | no |
| show tech-support isis | no |
| show tech-support issu | no |
| show tech-support kstack | no |
| show tech-support l2 | no |
| show tech-support l2fm | no |
| show tech-support l2fm clients | no |
| show tech-support l2fm detail | no |
| show tech-support l2fm l2dbg | no |
| show tech-support l2rib | no |
| show tech-support l3vm | no |
| show tech-support l3vpn | no |
| show tech-support lacp | no |
| show tech-support ldap | no |
| show tech-support license | no |
| show tech-support lim | no |
| show tech-support lisp | no |
| show tech-support lldp | no |
| show tech-support logging | no |
| show tech-support m2rib | no |
| show tech-support macsec | no |
| show tech-support macsec detail | no |

| Show Commands | XML Support |
|--|--------------------|
| show tech-support mfwd | no |
| show tech-support mmode | no |
| show tech-support module | no |
| show tech-support module all | no |
| show tech-support monitor | no |
| show tech-support monitor erspan | no |
| show tech-support monitorc-all | no |
| show tech-support mpls ldp | no |
| show tech-support mpls manager | no |
| show tech-support mpls static | no |
| show tech-support mpls strip | no |
| show tech-support mpls switching | no |
| show tech-support mpls traffic-eng | no |
| show tech-support mpls fwd | no |
| show tech-support multicast | no |
| show tech-support multicast-vxlan-evpn | no |
| show tech-support mvpn | no |
| show tech-support nat | no |
| show tech-support nbm | no |
| show tech-support nbm group | no |
| show tech-support netflow | no |
| show tech-support netstack | no |
| show tech-support netstack detail | no |
| show tech-support ngoam | no |
| show tech-support npacl | no |
| show tech-support npv | no |
| show tech-support ns | no |
| show tech-support ntp | no |

| Show Commands | XML Support |
|-------------------------------------|-------------|
| show tech-support nve | no |
| show tech-support nxapi | no |
| show tech-support nxsdk | no |
| show tech-support object-store | no |
| show tech-support openflow | no |
| show tech-support openflow platform | no |
| show tech-support ospf | no |
| show tech-support ospfv3 | no |
| show tech-support otv | no |
| show tech-support page | no |
| show tech-support patch | no |
| show tech-support pbr | no |
| show tech-support pfstat | no |
| show tech-support pixm | no |
| show tech-support pixm-all | no |
| show tech-support pixmc-all | no |
| show tech-support pktmgr | no |
| show tech-support platform-sdk | no |
| show tech-support plb-services | no |
| show tech-support plcmgr | no |
| show tech-support pltfm-config | no |
| show tech-support pnp | no |
| show tech-support poe | no |
| show tech-support port | no |
| show tech-support port-channel | no |
| show tech-support port-client-all | no |
| show tech-support port-profile | no |
| show tech-support port-security | no |

| Show Commands | XML Support |
|--|--------------------|
| show tech-support private-vlan | no |
| show tech-support ptp | no |
| show tech-support radius | no |
| show tech-support rip | no |
| show tech-support routing | no |
| show tech-support routing ipv6 | no |
| show tech-support routing ipv6 multicast | no |
| show tech-support routing multicast | no |
| show tech-support rpm | no |
| show tech-support sal | no |
| show tech-support san | no |
| show tech-support san-port-channel | no |
| show tech-support satmgr | no |
| show tech-support security | no |
| show tech-support segment-routing | no |
| show tech-support services | no |
| show tech-support session-mgr | no |
| show tech-support sflow | no |
| show tech-support single-gericho | no |
| show tech-support sksd | no |
| show tech-support sla responder | no |
| show tech-support sla sender | no |
| show tech-support sla twamp-server | no |
| show tech-support smartc | no |
| show tech-support smm | no |
| show tech-support snmp | no |
| show tech-support sockets | no |
| show tech-support spm | no |

| Show Commands | XML Support |
|-----------------------------------|-------------|
| show tech-support srte | no |
| show tech-support statsclient | no |
| show tech-support stp | no |
| show tech-support sup-filesys | no |
| show tech-support sysmgr | no |
| show tech-support tacacs | no |
| show tech-support telemetry | no |
| show tech-support track | no |
| show tech-support tunnel | no |
| show tech-support u2rib | no |
| show tech-support ulld | no |
| show tech-support usd-all | no |
| show tech-support vdc | no |
| show tech-support virtual-service | no |
| show tech-support vlan | no |
| show tech-support vmtracker | no |
| show tech-support vpc | no |
| show tech-support vrrp | no |
| show tech-support vrrp brief | no |
| show tech-support vrrpv3 | no |
| show tech-support vsan | no |
| show tech-support vshd | no |
| show tech-support vtp | no |
| show tech-support vvlan | no |
| show tech-support vxlan | no |
| show tech-support vxlan platform | no |
| show tech-support vxlan-evpn | no |
| show tech-support xbar | no |

| Show Commands | XML Support |
|---|--------------------|
| show tech-support xml | no |
| show tech-support xos | no |
| show telemetry control database | yes |
| show telemetry data collector brief | yes |
| show telemetry event collector stats | yes |
| show telemetry pipeline stats | yes |
| show telemetry transport | yes |
| show telemetry usability | yes |
| show telnet server | yes |
| show terminal | yes |
| show terminal output xml version | yes |
| show time-range | yes |
| show time-stamp running-config last-changed | yes |
| show trace callhome | no |
| show track | yes |
| show track brief | yes |
| show troubleshoot l2 mac vlan | no |
| show troubleshoot l3 vrf | no |
| show trunk protocol | yes |
| show ttag brief | yes |
| show udd | yes |
| show udd global | yes |
| show udd neighbors | yes |
| show user-account | yes |
| show username keypair | yes |
| show username passphrase timevalues | yes |
| show userpassphrase | yes |
| show users | yes |

| Show Commands | XML Support |
|--|-------------|
| show vdc | yes |
| show vdc current-vdc | yes |
| show vdc fcoe-vlan-range | yes |
| show vdc resource | yes |
| show vdc resource template | yes |
| show version | yes |
| show version epld | yes |
| show version image | yes |
| show version module | yes |
| show version module epld | yes |
| show virtual-service | yes |
| show virtual-service storage pool list | yes |
| show virtual-service tech-support | no |
| show virtual-service utilization name | yes |
| show virtual-service version | yes |
| show vlan | yes |
| show vlan access-list | yes |
| show vlan access-map | yes |
| show vlan all-ports | yes |
| show vlan counters | yes |
| show vlan dot1Q tag native | yes |
| show vlan fcoe | yes |
| show vlan filter | yes |
| show vlan id | yes |
| show vlan id counters | yes |
| show vlan id vn-segment | yes |
| show vlan name | yes |
| show vlan private-vlan type | yes |

| Show Commands | XML Support |
|--|-------------|
| show vlan xbrief | yes |
| show vlan xsummary | yes |
| show vmtracker | yes |
| show vmtracker certificate | yes |
| show vmtracker fabric auto-config | yes |
| show vmtracker status | yes |
| show vpc | yes |
| show vpc consistency-parameters | yes |
| show vpc consistency-parameters vlans | yes |
| show vpc fabric-ports | yes |
| show vpc orphan-ports | yes |
| show vpc peer-keepalive | yes |
| show vpc role | yes |
| show vpc statistics peer-keepalive | yes |
| show vpc statistics vpc | no |
| show vpc virtual-peerlink dest reachable | no |
| show vpc virtual-peerlink vlan consistency | no |
| show vrf | yes |
| show vrf | no |
| show vrrp | yes |
| show vrrp bfd-sessions | yes |
| show vrrpv3 | yes |
| show vrrs client | yes |
| show vrrs pathway | yes |
| show vrrs pathway address | no |
| show vrrs server | yes |
| show vrrs tag | yes |
| show vsan | yes |

| Show Commands | XML Support |
|---------------------------------------|--------------------|
| show vsan membership | yes |
| show vsan membership interface | yes |
| show vsan usage | yes |
| show vtp counters | yes |
| show vtp interface | yes |
| show vtp password | yes |
| show vtp status | yes |
| show wred-queue qos-group-map | yes |
| show wrr unicast-bandwidth | yes |
| show wrr-queue qos-group-map | yes |
| show wwn status | yes |
| show wwn switch | yes |
| show wwn test | no |
| show wwn vsan-wwn | yes |
| show xml server logging configuration | no |
| show xml server status | yes |