



## Preface

---

This preface describes the audience, organization, and conventions of the *Cisco NX-OS FCoE Command Reference Guide, Nexus 7000 and MDS 9500*. It also provides information on how to obtain related documentation.

This chapter includes the following sections:

- [Audience, page iii](#)
- [Organization, page iii](#)
- [Document Conventions, page iii](#)
- [Related Documentation, page iv](#)
- [Obtaining Documentation and Submitting a Service Request, page v](#)

## Audience

This publication is for experienced users who configure and maintain NX-OS devices.

## Organization

This reference is organized as follows:

Chapter and Title	Description
FCoE Commands	Describes the Cisco NX-OS FCoE commands for Nexus 7000 and MDS 9500 Series Switches.

## Document Conventions

Command descriptions use these conventions:

Convention	Description
<b>boldface font</b>	Commands and keywords are in boldface.
<i>italic font</i>	Arguments for which you supply values are in italics.

[ ]	Elements in square brackets are optional.
[ x   y   z ]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use these conventions:

screen font	Terminal sessions and information that the switch displays are in screen font.
<b>boldface screen font</b>	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:



**Note**

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



**Tip**

Means *the following information will help you solve a problem*.

## Related Documentation

The Cisco Nexus 7000 Series documentation is available at the following URL:

[http://www.cisco.com/en/US/products/ps9402/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps9402/tsd_products_support_series_home.html)

The Cisco MDS 9000 Series documentation is available at the following URL:

[http://www.cisco.com/en/US/products/ps5989/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps5989/tsd_products_support_series_home.html)

# Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

