



Configuring SDM Templates

- [Finding Feature Information, page 1](#)
- [Information About Configuring SDM Templates, page 1](#)
- [How to Configure SDM Templates, page 4](#)
- [Configuration Examples for SDM Templates, page 5](#)
- [Additional References for SDM Templates, page 7](#)
- [Feature History and Information for Configuring SDM Templates, page 8](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see Bug Search Tool and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

Information About Configuring SDM Templates

Restrictions for SDM Templates

The following are restrictions when using SDM templates:

The switch supports homogeneous stacking, but does not support mixed stacking.

SDM Templates

You can use Switch Database Management (SDM) templates to configure system resources to optimize support for specific features, depending on how your device is used in the network. You can select a template to provide maximum system usage for some functions: for example, use the default template to balance resources, and use the access template to obtain maximum ACL usage. The switch SDM templates allocate system hardware resources for different uses.

You can select SDM templates for IP Version 4 (IPv4) to optimize these features on switches running the IP Lite feature set:



Note

When the switch is running the LAN Base feature set, you must use the default template.

- IPv4—The IPv4 template provides maximum support for IPv4. No IPv6 support is available on this template.
- VLAN—The VLAN template provides Layer 2 functionality and the maximum number of unicast MAC addresses.
- Default—The default template gives balance to all functions providing support for Layer 2, IPv4 and IPv6 functionality.



Note

Use the default template when configuring IPv4 static routing on SVIs on switches running the LAN Base feature set. You can configure up to 16 static routes.

For information about homogeneous stacks, see the *Catalyst 2960-XR Switch Stacking Configuration Guide*.

After you change the template and the system reboots, you can use the **show sdm prefer** privileged EXEC command to verify the new template configuration. If you enter the **show sdm prefer** command before you enter the **reload** privileged EXEC command, the **show sdm prefer** command shows the template currently in use and the template that becomes active after a reload.

Related Topics

[Setting the SDM Template, on page 4](#)

[Examples: Displaying SDM Templates, on page 5](#)

SDM Template Resources

You can use SDM templates to configure system resources to optimize support for specific features, depending on how your device is used in the network. You can select a template to provide maximum system usage for some functions.

To allocate ternary content addressable memory (TCAM) resources for different usages, the switch SDM templates prioritize system resources to optimize support for certain features. These templates are supported on your device:

Table 1: Approximate Number of Feature Resources Allowed by Templates

Resource	Default	IPv4	VLAN
Unicast MAC addresses	16 K	16 K	32 K
Active VLANs/VLAN IDs	1K/4096	1K/4096	1K/4096
IPv4 IGMP groups	1 K	1 K	1 K
IPv4 unicast routes	5.25 K	24 K	0.5 K
<ul style="list-style-type: none"> • Directly connected hosts 	4 K	16 K	0.25 K
<ul style="list-style-type: none"> • Indirect routes 	1.25 K	8 K	0.25 K
IPv4 policy-based routing ACEs	0.5 K	0.375 k	0.5 K
IPv6 multicast groups:	1 K	0	1 K
<ul style="list-style-type: none"> • Directly connected IPv6 addresses 	4 K	0	0.25 K
<ul style="list-style-type: none"> • Indirect IPv6 unicast routes 	1.25 K	0	0.25 K
IPv4 MAC QoS ACEs	0.5 K	0.5 K	0.5 K
IPv4 MAC security ACEs	1 K	0.875 k	1 K
IPv6 policy-based routing ACEs	0.25 K	0	0
IPv6 QoS ACEs	0.25 K	0	0.5 K
IPv6 security ACEs	0.5 K	60	0.5 K

Related Topics

[Setting the SDM Template, on page 4](#)

[Examples: Configuring SDM Templates, on page 6](#)

SDM Templates and Switch Stacks

All stack members use the same SDM template that is stored on the stack master. When a new switch is added to a stack, as with the switch configuration and VLAN database files, the SDM configuration that is stored on the stack master overrides the template configured on an individual switch.

Version-mismatch (VM) mode has priority over SDM-mismatch mode. If a VM mode condition and an SDM-mismatch mode exist, the switch stack first attempts to resolve the VM-mode condition. You can use the **show switch** privileged EXEC command to see if any stack members are in SDM-mismatch mode.

Related Topics

[Setting the SDM Template, on page 4](#)

How to Configure SDM Templates

Setting the SDM Template

Follow these steps to use the SDM template to maximize feature usage:

Procedure

	Command or Action	Purpose
Step 1	enable Example: Switch> enable	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	configure terminal Example: Switch# configure terminal	Enters the global configuration mode.
Step 3	sdm prefer { default ipv4 vlan } Example: Switch(config)# sdm prefer default	Specifies the SDM template to be used on the switch. The keywords have these meanings: <ul style="list-style-type: none"> • default —The default template provides balance for all Layer 2, IPv4 and IPv6 functionality. • IPv4 —The IPv4 template provides maximum support for IPv4. No IPv6 support is available on this template. • VLAN —The VLAN template provides Layer 2 functionality and the maximum number of unicast MAC addresses.

	Command or Action	Purpose
		Use the no sdm prefer command to set the switch to the default template. The default template balances the use of system resources.
Step 4	end Example: Switch(config)# end	Returns to privileged EXEC mode.
Step 5	reload Example: Switch# reload	Reloads the operating system.

Related Topics

[SDM Templates, on page 2](#)

[Examples: Displaying SDM Templates, on page 5](#)

[SDM Template Resources, on page 2](#)

[Examples: Configuring SDM Templates, on page 6](#)

[SDM Templates and Switch Stacks, on page 4](#)

Configuration Examples for SDM Templates

Examples: Displaying SDM Templates

This is an example output showing the default template information:

```
Switch# show sdm prefer default

"default" template:
The selected template optimizes the resources in
the switch to support this level of features for
8 routed interfaces and 1024 VLANs.

number of unicast mac addresses:          16K
number of IPv4 IGMP groups + multicast routes: 1K
number of IPv4 unicast routes:           5.25K
  number of directly-connected IPv4 hosts: 4K
  number of indirect IPv4 routes:         1.25K
number of IPv6 multicast groups:          1K
number of directly-connected IPv6 addresses: 4K
number of indirect IPv6 unicast routes:    1.25K
number of IPv4 policy based routing aces: 0.5K
number of IPv4/MAC qos aces:              0.5K
number of IPv4/MAC security aces:         1K
number of IPv6 policy based routing aces: 0.25K
```

```

number of IPv6 qos aces:                0.25K
number of IPv6 security aces:          0.5K

```

Switch#

This is an example output showing the IPv4 template information:

Switch# **show sdm prefer ipv4**

"ipv4" template:

The selected template optimizes the resources in the switch to support this level of features for 8 routed interfaces and 1024 VLANs.

```

number of unicast mac addresses:        16K
number of IPv4 IGMP groups + multicast routes: 1K
number of IPv4 unicast routes:         24K
  number of directly-connected IPv4 hosts: 16K
  number of indirect IPv4 routes:       8K
number of IPv6 multicast groups:        0
number of directly-connected IPv6 addresses: 0
number of indirect IPv6 unicast routes:  0
number of IPv4 policy based routing aces: 0.375k
number of IPv4/MAC qos aces:           0.5K
number of IPv4/MAC security aces:       0.875k
number of IPv6 policy based routing aces: 0
number of IPv6 qos aces:                0
number of IPv6 security aces:           60

```

This is an example output showing the VLAN template information:

Switch# **show sdm prefer vlan**

"vlan" template:

The selected template optimizes the resources in the switch to support this level of features for 8 routed interfaces and 1024 VLANs.

```

number of unicast mac addresses:        32K
number of IPv4 IGMP groups + multicast routes: 1K
number of IPv4 unicast routes:         0.5K
  number of directly-connected IPv4 hosts: 0.25K
  number of indirect IPv4 routes:       0.25K
number of IPv6 multicast groups:        1K
number of directly-connected IPv6 addresses: 0.25K
number of indirect IPv6 unicast routes:  0.25K
number of IPv4 policy based routing aces: 0.5K
number of IPv4/MAC qos aces:           0.5K
number of IPv4/MAC security aces:       1K
number of IPv6 policy based routing aces: 0
number of IPv6 qos aces:                0.5K
number of IPv6 security aces:           0.5K

```

Related Topics

- [Setting the SDM Template, on page 4](#)
- [SDM Templates, on page 2](#)

Examples: Configuring SDM Templates

This example shows how to configure the VLAN template:

```
Switch(config)# sdm prefer vlan
Switch(config)# exit
Switch# reload
Proceed with reload? [confirm]
```

Related Topics

[Setting the SDM Template, on page 4](#)

[SDM Template Resources, on page 2](#)

Additional References for SDM Templates

Related Documents

Related Topic	Document Title
SDM commands	<i>Catalyst 2960-XR Switch System Management Command Reference</i>

Standards and RFCs

Standard/RFC	Title
None	—

MIBs

MIB	MIBs Link
All supported MIBs for this release.	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

Technical Assistance

Description	Link
<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>	<p>http://www.cisco.com/support</p>

Feature History and Information for Configuring SDM Templates

Release	Modification
Cisco IOS 15.0(2)EX1	This feature was introduced.