

Configuring Secure Storage

- Information About Secure Storage, on page 1
- Enabling Secure Storage, on page 1
- Disabling Secure Storage, on page 2
- Verifying the Status of Encryption, on page 3
- Feature Information for Secure Storage, on page 3

Information About Secure Storage

Secure Storage feature allows you to secure critical configuration information by encrypting it. It encrypts asymmetric key-pairs, pre-shared secrets, the type 6 password encryption key and certain credentials. An instance-unique encryption key is stored in the hardware trust anchor to prevent it from being compromised.

Enabling Secure Storage

Before you begin

By default, this feature is disabled.

SUMMARY STEPS

- 1. configure terminal
- 2. service private-config-encryption
- 3. end
- 4. write memory

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal	Enters the global configuration mode.
	Example:	
	Device# configure terminal	

	Command or Action	Purpose
Step 2	service private-config-encryption	Enables the Secure Storage feature on your device.
	Example:	
	Device(config)# service private-config-encryption	
Step 3	end	Returns to privileged EXEC mode.
	Example:	
	Device(config)# end	
Step 4	write memory	Encrypts the private-config file and saves the file in an
	Example:	encrypted format.
	Device# write memory	

Disabling Secure Storage

Before you begin

To disable Secure Storage feature on a device, perform this task:

SUMMARY STEPS

- 1. configure terminal
- 2. no service private-config-encryption
- end
- 4. write memory

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal	Enters the global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	no service private-config-encryption	Disables the Secure Storage feature on your device. When
	Example:	secure storage is disabled, all the user data is stored in plain text in the NVRAM
	Device(config)# no service	text in the IV V KAIVI.
	private-config-encryption	
Step 3	end	Returns to privileged EXEC mode.
	Example:	
	Device(config)# end	

	Command or Action	Purpose
Step 4	write memory	Decrypts the private-config file and saves the file in plane
	Example:	format.
	Device# write memory	

Verifying the Status of Encryption

Use the **show parser encrypt file status** command to verify the status of encryption. The following command output indicates that the feature is available but the file is not encrypted. The file is in 'plain text' format.

Device#show parser encrypt file status Feature: Enabled File Format: Plain Text Encryption Version: Ver1

Feature Information for Secure Storage

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Fuji 16.9.2	Secure Storage	Secure Storage feature allows you to secure critical configuration information by encrypting it. It encrypts asymmetric key-pairs, pre-shared secrets, the type 6 password encryption key and certain credentials. An instance-unique encryption key is stored in the hardware trust anchor to prevent it from being compromised.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to http://www.cisco.com/go/cfn.

Feature Information for Secure Storage