



Getting Started

This chapter contains the following section:

- [Getting Started, on page 1](#)

Getting Started

This section will guide you on how to install and manage your device.

Click on **Getting Started** to access the page where you can use the various links and follow the on-screen instructions to quickly configure your switch.

Basic or Advanced Display Mode

The switch's WEB GUI includes hundreds of configuration and display pages. These pages are divided into the following display modes:

- Basic—Basic subset of configuration options.
- Advanced—Full set of configuration options are available

When switching from one mode to another, any configuration which was made on the page (without Apply) is deleted.

Initial Setup

Change Management Applications and Services	TCP/UDP Services
Change Device IP Address	IPv4 Interface
Create VLAN	VLAN Settings
Configure Port Settings	Port Settings

Device Status

System Summary	System Summary
Port Statistics	Interface

RMON Statistics	Statistics
View Log	RAM Memory

Quick Access

Change Device Password	User Accounts
Upgrade Device Software	Firmware Operations
Backup Device Configuration	File Operations
Create MAC-Based ACL	MAC-Based ACL
Create IP-Based ACL	IPv4-based ACL
Configure QoS	QoS Properties
Configure SPAN	Session Sources

There are two hot links on the Getting Started page that take you to Cisco web pages for more information. Clicking on the Support link takes you to the device product support page, and clicking on the Forums link takes you to the Support Community page.