

Supported Platforms

To display the EnergyWise version and the Cisco IOS software running on the domain member, use the **show energywise version** and **show version** privileged EXEC command-line interface (CLI) commands.

You can also go to the toolkit on the Cisco Developer Network at <http://developer.cisco.com/web/esdk/home> to get this information.

EnergyWise Phase 1

The EnergyWise version is EnergyWise Specification 0.1.12.

Table A-1 Cisco Domain Members Supporting EnergyWise Specification 0.1.12

Network Device	Minimum Cisco IOS Release
Catalyst 3750-E switch	12.2(50)SE
Catalyst 3750 switch	12.2(50)SE
Catalyst 3560-E switch	12.2(50)SE
Catalyst 3560 switch	12.2(50)SE
Catalyst 2975 switch	12.2(52)SE
Catalyst 2960 switch running the LAN base image	12.2(50)SE
Cisco Catalyst Blade Switch 3040 for FSC	12.2(50)SE
Cisco Catalyst Blade Switch 3130 and 3032 for Dell	12.2(50)SE
Cisco Catalyst Blade Switch 3030 for Dell	12.2(50)SE
Cisco Catalyst Blade Switch 3120 for HP	12.2(50)SE
Cisco Catalyst Blade Switch 3020 for HP	12.2(50)SE
Cisco Catalyst Switch Module 3110 and 3012 for IBM BladeCenter	12.2(50)SE

EnergyWise Phase 2

The EnergyWise version is EnergyWise Specification 0.6.n.

Table A-2 Cisco Domain Members Supporting EnergyWise Specification 0.6.n

Network Device	Minimum Cisco IOS Release
Catalyst 3750-E switches	12.2(52)SE
Catalyst 3750 switches except the Catalyst 3750G-24WS, 3750G-16TD, and 3750V2 switches	12.2(52)SE
Catalyst 3560-E switches	12.2(52)SE
Catalyst 3560 switches	12.2(52)SE
Catalyst 2975 switches	12.2(52)SE
Catalyst 2960 switches	12.2(52)SE
Catalyst 2918 switches	12.2(52)SE