



INDEX

Numerics

- 802.1Q tunnel ports
 - and QoS guidelines [2-234, 2-264](#)
 - configuring [2-642](#)
 - displaying [2-399](#)
 - limitations [2-643](#)
- 802.1x
 - and switchport modes [2-643](#)
 - See also port-based authentication
 - violation error recovery [2-97](#)

A

- aaa accounting dot1x command [2-1](#)
- aaa authentication dot1x command [2-3](#)
- AAA methods [2-3](#)
- abort command [2-701](#)
- access control entries
 - See ACEs
- access control lists
 - See ACLs
- access groups
 - IP [2-117](#)
 - MAC, displaying [2-470](#)
- access lists
 - IP [2-117](#)
 - on Layer 2 interfaces [2-117](#)
- access map configuration mode [2-221](#)
- access mode [2-642](#)
- access ports [2-642](#)
- ACEs [2-72, 2-291](#)

ACLs

- deny [2-70](#)
- displaying [2-373](#)
- for non-IP protocols [2-199](#)
- matching [2-221](#)
- permit [2-289](#)
- action command [2-5](#)
- address aliasing [2-278](#)
- aggregate-port learner [2-285](#)
- allowed VLANs [2-661](#)
- Any Transport over MPLS
 - See AToM
- apply command [2-701](#)
- archive download-sw command [2-7](#)
- archive tar command [2-9](#)
- archive upload-sw command [2-12](#)
- arp access-list command [2-13](#)
- AToM, debug messages [B-23](#)
- audience [xix](#)
- authentication failed VLAN
 - See dot1x auth-fail vlan
- auth-fail max-attempts
 - See dot1x auth-fail max-attempts
- auth-fail vlan
 - See dot1x auth-fail vlan
- authorization state of controlled port [2-86](#)
- autonegotiation of duplex mode [2-93](#)
- auto-QoS
 - See QoS
- auto qos voip command [2-15](#)

B

BackboneFast, for STP [2-577](#)

backup interfaces

- configuring [2-636](#)
- displaying [2-420](#)

bandwidth command [2-20](#)

boot (boot loader) command [A-2](#)

boot bootlpr command [2-23](#)

boot config-file command [2-24](#)

boot enable-break command [2-25](#)

boot helper command [2-26](#)

boot helper-config file command [2-27](#)

booting

- displaying environment variables [2-382](#)
- interrupting [2-25](#)
- IOS image [2-30](#)
- manually [2-28](#)

boot loader

- accessing [A-1](#)
- booting
 - helper image [2-26](#)
 - IOS image [A-2](#)
- directories
 - creating [A-15](#)
 - displaying a list of [A-7](#)
 - removing [A-19](#)
- displaying
 - available commands [A-12](#)
 - memory heap utilization [A-13](#)
 - version [A-26](#)
- environment variables
 - described [A-20](#)
 - displaying settings [A-20](#)
 - location of [A-22](#)
 - setting [A-20](#)
 - unsetting [A-24](#)

boot loader (continued)

- files
 - copying [A-5](#)
 - deleting [A-6](#)
 - displaying a list of [A-7](#)
 - displaying the contents of [A-4, A-16, A-23](#)
 - renaming [A-17](#)
- file system
 - formatting [A-10](#)
 - initializing flash [A-9](#)
 - running a consistency check [A-11](#)
- prompt [A-1](#)
- resetting the system [A-18](#)

boot manual command [2-28](#)

boot private-config-file command [2-29](#)

boot system command [2-30](#)

BPDU filtering, for spanning tree [2-578, 2-612](#)

BPDU guard, for spanning tree [2-580, 2-612](#)

broadcast storm control [2-629](#)

bundling characteristics, UNI [2-102](#)

C

candidate switches

- See clusters

cat (boot loader) command [A-4](#)

caution, description [xx](#)

CDP, enabling protocol tunneling for [2-178](#)

CFM [2-284](#)

CFM as OAM protocol [2-284](#)

channel-group command [2-31](#)

channel-protocol command [2-35](#)

Cisco SoftPhone, auto-QoS configuration [2-15](#)

class command [2-36](#)

class-map command [2-40](#)

class maps

- creating [2-40](#)
- defining the match criteria [2-223](#)
- displaying [2-384](#)

- class of service
 - See CoS
 - clear ip arp inspection log command [2-42](#)
 - clear ip arp inspection statistics command [2-43](#)
 - clear l2protocol-tunnel counters command [2-46](#)
 - clear lacp command [2-47](#)
 - clear mac address-table command [2-48, 2-49](#)
 - clear pagp command [2-50](#)
 - clear spanning-tree counters command [2-51](#)
 - clear spanning-tree detected-protocols command [2-52](#)
 - clear vmps statistics command [2-53](#)
 - clear vtp counters command [2-54](#)
 - cluster commander-address command [2-55](#)
 - cluster discovery hop-count command [2-57](#)
 - cluster enable command [2-58](#)
 - cluster holdtime command [2-59](#)
 - cluster member command [2-60](#)
 - cluster outside-interface command [2-62](#)
 - cluster run command [2-63](#)
 - clusters
 - adding candidates [2-60](#)
 - binding to HSRP group [2-64](#)
 - building manually [2-60](#)
 - communicating with
 - devices outside the cluster [2-62](#)
 - members by using Telnet [2-337](#)
 - debug messages, display [B-5](#)
 - displaying
 - candidate switches [2-387](#)
 - debug messages [B-5](#)
 - member switches [2-389](#)
 - status [2-385](#)
 - hop-count limit for extended discovery [2-57](#)
 - HSRP standby groups [2-64](#)
 - redundancy [2-64](#)
 - SNMP trap [2-568](#)
 - cluster standby-group command [2-64](#)
 - cluster timer command [2-66](#)
 - command modes defined [1-1](#)
 - command switch
 - See clusters
 - configuration, initial
 - See hardware installation guide
 - configuration files
 - password recovery disable considerations [A-1](#)
 - specifying the name [2-24, 2-29](#)
 - configuring multiple interfaces [2-113](#)
 - config-vlan mode
 - commands [2-687](#)
 - description [1-4](#)
 - entering [2-686](#)
 - summary [1-2](#)
 - conventions
 - command [xx](#)
 - for examples [xx](#)
 - publication [xx](#)
 - text [xx](#)
 - copy (boot loader) command [A-5](#)
 - CoS
 - assigning default value to incoming packets [2-232](#)
 - assigning to Layer 2 protocol packets [2-182](#)
 - overriding the incoming value [2-232](#)
 - CoS-to-DSCP map [2-238](#)
 - CPU ASIC statistics, displaying [2-391](#)
-
- ## D
- debug autoqos command [B-2](#)
 - debug backup command [B-4](#)
 - debug cluster command [B-5](#)
 - debug dot1x command [B-7](#)
 - debug dtp command [B-8](#)
 - debug etherchannel command [B-9](#)
 - debug interface command [B-12](#)
 - debug ip dhcp snooping command [B-13](#)
 - debug ip igmp filter command [B-14](#)
 - debug ip igmp max-groups command [B-15](#)
 - debug ip igmp snooping command [B-16](#)

- debug ip verify source packet command [B-17](#)
- debug lacp command [B-18](#)
- debug mac-notification command [B-19](#)
- debug matm command [B-20](#)
- debug matm move update command [B-21](#)
- debug monitor command [B-22](#)
- debug mpls atom command [B-23](#)
- debug mpls l2transport vlan command [B-24](#)
- debug mvrdbg command [B-25](#)
- debug nvram command [B-26](#)
- debug pagp command [B-27](#)
- debug platform acl command [B-28](#)
- debug platform backup interface command [B-30](#)
- debug platform cfm command [B-29](#)
- debug platform cpu-queues command [B-31](#)
- debug platform dot1x command [B-33](#)
- debug platform etherchannel command [B-34](#)
- debug platform fallback-bridging command [B-35](#)
- debug platform forw-team command [B-36](#)
- debug platform ip arp inspection command [B-37](#)
- debug platform ip igmp snooping command [B-38](#)
- debug platform ip multicast command [B-40](#)
- debug platform ip unicast command [B-42](#)
- debug platform led command [B-44](#)
- debug platform matm command [B-45](#)
- debug platform messaging command [B-46](#)
- debug platform mpls command [B-47](#)
- debug platform phy command [B-48](#)
- debug platform pm command [B-49](#)
- debug platform port-asic command [B-51](#)
- debug platform port-security command [B-52](#)
- debug platform qos-acl-tcam command [B-53](#)
- debug platform remote-commands command [B-54](#)
- debug platform resource-manager command [B-55](#)
- debug platform snmp command [B-56](#)
- debug platform span command [B-57](#)
- debug platform supervisor-asic command [B-58](#)
- debug platform sw-bridge command [B-59](#)
- debug platform team command [B-60](#)
- debug platform udd command [B-62](#)
- debug platform vlan command [B-63](#)
- debug pm command [B-64](#)
- debug port-security command [B-66](#)
- debug qos-manager command [B-67](#)
- debug spanning-tree backbonefast command [B-70](#)
- debug spanning-tree bpdu command [B-71](#)
- debug spanning-tree bpdu-opt command [B-72](#)
- debug spanning-tree command [B-68](#)
- debug spanning-tree mstp command [B-73](#)
- debug spanning-tree switch command [B-75](#)
- debug spanning-tree uplinkfast command [B-77](#)
- debug sw-vlan command [B-78](#)
- debug sw-vlan ifs command [B-80](#)
- debug sw-vlan notification command [B-81](#)
- debug sw-vlan vtp command [B-82](#)
- debug udd command [B-84](#)
- debug vqpc command [B-86](#)
- debug xconnect command [B-87](#)
- default template [2-354](#)
- define interface-range command [2-67](#)
- delete (boot loader) command [A-6](#)
- delete command [2-69](#)
- deny (ARP access-list configuration) command [2-73](#)
- deny command [2-70](#)
- detect mechanism, causes [2-95](#)
- DHCP snooping
 - accepting untrusted packets from edge switch [2-142](#)
 - enabling
 - on a VLAN [2-148](#)
 - option 82 [2-140, 2-142](#)
 - trust on an interface [2-146](#)
 - rate limiting [2-145](#)
- DHCP snooping binding database
 - binding file, configuring [2-138](#)
 - bindings
 - adding [2-136](#)
 - deleting [2-136](#)
 - clearing database agent statistics [2-44](#)

DHCP snooping binding database (continued)

- database agent, configuring [2-138](#)
- displaying
 - database agent status [2-442, 2-444](#)
 - renewing [2-341](#)
- dir (boot loader) command [A-7](#)
- directories, deleting [2-69](#)
- documentation, related [xx](#)
- document conventions [xx](#)
- domain name, VTP [2-710, 2-714](#)
- domains, CFM [2-284](#)
- dot1x auth-fail max-attempts [2-75](#)
- dot1x auth-fail vlan [2-77](#)
- dot1x default command [2-79](#)
- dot1x guest-vlan command [2-80](#)
- dot1x host-mode command [2-82](#)
- dot1x initialize command [2-83](#)
- dot1x max-req command [2-84, 2-85](#)
- dot1x port-control command [2-86](#)
- dot1x re-authenticate command [2-88](#)
- dot1x reauthentication command [2-89](#)
- dot1x system-auth-control command [2-90](#)
- dot1x timeout command [2-91](#)
- dropping packets, with ACL matches [2-5](#)
- drop threshold, Layer 2 protocol tunneling [2-178](#)
- DSCP-to-CoS map [2-238](#)
- DSCP-to-DSCP-mutation map [2-238](#)
- DTP [2-643](#)
- DTP flap
 - error detection for [2-95](#)
 - error recovery timer [2-97](#)
- dual-level policy maps [2-307](#)
- duplex command [2-93](#)
- dynamic-access ports
 - configuring [2-634](#)
 - restrictions [2-635](#)

dynamic ARP inspection

- ARP ACLs
 - apply to a VLAN [2-122](#)
 - define [2-13](#)
 - deny packets [2-73](#)
 - display [2-377](#)
 - permit packets [2-292](#)
- clear
 - log buffer [2-42](#)
 - statistics [2-43](#)
- display
 - ARP ACLs [2-377](#)
 - configuration and operating state [2-435](#)
 - log buffer [2-435](#)
 - statistics [2-435](#)
 - trust state and rate limit [2-435](#)
- enable per VLAN [2-132](#)
- error detection for [2-97](#)
- log buffer
 - clear [2-42](#)
 - configure [2-126](#)
 - display [2-435](#)
- rate-limit incoming ARP packets [2-124](#)
- statistics
 - clear [2-43](#)
 - display [2-435](#)
- trusted interface state [2-128](#)
- type of packet logged [2-133](#)
- validation checks [2-130](#)

dynamic auto VLAN membership mode [2-642](#)

dynamic desirable VLAN membership mode [2-642](#)

Dynamic Host Configuration Protocol (DHCP)

- See DHCP snooping

Dynamic Trunking Protocol

- See DTP

E

EAP-request/identity frame

- maximum number to send [2-85](#)
- response time before retransmitting [2-91](#)

E-LMI

- enabling [2-100](#)
- mapping [2-102](#)

encapsulation methods [2-661](#)environment variables, displaying [2-382](#)

EoMPLS

- configuring [2-272, 2-718](#)
- displaying [2-511](#)

errdisable detect cause command [2-95](#)errdisable recovery command [2-97](#)error conditions, displaying [2-408](#)error disable detection [2-95](#)error-disabled interfaces, displaying [2-420](#)

EtherChannel

- assigning Ethernet interface to channel group [2-31](#)
- creating port-channel logical interface [2-111](#)
- debug EtherChannel/PAgP, display [B-9](#)
- debug platform-specific events, display [B-34](#)
- displaying [2-412](#)
- enabling Layer 2 protocol tunneling for
 - LACP [2-179](#)
 - PAgP [2-179](#)
 - UDLD [2-179](#)

interface information, displaying [2-420](#)

LACP

- clearing channel-group information [2-47](#)
- debug messages, display [B-18](#)
- displaying [2-461](#)
- modes [2-31](#)
- port priority for hot-standby ports [2-183](#)
- restricting a protocol [2-35](#)
- system priority [2-185](#)

load-distribution methods [2-310](#)**EtherChannel (continued)**

PAgP

- aggregate-port learner [2-285](#)
- clearing channel-group information [2-50](#)
- debug messages, display [B-27](#)
- displaying [2-521](#)
- error detection for [2-95](#)
- error recovery timer [2-97](#)
- learn method [2-285](#)
- modes [2-31](#)
- physical-port learner [2-285](#)
- priority of interface for transmitted traffic [2-287](#)

ethermet lmi ce command [2-100](#)Ethernet controller, internal register display [2-393](#)ethernet evc command [2-99](#)ethernet lim global command [2-100](#)ethernet lmi ce-vlan map command [2-102, 2-104](#)ethernet lmi command [2-100](#)

Ethernet Local Management Interface

See E-LMI

Ethernet over MPLS

See EoMPLS

Ethernet over multiprotocol label switching

See EoMPLS

Ethernet service

- debugging [B-10](#)
- displaying [2-415](#)

Ethernet service instance [2-356](#)Ethernet service interfaces [2-418](#)Ethernet statistics, collecting [2-353](#)Ethernet UNI configuration [2-106](#)ethernet uni id command [2-108](#)

Ethernet virtual connections

See EVCs

EVC configuration mode [2-99](#)EVCs [2-99](#)

and VLANs [2-106](#)

service instances [2-356](#)

UNI counts [2-684](#)

EVC service

point-to-multipoint [2-684](#)

point-to-point [2-684](#)

examples, conventions for [xx](#)

exit command, VLAN database mode [2-701](#)

extended discovery of candidate switches [2-57](#)

extended-range VLANs

and allowed VLAN list [2-662](#)

and pruning-eligible list [2-662](#)

configuring [2-686](#)

extended system ID for STP [2-586](#)

F

fan information, displaying [2-405](#)

file name, VTP [2-710](#)

files, deleting [2-69](#)

flash_init (boot loader) command [A-9](#)

Flex Links

configuring [2-636](#)

configuring preferred VLAN [2-638](#)

displaying [2-420](#)

flowcontrol command [2-109](#)

format (boot loader) command [A-10](#)

forwarding packets, with ACL matches [2-5](#)

forwarding results, display [C-6](#)

frame forwarding information, displaying [C-6](#)

fsck (boot loader) command [A-11](#)

G

global configuration mode [1-2, 1-3](#)

H

hardware ACL statistics [2-373](#)

help (boot loader) command [A-12](#)

hop-count limit for clusters [2-57](#)

host connection, port configuration [2-641](#)

host ports, private VLANs [2-645](#)

HSRP

binding HSRP group to cluster [2-64](#)

standby group [2-64](#)

I

IEEE 802.1ag Connectivity Fault Management

See CFM

IEEE 802.1X Port Based Authentication

enabling guest VLAN supplicant [2-76](#)

IGMP filters

applying [2-151](#)

debug messages, display [B-14](#)

IGMP groups, setting maximum [2-153](#)

IGMP maximum groups, debugging [B-15](#)

IGMP profiles

creating [2-155](#)

displaying [2-447](#)

IGMP snooping

adding ports as a static member of a group [2-166](#)

displaying [2-448, 2-452, 2-454](#)

enabling the Immediate-Leave feature [2-163](#)

multicast table [2-450](#)

querier [2-159](#)

report suppression [2-161](#)

images

See software images

Immediate-Leave feature, MVR [2-280](#)

immediate-leave processing [2-163](#)

import map command [2-174](#)

initial configuration

See hardware installation guide

interface configuration mode [1-2, 1-3](#)

interface port-channel command [2-111](#)

interface range command [2-113](#)

interface-range macros [2-67](#)

- interfaces
 - assigning Ethernet interface to channel group [2-31](#)
 - configuring [2-93](#)
 - configuring multiple [2-113](#)
 - creating port-channel logical [2-111](#)
 - debug messages, display [B-12](#)
 - disabling [2-565](#)
 - displaying the MAC address table [2-482](#)
 - restarting [2-565](#)
 - interface speed, configuring [2-621](#)
 - interface vlan command [2-115](#)
 - internal registers, displaying [2-393, 2-397](#)
 - Internet Group Management Protocol
 - See IGMP
 - invalid GBIC
 - error detection for [2-95](#)
 - error recovery timer [2-97](#)
 - ip access-group command [2-117](#)
 - ip address command [2-120](#)
 - IP addresses, setting [2-120](#)
 - IP address matching [2-221](#)
 - ip arp inspection filter vlan command [2-122](#)
 - ip arp inspection limit command [2-124](#)
 - ip arp inspection log-buffer command [2-126](#)
 - ip arp inspection trust command [2-128](#)
 - ip arp inspection validate command [2-130](#)
 - ip arp inspection vlan command [2-132](#)
 - ip arp inspection vlan logging command [2-133](#)
 - IP DHCP snooping
 - See DHCP snooping
 - ip dhcp snooping binding command [2-136](#)
 - ip dhcp snooping command [2-135](#)
 - ip dhcp snooping database command [2-138](#)
 - ip dhcp snooping information option allow-untrusted command [2-142](#)
 - ip dhcp snooping information option command [2-140](#)
 - ip dhcp snooping information option format remote-id command [2-144](#)
 - ip dhcp snooping limit rate command [2-145](#)
 - ip dhcp snooping trust command [2-146](#)
 - ip dhcp snooping verify command [2-147](#)
 - ip dhcp snooping vlan command [2-148](#)
 - ip dhcp snooping vlan information option format-type circuit-id string command [2-149](#)
 - ip igmp filter command [2-151](#)
 - ip igmp max-groups command [2-153](#)
 - ip igmp profile command [2-155](#)
 - ip igmp snooping command [2-157](#)
 - ip igmp snooping querier command [2-159](#)
 - ip igmp snooping report-suppression command [2-161](#)
 - ip igmp snooping vlan immediate-leave command [2-163](#)
 - ip igmp snooping vlan mrouter command [2-164](#)
 - ip igmp snooping vlan static command [2-166](#)
 - IP multicast addresses [2-277](#)
 - IP phones
 - auto-QoS configuration [2-15](#)
 - trusting packets sent from [2-263](#)
 - IP-precedence-to-DSCP map [2-238](#)
 - ip source binding command [2-168](#)
 - IP source guard
 - disabling [2-172](#)
 - displaying
 - binding entries [2-456](#)
 - configuration [2-457](#)
 - enabling [2-172](#)
 - static IP source bindings [2-168](#)
 - ip ssh command [2-170](#)
 - ip verify source command [2-172](#)
 - ip vrf (global configuration) command [2-173](#)
 - ip vrf (interface configuration) command [2-176](#)
-
- ## J
- jumbo frames
 - See MTU

L

l2protocol-tunnel command [2-178](#)
 l2protocol-tunnel cos command [2-182](#)
 label distribution protocol
 See LDP
 LACP
 See EtherChannel
 lacp port-priority command [2-183](#)
 lacp system-priority command [2-185](#)
 Layer 2 mode, enabling [2-632](#)
 Layer 2 protocol ports, displaying [2-459](#)
 Layer 2 protocol tunnel
 and EtherChannels [2-179](#)
 CoS [2-182](#)
 counters, clearing [2-46](#)
 error detection for [2-95](#)
 error recovery [2-180](#)
 error recovery timer [2-97](#)
 setting thresholds for [2-180](#)
 Layer 2 traceroute
 IP addresses [2-675](#)
 MAC addresses [2-672](#)
 Layer 3 mode, enabling [2-632](#)
 LDP
 destination [2-272](#)
 holdtime [2-274](#)
 line configuration mode [1-2, 1-5](#)
 Link Aggregation Control Protocol
 See EtherChannel
 link flap
 error detection for [2-95](#)
 error recovery timer [2-97](#)
 link state group command [2-187](#)
 link state track command [2-189](#)
 load-distribution methods for EtherChannel [2-310](#)
 location (global configuration) command [2-190](#)
 location (interface configuration) command [2-192](#)
 logging event command [2-194](#)

logging file command [2-195](#)
 logical interface [2-111](#)
 loopback error
 detection for [2-95](#)
 recovery timer [2-97](#)
 loop guard, for spanning tree [2-587, 2-591](#)

M

mac access-group command [2-197](#)
 MAC access-groups, displaying [2-470](#)
 MAC access list configuration mode [2-199](#)
 mac access-list extended command [2-199](#)
 MAC access lists [2-70](#)
 MAC addresses
 disabling MAC address learning per VLAN [2-202](#)
 displaying
 aging time [2-476](#)
 all [2-474](#)
 dynamic [2-480](#)
 Layer 2 multicast entries [2-487](#)
 MAC address-table move updates [2-485](#)
 notification settings [2-484, 2-489](#)
 number of addresses in a VLAN [2-478](#)
 per interface [2-482](#)
 per VLAN [2-493](#)
 static [2-491](#)
 static and dynamic entries [2-472](#)
 dynamic
 aging time [2-201](#)
 deleting [2-48](#)
 displaying [2-480](#)
 enabling MAC address notification [2-206](#)
 enabling MAC address-table move update [2-204](#)
 matching [2-221](#)

MAC addresses (continued)

static

adding and removing [2-208](#)displaying [2-491](#)dropping on an interface [2-209](#)tables [2-474](#)MAC address notification, debugging [B-19](#)mac address-table aging-time [2-197](#), [2-221](#)mac address-table aging-time command [2-201](#)mac address-table learning command [2-202](#)mac address-table move update [2-204](#)mac address-table move update command [2-204](#)mac address-table notification command [2-206](#)mac address-table static command [2-208](#)mac address-table static drop command [2-209](#)macro description command [2-214](#)macro global command [2-215](#)macro global description command [2-218](#)macro name command [2-219](#)

macros

adding a description [2-214](#)adding a global description [2-218](#)applying [2-215](#)creating [2-219](#)displaying [2-523](#)specifying parameter values [2-215](#)tracing [2-215](#)macros, interface range [2-67](#), [2-113](#)maintenance end points [2-684](#)

manual

audience [xix](#)purpose of [xix](#)

maps

QoS

defining [2-238](#)displaying [2-503](#)**maps (continued)**

VLAN

creating [2-698](#)defining [2-221](#)displaying [2-556](#)match (access-map configuration) command [2-221](#)match (class-map configuration) command [2-223](#)

maximum transmission unit

See MTU

mdix auto command [2-226](#)

member switches

See clusters

memory (boot loader) command [A-13](#)mkdir (boot loader) command [A-15](#)mls qos aggregate-policer command [2-230](#)mls qos command [2-228](#)mls qos cos command [2-232](#)mls qos dscp-mutation command [2-234](#)mls qos enhanced command [2-236](#)mls qos map command [2-238](#)mls qos queue-set output buffers command [2-241](#)mls qos queue-set output threshold command [2-243](#)mls qos srr-queue input bandwidth command [2-247](#)mls qos srr-queue input buffers command [2-249](#)mls qos-srr-queue input cos-map command [2-251](#)mls qos srr-queue input dscp-map command [2-253](#)mls qos srr-queue input priority-queue command [2-255](#)mls qos srr-queue input threshold command [2-257](#)mls qos-srr-queue output cos-map command [2-259](#)mls qos srr-queue output dscp-map command [2-261](#)mls qos trust command [2-263](#)mls qos vlan-based command [2-266](#)mode, MVR [2-277](#)Mode button, and password recovery [2-357](#)modes, commands [1-1](#)monitor session command [2-267](#)more (boot loader) command [A-16](#)

MPLS

MTU [2-275](#)

VCs [2-272, 2-718](#)

mpls l2transport route command [2-272, 2-511](#)

mpls ldp holdtime command [2-274](#)

mpls mtu command [2-275](#)

MSTP

displaying [2-538](#)

interoperability [2-52](#)

link type [2-589](#)

MST region

aborting changes [2-595](#)

applying changes [2-595](#)

configuration name [2-595](#)

configuration revision number [2-595](#)

current or pending display [2-595](#)

displaying [2-538](#)

MST configuration mode [2-595](#)

VLANs-to-instance mapping [2-595](#)

path cost [2-597](#)

protocol mode [2-593](#)

restart protocol migration process [2-52](#)

root port

loop guard [2-587](#)

preventing from becoming designated [2-587](#)

restricting which can be root [2-587](#)

root guard [2-587](#)

root switch

affects of extended system ID [2-586](#)

hello-time [2-600, 2-608](#)

interval between BDPUs messages [2-601](#)

interval between hello BDPUs messages [2-600, 2-608](#)

max-age [2-601](#)

maximum hop count before discarding BDU [2-602](#)

port priority for selection of [2-605](#)

primary or secondary [2-608](#)

switch priority [2-607](#)

MSTP (continued)

state changes

blocking to forwarding state [2-614](#)

enabling BPDU filtering [2-578, 2-612](#)

enabling BPDU guard [2-580, 2-612](#)

enabling Port Fast [2-612, 2-614](#)

forward-delay time [2-599](#)

length of listening and learning states [2-599](#)

rapid transition to forwarding [2-589](#)

shutting down Port Fast-enabled ports [2-612](#)

state information display [2-537](#)

MTU

configuring size [2-670](#)

displaying global setting [2-545](#)

for MPLS [2-275](#)

multicast-VRF CE [2-173, 2-176](#)

multicast group address, MVR [2-280](#)

multicast groups, MVR [2-278](#)

multicast router learning method [2-164](#)

multicast router ports, configuring [2-164](#)

multicast storm control [2-629](#)

multicast VLAN, MVR [2-277](#)

multicast VLAN registration

See MVR

multiple hosts on authorized port [2-82](#)

Multiple Spanning Tree Protocol

See MSTP

multiplexing, UNI [2-106](#)

multi VPN routing/forwarding instances in customer edge devices

See multi-VRF CE

MVR

and address aliasing [2-278](#)

configuring [2-277](#)

configuring interfaces [2-280](#)

debug messages, display [B-25](#)

displaying [2-515](#)

displaying interface information [2-517](#)

members, displaying [2-519](#)

mvr (global configuration) command [2-277](#)
 mvr (interface configuration) command [2-280](#)
 mvr vlan group command [2-281](#)

N

native VLANs [2-661](#)
 nonegotiate, DTP messaging [2-647](#)
 nonhierarchical single-level policy maps [2-307](#)
 non-IP protocols
 denying [2-70](#)
 forwarding [2-289](#)
 non-IP traffic
 access lists [2-199](#)
 denying [2-70](#)
 permitting [2-289](#)
 normal-range VLANs [2-686, 2-692](#)
 note, description **xx**
 no vlan command [2-686, 2-696](#)

O

OAM PDUs [2-104](#)
 OAM protocol [2-284](#)
 oam protocol cfm svlan command [2-284](#)
 operation, administration, and maintenance protocol
 See OAM

P

PAgP
 See EtherChannel
 pagp learn-method command [2-285](#)
 pagp port-priority command [2-287](#)
 password, VTP [2-710, 2-714](#)
 password-recovery mechanism, enabling and disabling [2-357](#)
 permit (ARP access-list configuration) command [2-292](#)
 permit command [2-289](#)

per-VLAN spanning-tree plus
 See STP
 physical-port learner [2-285](#)
 PID, displaying [2-434](#)
 PIM-DVMRP, as multicast router learning method [2-164](#)
 police aggregate command [2-296](#)
 police cir command [2-298](#)
 police cir percent command [2-302](#)
 police command [2-294](#)
 policed-DSCP map [2-238](#)
 policers
 aggregate [2-230, 2-296](#)
 displaying [2-496](#)
 policed-DSCP map [2-238](#)
 single-rate ingress [2-294](#)
 two-rate hierarchical [2-298, 2-302](#)
 policy-map command [2-306](#)
 policy maps
 applying to an interface [2-359](#)
 creating [2-306](#)
 displaying [2-526](#)
 dual-level [2-307](#)
 marking [2-364](#)
 nonhierarchical and single-level [2-307](#)
 See also policers
 See also QoS, hierarchical policies
 traffic classification
 defining the class [2-36](#)
 defining trust states [2-677](#)
 Port Aggregation Protocol
 See EtherChannel
 port-based authentication
 802.1x AAA accounting methods [2-1](#)
 AAA method list [2-3](#)
 debug messages, display [B-7](#)
 enabling 802.1x
 globally [2-90](#)
 per interface [2-86](#)
 guest VLAN [2-80](#)

port-based authentication (continued)

- host modes [2-82](#)
- initialize an interface [2-83](#)
- manual control of authorization state [2-86](#)
- multiple hosts on authorized port [2-82](#)
- periodic re-authentication
 - enabling [2-89](#)
 - time between attempts [2-91](#)
- quiet period between failed authentication exchanges [2-91](#)
- re-authenticating 802.1x-enabled ports [2-88](#)
- resetting configurable 802.1x parameters [2-79](#)
- statistics and status display [2-400](#)
- switch-to-authentication server retransmission time [2-91](#)
- switch-to-client frame-retransmission number [2-84, 2-85](#)
- switch-to-client retransmission time [2-91](#)

port-channel load-balance command [2-310](#)

Port Fast, for spanning tree [2-614](#)

port ranges, defining [2-67](#)

ports, debugging [B-64](#)

ports, protected [2-659](#)

port security

- aging [2-653](#)
- debug messages, display [B-66](#)
- enabling [2-649](#)
- violation error recovery [2-97](#)

port trust states for QoS [2-263](#)

port types, MVR [2-280](#)

power information, displaying [2-405](#)

priority command [2-312](#)

priority-queue command [2-314](#)

private-vlan command [2-316](#)

private-vlan mapping command [2-319](#)

private VLANs

- association [2-657](#)
- configuring [2-316](#)
- configuring ports [2-645](#)
- displaying [2-551](#)

private VLANs (continued)

- host ports [2-645](#)
- mapping
 - configuring [2-657](#)
 - promiscuous ports [2-645](#)
- privileged EXEC mode [1-2, 1-3](#)
- product identification information, displaying [2-434](#)
- promiscuous ports, private VLANs [2-645](#)
- protected ports, displaying [2-425](#)
- pruning
 - VLANs [2-661](#)
 - VTP
 - displaying interface information [2-420](#)
 - enabling [2-710, 2-714](#)
- pruning-eligible VLAN list [2-663](#)
- PVST+
 - See STP

Q**QoS**

- and 802.1Q tunneling guidelines [2-224, 2-234, 2-264](#)
- applying bandwidth to only one ES port [2-236](#)
- auto-QoS
 - configuring [2-15](#)
 - debug messages, display [1-6, B-2](#)
 - displaying [2-378](#)
- class maps
 - creating [2-40](#)
 - defining the match criteria [2-223](#)
 - displaying [2-384](#)
- defining the CoS value for an incoming packet [2-232](#)
- displaying configuration information [2-378, 2-495](#)
- DSCP trusted ports
 - applying DSCP-to-DSCP-mutation map to [2-234](#)
 - defining DSCP-to-DSCP-mutation map [2-238](#)
- egress queues
 - displaying queue-set settings [2-508](#)

QoS (continued)

- egress queue-sets
 - allocating buffers [2-241](#)
 - defining the CoS output queue threshold map [2-259](#)
 - defining the DSCP output queue threshold map [2-261](#)
 - displaying buffer allocations [2-499](#)
 - displaying CoS output queue threshold map [2-503](#)
 - displaying DSCP output queue threshold map [2-503](#)
 - displaying queueing strategy [2-499](#)
 - displaying queue-set settings [2-506](#)
 - enabling bandwidth shaping and scheduling [2-625](#)
 - enabling bandwidth sharing and scheduling [2-627](#)
 - enabling the priority queue [2-314](#)
 - limiting the maximum output on a port [2-623](#)
 - mapping a port to a queue-set [2-323](#)
 - mapping CoS values to a queue and threshold [2-259](#)
 - mapping DSCP values to a queue and threshold [2-261](#)
 - setting maximum and reserved memory allocations [2-243](#)
 - setting WTD thresholds [2-243](#)
 - SRR and priority queue interaction [2-314](#)
- enabling [2-228](#)

QoS (continued)

- hierarchical policies
 - applying to an interface [2-359](#)
 - average-rate traffic shaping on a class [2-371](#)
 - bandwidth allocation for a class [2-20](#)
 - class-based weighted fair queueing [2-20, 2-37](#)
 - creating a service policy [2-362](#)
 - displaying [2-526](#)
 - DSCP-based WRED [2-327](#)
 - IP precedence-based WRED [2-334](#)
 - marking [2-364](#)
 - strict priority queueing (LLQ) [2-312](#)
 - tail drop [2-321](#)
 - two-rate policers [2-298, 2-302](#)
 - WRED [2-324](#)
 - WRED average queue size calculation [2-331](#)
- ingress queues
 - allocating buffers [2-249](#)
 - assigning SRR scheduling weights [2-247](#)
 - defining the CoS input queue threshold map [2-251](#)
 - defining the DSCP input queue threshold map [2-253](#)
 - displaying buffer allocations [2-499](#)
 - displaying CoS input queue threshold map [2-503](#)
 - displaying DSCP input queue threshold map [2-503](#)
 - displaying queueing strategy [2-499](#)
 - displaying settings for [2-497](#)
 - enabling the priority queue [2-255](#)
 - mapping CoS values to a queue and threshold [2-251](#)
 - mapping DSCP values to a queue and threshold [2-253](#)
 - setting WTD thresholds [2-257](#)
- maps
 - defining [2-238, 2-251, 2-253, 2-259, 2-261](#)
 - displaying [2-503](#)

QoS (continued)

policy maps

- applying an aggregate policer [2-296](#)
- applying to an interface [2-359](#)
- creating [2-306](#)
- defining aggregate policers [2-230](#)
- defining single-rate ingress policers [2-294](#)
- displaying policers [2-496](#)
- displaying policy maps [2-526](#)
- dual-level [2-307](#)
- hierarchical on non-ES ports [2-307](#)
- marking [2-364](#)
- policed-DSCP map [2-238](#)
- traffic classifications [2-36](#)
- trust states [2-677](#)

port trust states [2-263](#)

statistics

- in-profile and out-of-profile packets [2-499](#)
- packets enqueued or dropped [2-499](#)
- sent and received CoS values [2-499](#)
- sent and received DSCP values [2-499](#)

trusted boundary for IP phones [2-263](#)VLAN-based [2-266](#)

quality of service

See QoS

querytime, MVR [2-277](#)queue-limit command [2-321](#)queue-set command [2-323](#)**R**random-detect command [2-324](#)random-detect dscp command [2-327](#)random-detect exponential-weighting-constant command [2-331](#)random-detect precedence command [2-334](#)

rapid per-VLAN spanning-tree plus

See STP

rapid PVST+

See STP

rcommand command [2-337](#)re-authenticating 802.1x-enabled ports [2-88](#)

re-authentication

- periodic [2-89](#)
- time between attempts [2-91](#)

receiver ports, MVR [2-280](#)receiving flow-control packets [2-109](#)

recovery mechanism

- causes [2-97](#)
- display [2-406, 2-410](#)
- timer interval [2-97](#)

redundancy for cluster switches [2-64](#)remote-span command [2-339](#)

Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [A-17](#)renew ip dhcp snooping database command [2-341](#)rep admin vlan command [2-343](#)rep block port command [2-344](#)rep preempt delay command [2-347](#)rep preempt segment command [2-349](#)rep segment command [2-350](#)rep stcn command [2-352](#)reset (boot loader) command [A-18](#)reset command [2-701](#)resource templates, displaying [2-534](#)

restricted VLAN

See dot1x auth-fail vlan

rmdir (boot loader) command [A-19](#)rmon collection stats command [2-583](#)root guard, for spanning tree [2-587](#)route distinguisher [2-174](#)

routed ports

- IP addresses on [2-121](#)
- number supported [2-121](#)

route-target command [2-174](#)routing template [2-354](#)

RSPAN

- configuring [2-267](#)
- displaying [2-509](#)
- filter RSPAN traffic [2-267](#)
- sessions
 - add interfaces to [2-267](#)
 - displaying [2-509](#)
 - start new [2-267](#)
- VLAN [2-339](#)

S

- sdm prefer command [2-354](#)
- secure ports, limitations [2-650](#)
- sending flow-control packets [2-109](#)
- service instance command [2-356](#)
- service instances, displaying [2-416](#)
- service password-recovery command [2-357](#)
- service-policy command (interface configuration) [2-359](#)
- service-policy command (policy-map class) [2-362](#)
- set (boot loader) command [A-20](#)
- set command [2-364](#)
- setup command [2-366](#)
- setup express command [2-369](#)
- shape command [2-371](#)
- show access-lists command [2-373](#)
- show archive status command [2-376](#)
- show arp access-list command [2-377](#)
- show auto qos command [2-378](#)
- show boot command [2-382](#)
- show changes command [2-701](#)
- show class-map command [2-384](#)
- show cluster candidates command [2-387](#)
- show cluster command [2-385](#)
- show cluster members command [2-389](#)
- show controllers cpu-interface command [2-391](#)
- show controllers ethernet-controller command [2-393](#)
- show controllers tcam command [2-397](#)
- show current command [2-701](#)
- show dot1q-tunnel command [2-399](#)
- show dot1x command [2-400](#)
- show dtp command [2-403](#)
- show env command [2-405](#)
- show errdisable detect command [2-406](#)
- show errdisable flap-values command [2-408](#)
- show errdisable recovery command [2-410](#)
- show etherchannel command [2-412](#)
- show ethernet service evc command [2-415](#)
- show ethernet service instance command [2-416](#)
- show ethernet service interface command [2-418](#)
- show interface rep command [2-432](#)
- show interfaces command [2-420](#)
- show interfaces counters command [2-429](#)
- show inventory command [2-434](#)
- show ip arp inspection command [2-435](#)
- show ip dhcp snooping binding command [2-440](#)
- show ip dhcp snooping command [2-439](#)
- show ip dhcp snooping database command [2-442, 2-444](#)
- show ip igmp profile command [2-447](#)
- show ip igmp snooping command [2-448](#)
- show ip igmp snooping groups command [2-450](#)
- show ip igmp snooping mrouter command [2-452](#)
- show ip igmp snooping querier command [2-454](#)
- show ip source binding command [2-456](#)
- show ip verify source command [2-457](#)
- show l2protocol-tunnel command [2-459](#)
- show lacp command [2-461](#)
- show link state group command [2-465](#)
- show location [2-467](#)
- show location command [2-467](#)
- show mac access-group command [2-470](#)
- show mac address-table address command [2-474](#)
- show mac address-table aging time command [2-476](#)
- show mac address-table command [2-472](#)
- show mac address-table count command [2-478](#)
- show mac address-table dynamic command [2-480](#)
- show mac address-table interface command [2-482](#)
- show mac address-table learning command [2-484](#)

- show mac address-table move update [2-485](#)
- show mac address-table move update command [2-485](#)
- show mac address-table multicast command [2-487](#)
- show mac address-table notification command [2-49, 2-489, B-21](#)
- show mac address-table static command [2-491](#)
- show mac address-table vlan command [2-493](#)
- show mls qos aggregate-policer command [2-496](#)
- show mls qos command [2-495](#)
- show mls qos input-queue command [2-497](#)
- show mls qos interface command [2-499](#)
- show mls qos maps command [2-503](#)
- show mls qos queue-set command [2-506](#)
- show monitor command [2-509](#)
- show mvr command [2-515](#)
- show mvr interface command [2-517](#)
- show mvr members command [2-519](#)
- show pagp command [2-521](#)
- show parser macro command [2-523](#)
- show platform acl command [C-2](#)
- show platform cfm command [C-3](#)
- show platform configuration command [C-4](#)
- show platform etherchannel command [C-5](#)
- show platform forward command [C-6](#)
- show platform igmp snooping command [C-8](#)
- show platform ipc trace command [C-14](#)
- show platform ip multicast command [C-10](#)
- show platform ip policy command [C-11](#)
- show platform ip unicast command [C-12](#)
- show platform layer4op command [C-15](#)
- show platform mac-address-table command [C-16](#)
- show platform messaging command [C-17](#)
- show platform monitor command [C-18](#)
- show platform mvr table command [C-19](#)
- show platform pm command [C-20](#)
- show platform port-asic command [C-22](#)
- show platform port-security command [C-26](#)
- show platform qos command [C-27](#)
- show platform resource-manager command [C-28](#)
- show platform snmp counters command [C-30](#)
- show platform spanning-tree command [C-31](#)
- show platform stp-instance command [C-32](#)
- show platform tb command [C-33](#)
- show platform tcam command [C-34](#)
- show platform vlan command [C-37](#)
- show policy-map command [2-526](#)
- show port security command [2-529](#)
- show proposed command [2-701](#)
- show rep topology command [2-532](#)
- show sdm prefer command [2-534](#)
- show setup express command [2-536](#)
- show spanning-tree command [2-537](#)
- show storm-control command [2-543](#)
- show system mtu command [2-545](#)
- show trust command [2-677](#)
- show udd command [2-546](#)
- show version command [2-549](#)
- show vlan access-map command [2-556](#)
- show vlan command [2-551](#)
- show vlan command, fields [2-553](#)
- show vlan filter command [2-557](#)
- show vmps command [2-558](#)
- show vtp command [2-561](#)
- shutdown command [2-565](#)
- shutdown threshold, Layer 2 protocol tunneling [2-178](#)
- shutdown vlan command [2-566](#)
- Smartports macros
 - See macros
- SNMP host, specifying [2-571](#)
- SNMP informs, enabling the sending of [2-568](#)
- snmp mib rep trap-rate command [2-567](#)
- snmp-server enable traps command [2-568](#)
- snmp-server host command [2-571](#)
- snmp trap mac-notification command [2-575](#)
- SNMP traps
 - enabling MAC address notification trap [2-575](#)
 - enabling the MAC address notification feature [2-206](#)
 - enabling the sending of [2-568](#)

- SoftPhone
 - See Cisco SoftPhone
- software images
 - deleting [2-69](#)
 - downloading [2-7](#)
 - monitoring status of [2-376](#)
 - upgrading [2-7](#)
 - uploading [2-12](#)
- software version, displaying [2-549](#)
- source ports, MVR [2-280](#)
- SPAN
 - configuring [2-267](#)
 - debug messages, display [B-22](#)
 - displaying [2-509](#)
 - filter SPAN traffic [2-267](#)
 - sessions
 - add interfaces to [2-267](#)
 - displaying [2-509](#)
 - start new [2-267](#)
- spanning-tree backbonefast command [2-577](#)
- spanning-tree bpdudfilter command [2-578](#)
- spanning-tree bpduguard command [2-580](#)
- spanning-tree cost command [2-582](#)
- spanning-tree etherchannel command [2-584](#)
- spanning-tree extend system-id command [2-586](#)
- spanning-tree guard command [2-587](#)
- spanning-tree link-type command [2-589](#)
- spanning-tree loopguard default command [2-591](#)
- spanning-tree mode command [2-593](#)
- spanning-tree mst configuration command [2-595](#)
- spanning-tree mst cost command [2-597](#)
- spanning-tree mst forward-time command [2-599](#)
- spanning-tree mst hello-time command [2-600](#)
- spanning-tree mst max-age command [2-601](#)
- spanning-tree mst max-hops command [2-602](#)
- spanning-tree mst port-priority command [2-605](#)
- spanning-tree mst pre-standard command [2-604](#)
- spanning-tree mst priority command [2-607](#)
- spanning-tree mst root command [2-608](#)
- spanning-tree portfast (global configuration) command [2-612](#)
- spanning-tree portfast (interface configuration) command [2-614](#)
- spanning-tree port-priority command [2-610](#)
- Spanning Tree Protocol
 - See STP
- spanning-tree uplinkfast command [2-616](#)
- spanning-tree vlan command [2-618](#)
- speed command [2-621](#)
- srr-queue bandwidth limit command [2-623](#)
- srr-queue bandwidth shape command [2-625](#)
- srr-queue bandwidth share command [2-627](#)
- SSH, configuring version [2-170](#)
- static-access ports, configuring [2-634](#)
- statistics, Ethernet group [2-353](#)
- sticky learning, enabling [2-649](#)
- storm-control command [2-629](#)
- STP
 - BackboneFast [2-577](#)
 - counters, clearing [2-51](#)
 - debug messages, display
 - BackboneFast events [B-70](#)
 - MSTP [B-73](#)
 - optimized BPDUs handling [B-72](#)
 - spanning-tree activity [B-68](#)
 - switch shim [B-75](#)
 - transmitted and received BPDUs [B-71](#)
 - UplinkFast [B-77](#)
 - detection of indirect link failures [2-577](#)
 - enabling protocol tunneling for [2-178](#)
 - EtherChannel misconfiguration [2-584](#)
 - extended system ID [2-586](#)

STP (continued)

- path cost [2-582](#)
- protocol modes [2-593](#)
- root port
 - accelerating choice of new [2-616](#)
 - loop guard [2-587](#)
 - preventing from becoming designated [2-587](#)
 - restricting which can be root [2-587](#)
 - root guard [2-587](#)
 - UplinkFast [2-616](#)
- root switch
 - affects of extended system ID [2-586, 2-619](#)
 - hello-time [2-618](#)
 - interval between BPDU messages [2-618](#)
 - interval between hello BPDU messages [2-618](#)
 - max-age [2-618](#)
 - port priority for selection of [2-610](#)
 - primary or secondary [2-618](#)
 - switch priority [2-618](#)
- state changes
 - blocking to forwarding state [2-614](#)
 - enabling BPDU filtering [2-578, 2-612](#)
 - enabling BPDU guard [2-580, 2-612](#)
 - enabling Port Fast [2-612, 2-614](#)
 - enabling timer to recover from error state [2-97](#)
 - forward-delay time [2-618](#)
 - length of listening and learning states [2-618](#)
 - shutting down Port Fast-enabled ports [2-612](#)
- state information display [2-537](#)
- VLAN options [2-607, 2-618](#)
- SVIs, creating [2-115](#)
- Switched Port Analyzer
 - See SPAN
- switching characteristics
 - modifying [2-632, 2-647](#)
 - returning to interfaces [2-632, 2-647](#)
- switchport access command [2-634](#)
- switchport backup interface command [2-636](#)
- switchport block command [2-640](#)
- switchport command [2-632](#)
- switchport host command [2-641](#)
- switchport mode command [2-642](#)
- switchport mode private-vlan command [2-645](#)
- switchport nonegotiate command [2-647](#)
- switchport port-security aging command [2-653](#)
- switchport port-security command [2-649](#)
- switchport priority extend command [2-655](#)
- switchport private-vlan command [2-657](#)
- switchport protected command [2-659](#)
- switchports, displaying [2-420](#)
- switchport trunk command [2-661](#)
- switchport vlan mapping command [2-665](#)
- switchport voice vlan command [2-668](#)
- system message logging, save message to flash [2-195](#)
- system mtu command [2-670](#)
- system resource templates [2-354](#)

T

- tar files, creating, listing, and extracting [2-9](#)
- Telnetting to cluster switches [2-337](#)
- temperature information, displaying [2-405](#)
- templates, system resources [2-354](#)
- traceroute mac command [2-672](#)
- traceroute mac ip command [2-675](#)
- trunking, VLAN mode [2-642](#)
- trunk mode [2-642](#)
- trunk ports [2-642](#)
- trunks, to non-DTP device [2-643](#)
- trusted boundary for QoS [2-263](#)
- trusted port states for QoS [2-263](#)
- tunneling
 - drop threshold [2-180](#)
 - PAgP, LACP, and UDLD packets [2-179](#)
 - shutdown threshold [2-180](#)
- tunnel ports, Layer 2 protocol, displaying [2-459](#)
- type (boot loader) command [A-23](#)

U

UDLD

- aggressive mode [2-679, 2-681](#)
- debug messages, display [B-84](#)
- enable globally [2-679](#)
- enable per interface [2-681](#)
- error recovery timer [2-97](#)
- message timer [2-679](#)
- normal mode [2-679, 2-681](#)
- reset a shutdown interface [2-683](#)
- status [2-546](#)

udd (global configuration) command [2-679](#)

udd (interface configuration) command [2-681](#)

udd reset command [2-683](#)

UNI

- bundling and multiplexing [2-106](#)
- Ethernet [2-106](#)

unicast storm control [2-629](#)

uni count command [2-684](#)

UniDirectional Link Detection

See UDLD

UNI ID, Ethernet [2-108](#)

unknown multicast traffic, preventing [2-640](#)

unknown unicast traffic, preventing [2-640](#)

unset (boot loader) command [A-24](#)

upgrading, software images [2-7](#)

upgrading information

See release notes [xx](#)

UplinkFast, for STP [2-616](#)

user EXEC mode [1-2](#)

V

VCs

- assigning interfaces to [1-6, 2-718](#)
- configuring [2-272](#)
- MPLS, displaying [2-511](#)

version (boot loader) command [A-26](#)

virtual circuits

See VCs

VLAN

enabling guest VLAN supplicant [2-76](#)

vlan (global configuration) command [2-686](#)

vlan (VLAN configuration) command [2-692](#)

vlan access-map command [2-698](#)

VLAN access map configuration mode [2-698](#)

VLAN access maps

actions [2-5](#)

displaying [2-556](#)

VLAN-based QoS [2-266](#)

VLAN configuration

rules [2-689, 2-694](#)

saving [2-686, 2-696](#)

VLAN configuration mode

commands

VLAN [2-692](#)

VTP [2-714](#)

description [1-5](#)

entering [2-700](#)

summary [1-2](#)

vlan database command [2-700](#)

vlan filter command [2-703](#)

VLAN filters, displaying [2-557](#)

VLAN ID range [2-686, 2-692](#)

VLAN mapping, command [2-666](#)

VLAN maps

applying [2-703](#)

creating [2-698](#)

defining [2-221](#)

displaying [2-556](#)

VLAN Query Protocol

See VQP

VLANs

adding [2-686](#)

configuring [2-686, 2-692](#)

VMPS (continued)

debug messages, display

ISL [B-81](#)

VLAN IOS file system error tests [B-80](#)

VLAN manager activity [B-78](#)

VTP [B-82](#)

displaying configurations [2-551](#)

extended-range [2-686](#)

MAC addresses

displaying [2-493](#)

number of [2-478](#)

media types [2-689, 2-694](#)

normal-range [2-686, 2-692](#)

private [2-645](#)

configuring [2-316](#)

displaying [2-551](#)

See also private VLANs

restarting [2-566](#)

saving the configuration [2-686](#)

shutting down [2-566](#)

SNMP traps for VTP [2-569, 2-572](#)

suspending [2-566](#)

variables [2-692](#)

VLAN template [2-354](#)

VLAN Trunking Protocol

See VTP

VMPS

configuring servers [2-708](#)

displaying [2-558](#)

error recovery timer [2-97](#)

reconfirming dynamic VLAN assignments [2-705](#)

vmpls reconfirm (global configuration) command [2-706](#)

vmpls reconfirm (privileged EXEC) command [2-705](#)

vmpls retry command [2-707](#)

vmpls server command [2-708](#)

voice VLAN

configuring [2-668](#)

setting port priority [2-655](#)

VPN routing/forwarding table

See VRF

VQP

and dynamic-access ports [2-635](#)

clearing client statistics [2-53](#)

displaying information [2-558](#)

per-server retry count [2-707](#)

reconfirmation interval [2-706](#)

reconfirming dynamic VLAN assignments [2-705](#)

VRF

associating to an interface [2-176](#)

configuring [2-173](#)

VTP

changing characteristics [2-710](#)

clearing pruning counters [2-54](#)

configuring

domain name [2-710, 2-714](#)

file name [2-710](#)

mode [2-710, 2-714](#)

password [2-710, 2-714](#)

counters display fields [2-562](#)

displaying information [2-561](#)

enabling

pruning [2-710, 2-714](#)

tunneling for [2-178](#)

version 2 [2-710, 2-714](#)

mode [2-710, 2-714](#)

pruning [2-710, 2-714](#)

saving the configuration [2-686, 2-696](#)

statistics [2-561](#)

status [2-561](#)

status display fields [2-563](#)

vtp (global configuration) command [2-710](#)

vtp (VLAN configuration) command [2-714](#)

X

xconnect command [2-718](#)

