



## INDEX

---

### Numerics

- 802.1Q tunnel ports
  - and QoS guidelines [2-248, 2-280](#)
  - configuring [2-666](#)
  - displaying [2-416](#)
  - limitations [2-667](#)
- 802.1x
  - and switchport modes [2-667](#)
  - See also port-based authentication
  - violation error recovery [2-108](#)

---

### A

- aaa accounting dot1x command [2-1](#)
- aaa authentication dot1x command [2-3](#)
- AAA methods [2-3](#)
- abort command [2-724](#)
- access control entries
  - See ACEs
- access control lists
  - See ACLs
- access groups
  - IP [2-128](#)
  - MAC, displaying [2-488](#)
- access lists
  - IP [2-128](#)
  - on Layer 2 interfaces [2-128](#)
- access map configuration mode [2-235](#)
- access mode [2-666](#)
- access ports [2-666](#)
- ACEs [2-75, 2-306](#)

### ACLs

- deny [2-73](#)
- displaying [2-389](#)
- for non-IP protocols [2-213](#)
- matching [2-235](#)
- permit [2-304](#)
- action command [2-5](#)
- address aliasing [2-293](#)
- aggregate-port learner [2-300](#)
- allowed VLANs [2-684](#)
- Any Transport over MPLS
  - See AToM
- apply command [2-724](#)
- archive download-sw command [2-7](#)
- archive tar command [2-9](#)
- archive upload-sw command [2-12](#)
- arp access-list command [2-13](#)
- AToM, debug messages [B-23](#)
- audience [xix](#)
- authentication failed VLAN
  - See dot1x auth-fail vlan
- auth-fail max-attempts
  - See dot1x auth-fail max-attempts
- auth-fail vlan
  - See dot1x auth-fail vlan
- authorization state of controlled port [2-90](#)
- autonegotiation of duplex mode [2-101](#)
- auto-QoS
  - See QoS
- auto qos voip command [2-15](#)

**B**

BackboneFast, for STP [2-598](#)

backup interfaces

- configuring [2-657, 2-660](#)
- displaying [2-437](#)

bandwidth command [2-20](#)

boot (boot loader) command [A-2](#)

boot config-file command [2-23](#)

boot enable-break command [2-24](#)

boot helper command [2-25](#)

boot helper-config file command [2-26](#)

booting

- displaying environment variables [2-398](#)
- interrupting [2-24](#)
- IOS image [2-29](#)
- manually [2-27](#)

boot loader

- accessing [A-1](#)
- booting
  - helper image [2-25](#)
  - IOS image [A-2](#)

directories

- creating [A-15](#)
- displaying a list of [A-7](#)
- removing [A-19](#)

displaying

- available commands [A-12](#)
- memory heap utilization [A-13](#)
- version [A-26](#)

environment variables

- described [A-20](#)
- displaying settings [A-20](#)
- location of [A-21](#)
- setting [A-20](#)
- unsetting [A-24](#)

boot loader (continued)

- files
  - copying [A-5](#)
  - deleting [A-6](#)
  - displaying a list of [A-7](#)
  - displaying the contents of [A-4, A-16, A-23](#)
  - renaming [A-17](#)
- file system
  - formatting [A-10](#)
  - initializing flash [A-9](#)
  - running a consistency check [A-11](#)
- prompt [A-1](#)
- resetting the system [A-18](#)

boot manual command [2-27](#)

boot private-config-file command [2-28](#)

boot system command [2-29](#)

BPDU filtering, for spanning tree [2-599, 2-633](#)

BPDU guard, for spanning tree [2-601, 2-633](#)

broadcast storm control [2-650](#)

bundling characteristics, UNI [2-113](#)

**C**

candidate switches

- See clusters

cat (boot loader) command [A-4](#)

caution, description [xx](#)

CDP, enabling protocol tunneling for [2-192](#)

CFM [2-299](#)

CFM as OAM protocol [2-299](#)

channel-group command [2-30](#)

channel-protocol command [2-34](#)

Cisco SoftPhone, auto-QoS configuration [2-15](#)

class command [2-35](#)

class-map command [2-39](#)

class maps

- creating [2-39](#)
- defining the match criteria [2-237](#)
- displaying [2-400](#)

- class of service
    - See CoS
  - clear ip arp inspection log command [2-41](#)
  - clear ip arp inspection statistics command [2-42](#)
  - clear l2protocol-tunnel counters command [2-45](#)
  - clear lacp command [2-46](#)
  - clear mac address-table command [2-47, 2-48](#)
  - clear pagp command [2-49, 2-50](#)
  - clear spanning-tree counters command [2-51](#)
  - clear spanning-tree detected-protocols command [2-52](#)
  - clear vmps statistics command [2-53](#)
  - clear vtp counters command [2-54](#)
  - cluster commander-address command [2-55](#)
  - cluster discovery hop-count command [2-57](#)
  - cluster enable command [2-58](#)
  - cluster holdtime command [2-60](#)
  - cluster member command [2-61](#)
  - cluster outside-interface command [2-63](#)
  - cluster run command [2-64](#)
  - clusters
    - adding candidates [2-61](#)
    - binding to HSRP group [2-65](#)
    - building manually [2-61](#)
    - communicating with
      - devices outside the cluster [2-63](#)
      - members by using Telnet [2-350](#)
    - debug messages, display [B-5](#)
    - displaying
      - candidate switches [2-403](#)
      - debug messages [B-5](#)
      - member switches [2-405](#)
      - status [2-401](#)
    - hop-count limit for extended discovery [2-57](#)
    - HSRP standby groups [2-65](#)
    - redundancy [2-65](#)
    - SNMP trap [2-588](#)
  - cluster standby-group command [2-65](#)
  - cluster timer command [2-67](#)
  - command modes defined [1-1](#)
  - command switch
    - See clusters
  - configuration, initial
    - See hardware installation guide
  - configuration files
    - password recovery disable considerations [A-1](#)
    - specifying the name [2-23, 2-28](#)
  - configuring multiple interfaces [2-124](#)
  - config-vlan mode
    - commands [2-710](#)
    - description [1-4](#)
    - entering [2-709](#)
    - summary [1-2](#)
  - conventions
    - command [xix](#)
    - for examples [xx](#)
    - publication [xix](#)
    - text [xix](#)
  - copy (boot loader) command [A-5](#)
  - CoS
    - assigning default value to incoming packets [2-246](#)
    - assigning to Layer 2 protocol packets [2-196](#)
    - overriding the incoming value [2-246](#)
  - CoS-to-DSCP map [2-252](#)
  - CPU ASIC statistics, displaying [2-407](#)
  - cpu traffic qos [2-68](#)
- 
- ## D
- debug autoqos command [B-2](#)
  - debug backup command [B-4](#)
  - debug cluster command [B-5](#)
  - debug dot1x command [B-7](#)
  - debug dtp command [B-8](#)
  - debug etherchannel command [B-9](#)
  - debug interface command [B-12](#)
  - debug ip dhcp snooping command [B-13](#)
  - debug ip igmp filter command [B-14](#)
  - debug ip igmp max-groups command [B-15](#)

- debug ip igmp snooping command [B-16](#)
- debug ip verify source packet command [B-17](#)
- debug lacp command [B-18](#)
- debug mac-notification command [B-19](#)
- debug matm command [B-20](#)
- debug matm move update command [B-21](#)
- debug monitor command [B-22](#)
- debug mpls atom command [B-23](#)
- debug mpls l2transport vlan command [B-24](#)
- debug mvrdbg command [B-25](#)
- debug nvram command [B-26](#)
- debug pagp command [B-27](#)
- debug platform acl command [B-28](#)
- debug platform backup interface command [B-30](#)
- debug platform cfm command [B-29](#)
- debug platform cpu-queues command [B-31](#)
- debug platform dot1x command [B-33](#)
- debug platform etherchannel command [B-34](#)
- debug platform fallback-bridging command [B-35](#)
- debug platform forw-tcam command [B-36](#)
- debug platform ip arp inspection command [B-37](#)
- debug platform ip igmp snooping command [B-38](#)
- debug platform ip multicast command [B-40](#)
- debug platform ip unicast command [B-42](#)
- debug platform led command [B-44](#)
- debug platform matm command [B-45](#)
- debug platform messaging command [B-46](#)
- debug platform mpls command [B-47](#)
- debug platform phy command [B-48](#)
- debug platform pm command [B-49](#)
- debug platform port-asic command [B-51](#)
- debug platform port-security command [B-52](#)
- debug platform qos-acl-tcam command [B-53](#)
- debug platform remote-commands command [B-54](#)
- debug platform rep command [B-55](#)
- debug platform resource-manager command [B-56](#)
- debug platform snmp command [B-57](#)
- debug platform span command [B-58](#)
- debug platform supervisor-asic command [B-59](#)
- debug platform sw-bridge command [B-60](#)
- debug platform tcam command [B-61](#)
- debug platform udd command [B-63](#)
- debug platform vlan command [B-64](#)
- debug pm command [B-65](#)
- debug port-security command [B-67](#)
- debug qos-manager command [B-69](#)
- debug rep command [B-68](#)
- debug spanning-tree backbonefast command [B-72](#)
- debug spanning-tree bpdu command [B-73](#)
- debug spanning-tree bpdu-opt command [B-74](#)
- debug spanning-tree command [B-70](#)
- debug spanning-tree mstp command [B-75](#)
- debug spanning-tree switch command [B-77](#)
- debug spanning-tree uplinkfast command [B-79](#)
- debug sw-vlan command [B-80](#)
- debug sw-vlan ifs command [B-82](#)
- debug sw-vlan notification command [B-83](#)
- debug sw-vlan vtp command [B-84](#)
- debug udd command [B-86](#)
- debug vqpc command [B-88](#)
- debug xconnect command [B-89](#)
- default template [2-370](#)
- define interface-range command [2-70](#)
- delete (boot loader) command [A-6](#)
- delete command [2-72](#)
- deny (ARP access-list configuration) command [2-76](#)
- deny command [2-73](#)
- detect mechanism, causes [2-103](#)
- DHCP snooping
  - accepting untrusted packets from edge switch [2-153](#)
  - enabling
    - on a VLAN [2-159](#)
    - option 82 [2-151, 2-153](#)
    - trust on an interface [2-157](#)
  - rate limiting [2-156](#)

- DHCP snooping binding database
  - binding file, configuring [2-149](#)
  - bindings
    - adding [2-147](#)
    - deleting [2-147](#)
  - clearing database agent statistics [2-43](#)
  - database agent, configuring [2-149](#)
  - displaying
    - database agent status [2-461, 2-463](#)
    - renewing [2-354](#)
- Digital Optical Monitoring
  - see DoM
- dir (boot loader) command [A-7](#)
- directories, deleting [2-72](#)
- documentation, related [xx](#)
- document conventions [xix](#)
- DoM
  - displaying supported transceivers [2-450](#)
- domain name, VTP [2-733, 2-737](#)
- domains, CFM [2-299](#)
- dot1x auth-fail max-attempts [2-78](#)
- dot1x auth-fail vlan [2-80](#)
- dot1x default command [2-82](#)
- dot1x guest-vlan command [2-83](#)
- dot1x host-mode command [2-85](#)
- dot1x initialize command [2-87](#)
- dot1x max-req command [2-88, 2-89](#)
- dot1x port-control command [2-90](#)
- dot1x re-authenticate command [2-92](#)
- dot1x reauthentication command [2-93](#)
- dot1x system-auth-control command [2-94](#)
- dot1x test eapol-capable command [2-95](#)
- dot1x test timeout command [2-96](#)
- dot1x timeout command [2-97](#)
- dot1x violation-mode command [2-99](#)
- dropping packets, with ACL matches [2-5](#)
- drop threshold, Layer 2 protocol tunneling [2-192](#)
- DSCP-to-CoS map [2-252](#)
- DSCP-to-DSCP-mutation map [2-252](#)
- DTP [2-667](#)
- DTP flap
  - error detection for [2-103](#)
  - error recovery timer [2-108](#)
- dual-level policy maps [2-321](#)
- duplex command [2-101](#)
- dynamic-access ports
  - configuring [2-655](#)
  - restrictions [2-655](#)
- dynamic ARP inspection
  - ARP ACLs
    - apply to a VLAN [2-133](#)
    - define [2-13](#)
    - deny packets [2-76](#)
    - display [2-393](#)
    - permit packets [2-307](#)
  - clear
    - log buffer [2-41](#)
    - statistics [2-42](#)
  - display
    - ARP ACLs [2-393](#)
    - configuration and operating state [2-454](#)
    - log buffer [2-454](#)
    - statistics [2-454](#)
    - trust state and rate limit [2-454](#)
  - enable per VLAN [2-143](#)
  - error detection for [2-108](#)
  - log buffer
    - clear [2-41](#)
    - configure [2-137](#)
    - display [2-454](#)
  - rate-limit incoming ARP packets [2-135](#)
  - statistics
    - clear [2-42](#)
    - display [2-454](#)
  - trusted interface state [2-139](#)
  - type of packet logged [2-144](#)
  - validation checks [2-141](#)
- dynamic auto VLAN membership mode [2-666](#)

dynamic desirable VLAN membership mode [2-666](#)

Dynamic Host Configuration Protocol (DHCP)

See DHCP snooping

Dynamic Trunking Protocol

See DTP

## E

EAP-request/identity frame

maximum number to send [2-89](#)

response time before retransmitting [2-97](#)

E-LMI

enabling [2-111](#)

mapping [2-113](#)

encapsulation methods [2-684](#)

environment variables, displaying [2-398](#)

EoMPLS

configuring [2-287, 2-741](#)

displaying [2-528](#)

errdisable detect cause command [2-103](#)

errdisable detect cause small-frame command [2-105](#)

errdisable recovery cause small-frame [2-107](#)

errdisable recovery command [2-108](#)

error conditions, displaying [2-425](#)

error disable detection [2-103](#)

error-disabled interfaces, displaying [2-437](#)

EtherChannel

assigning Ethernet interface to channel group [2-30](#)

creating port-channel logical interface [2-122](#)

debug EtherChannel/PAgP, display [B-9](#)

debug platform-specific events, display [B-34](#)

displaying [2-429](#)

enabling Layer 2 protocol tunneling for

LACP [2-193](#)

PAgP [2-193](#)

UDLD [2-193](#)

interface information, displaying [2-437](#)

LACP

clearing channel-group information [2-46](#)

debug messages, display [B-18](#)

displaying [2-480](#)

modes [2-30](#)

port priority for hot-standby ports [2-197](#)

restricting a protocol [2-34](#)

system priority [2-199](#)

load-distribution methods [2-323](#)

PAgP

aggregate-port learner [2-300](#)

clearing channel-group information [2-49](#)

debug messages, display [B-27](#)

displaying [2-538](#)

error detection for [2-103](#)

error recovery timer [2-108](#)

learn method [2-300](#)

modes [2-30](#)

physical-port learner [2-300](#)

priority of interface for transmitted traffic [2-302](#)

ethernet lmi ce command [2-111](#)

Ethernet controller, internal register display [2-409](#)

ethernet evc command [2-110](#)

ethernet lim global command [2-111](#)

ethernet lmi ce-vlan map command [2-113, 2-115](#)

ethernet lmi command [2-111](#)

Ethernet Local Management Interface

See E-LMI

Ethernet over MPLS

See EoMPLS

Ethernet over multiprotocol label switching

See EoMPLS

Ethernet service

debugging [B-10](#)

displaying [2-432](#)

Ethernet service instance [2-372](#)

Ethernet service interfaces [2-435](#)

Ethernet statistics, collecting [2-369](#)

Ethernet UNI configuration [2-117](#)

ethernet uni id command [2-119](#)

Ethernet virtual connections

See EVCs

EVC configuration mode [2-110](#)

EVCs [2-110](#)

and VLANs [2-117](#)

service instances [2-372](#)

UNI counts [2-707](#)

EVC service

point-to-multipoint [2-707](#)

point-to-point [2-707](#)

examples, conventions for [xx](#)

exit command, VLAN database mode [2-724](#)

extended discovery of candidate switches [2-57](#)

extended-range VLANs

and allowed VLAN list [2-685](#)

and pruning-eligible list [2-685](#)

configuring [2-709](#)

extended system ID for STP [2-607](#)

---

## F

fan information, displaying [2-422](#)

file name, VTP [2-733](#)

files, deleting [2-72](#)

flash\_init (boot loader) command [A-9](#)

Flex Links

configuring [2-657, 2-660](#)

configuring preferred VLAN [2-659, 2-663](#)

displaying [2-437](#)

flowcontrol command [2-120](#)

format (boot loader) command [A-10](#)

forwarding packets, with ACL matches [2-5](#)

forwarding results, display [C-6](#)

frame forwarding information, displaying [C-6](#)

fsck (boot loader) command [A-11](#)

---

## G

global configuration mode [1-2, 1-3](#)

---

## H

hardware ACL statistics [2-389](#)

help (boot loader) command [A-12](#)

hop-count limit for clusters [2-57](#)

host connection, port configuration [2-665](#)

host ports, private VLANs [2-669](#)

HSRP

binding HSRP group to cluster [2-65](#)

standby group [2-65](#)

---

## I

IEEE 802.1ag Connectivity Fault Management

See CFM

IEEE 802.1X Port Based Authentication

enabling guest VLAN supplicant [2-79](#)

IGMP filters

applying [2-162](#)

debug messages, display [B-14](#)

IGMP groups, setting maximum [2-164](#)

IGMP maximum groups, debugging [B-15](#)

IGMP profiles

creating [2-166](#)

displaying [2-466](#)

IGMP snooping

adding ports as a static member of a group [2-177](#)

displaying [2-467, 2-471, 2-473](#)

enabling the Immediate-Leave feature [2-174](#)

multicast table [2-469](#)

querier [2-170](#)

report suppression [2-172](#)

images

See software images

Immediate-Leave feature, MVR [2-295](#)

- immediate-leave processing [2-174](#)
- import map command [2-189](#)
- initial configuration
  - See hardware installation guide
- interface configuration mode [1-2, 1-3](#)
- interface port-channel command [2-122](#)
- interface range command [2-124](#)
- interface-range macros [2-68, 2-70](#)
- interfaces
  - assigning Ethernet interface to channel group [2-30](#)
  - configuring [2-101](#)
  - configuring multiple [2-124](#)
  - creating port-channel logical [2-122](#)
  - debug messages, display [B-12](#)
  - disabling [2-583](#)
  - displaying the MAC address table [2-500](#)
  - restarting [2-583](#)
- interface speed, configuring [2-642](#)
- interface vlan command [2-126](#)
- internal registers, displaying [2-409, 2-413, 2-415](#)
- Internet Group Management Protocol
  - See IGMP
- invalid GBIC
  - error detection for [2-103](#)
  - error recovery timer [2-108](#)
- ip access-group command [2-128](#)
- ip address command [2-131](#)
- IP addresses, setting [2-131](#)
- IP address matching [2-235](#)
- ip arp inspection filter vlan command [2-133](#)
- ip arp inspection limit command [2-135](#)
- ip arp inspection log-buffer command [2-137](#)
- ip arp inspection trust command [2-139](#)
- ip arp inspection validate command [2-141](#)
- ip arp inspection vlan command [2-143](#)
- ip arp inspection vlan logging command [2-144](#)
- IP DHCP snooping
  - See DHCP snooping
- ip dhcp snooping binding command [2-147](#)
- ip dhcp snooping command [2-146](#)
- ip dhcp snooping database command [2-149](#)
- ip dhcp snooping information option allow-untrusted command [2-153](#)
- ip dhcp snooping information option command [2-151](#)
- ip dhcp snooping information option format remote-id command [2-155](#)
- ip dhcp snooping limit rate command [2-156](#)
- ip dhcp snooping trust command [2-157](#)
- ip dhcp snooping verify command [2-158](#)
- ip dhcp snooping vlan command [2-159](#)
- ip dhcp snooping vlan information option format-type circuit-id string command [2-160](#)
- ip igmp filter command [2-162](#)
- ip igmp max-groups command [2-164, 2-183, 2-185](#)
- ip igmp profile command [2-166](#)
- ip igmp snooping command [2-168](#)
- ip igmp snooping querier command [2-170](#)
- ip igmp snooping report-suppression command [2-172](#)
- ip igmp snooping vlan immediate-leave command [2-174](#)
- ip igmp snooping vlan mrouter command [2-175](#)
- ip igmp snooping vlan static command [2-177](#)
- IP multicast addresses [2-292](#)
- IP phones
  - auto-QoS configuration [2-15](#)
  - trusting packets sent from [2-279](#)
- IP-precedence-to-DSCP map [2-252](#)
- ip source binding command [2-179](#)
- IP source guard
  - disabling [2-187](#)
  - displaying
    - binding entries [2-475](#)
    - configuration [2-476](#)
  - enabling [2-187](#)
  - static IP source bindings [2-179](#)
- ip ssh command [2-181](#)
- ip verify source command [2-187](#)
- ip vrf (global configuration) command [2-188](#)
- ip vrf (interface configuration) command [2-190](#)



**J**

jumbo frames  
See MTU

**L**

l2protocol-tunnel command [2-192](#)  
l2protocol-tunnel cos command [2-196](#)  
label distribution protocol  
See LDP  
LACP  
See EtherChannel  
lacp port-priority command [2-197](#)  
lacp system-priority command [2-199](#)  
Layer 2 mode, enabling [2-653](#)  
Layer 2 protocol ports, displaying [2-478](#)  
Layer 2 protocol tunnel  
and EtherChannels [2-193](#)  
CoS [2-196](#)  
counters, clearing [2-45](#)  
error detection for [2-103](#)  
error recovery [2-194](#)  
error recovery timer [2-108](#)  
setting thresholds for [2-194](#)  
Layer 2 traceroute  
IP addresses [2-698](#)  
MAC addresses [2-695](#)  
Layer 3 mode, enabling [2-653](#)  
LDP  
destination [2-287](#)  
holdtime [2-289](#)  
line configuration mode [1-2, 1-5](#)  
Link Aggregation Control Protocol  
See EtherChannel  
link flap  
error detection for [2-103](#)  
error recovery timer [2-108](#)  
link state group command [2-201](#)

link state track command [2-203](#)  
load-distribution methods for EtherChannel [2-323](#)  
location (global configuration) command [2-204](#)  
location (interface configuration) command [2-206](#)  
logging event command [2-208](#)  
logging file command [2-209](#)  
logical interface [2-122](#)  
loopback error  
detection for [2-103](#)  
recovery timer [2-108](#)  
loop guard, for spanning tree [2-608, 2-612](#)

**M**

mac access-group command [2-211](#)  
MAC access-groups, displaying [2-488](#)  
MAC access list configuration mode [2-213](#)  
mac access-list extended command [2-213](#)  
MAC access lists [2-73](#)  
MAC addresses  
disabling MAC address learning per VLAN [2-216](#)  
displaying  
aging time [2-494](#)  
all [2-492](#)  
dynamic [2-498](#)  
Layer 2 multicast entries [2-505](#)  
MAC address-table move updates [2-503](#)  
notification settings [2-502, 2-507](#)  
number of addresses in a VLAN [2-496](#)  
per interface [2-500](#)  
per VLAN [2-511](#)  
static [2-509](#)  
static and dynamic entries [2-490](#)  
dynamic  
aging time [2-215](#)  
deleting [2-47](#)  
displaying [2-498](#)  
enabling MAC address notification [2-220](#)  
enabling MAC address-table move update [2-218](#)

- MAC addresses (continued)
  - matching [2-235](#)
  - static
    - adding and removing [2-222](#)
    - displaying [2-509](#)
    - dropping on an interface [2-223](#)
  - tables [2-492](#)
- MAC address notification, debugging [B-19](#)
- mac address-table aging-time [2-211, 2-235](#)
- mac address-table aging-time command [2-215](#)
- mac address-table learning command [2-216](#)
- mac address-table move update [2-218](#)
- mac address-table move update command [2-218](#)
- mac address-table notification command [2-220](#)
- mac address-table static command [2-222](#)
- mac address-table static drop command [2-223](#)
- macro description command [2-228](#)
- macro global command [2-229](#)
- macro global description command [2-232](#)
- macro name command [2-233](#)
- macros
  - adding a description [2-228](#)
  - adding a global description [2-232](#)
  - applying [2-229](#)
  - creating [2-233](#)
  - displaying [2-540](#)
  - specifying parameter values [2-229](#)
  - tracing [2-229](#)
- macros, interface range [2-70, 2-124](#)
- maintenance end points [2-707](#)
- manual
  - audience [xix](#)
  - purpose of [xix](#)
- maps
  - QoS
    - defining [2-252](#)
    - displaying [2-520](#)
  - VLAN
    - creating [2-721](#)
    - defining [2-235](#)
    - displaying [2-573](#)
- match (access-map configuration) command [2-235](#)
- match (class-map configuration) command [2-237](#)
- maximum transmission unit
  - See MTU
- mdix auto command [2-240](#)
- member switches
  - See clusters
- memory (boot loader) command [A-13](#)
- mkdir (boot loader) command [A-15](#)
- mls qos aggregate-policer command [2-244](#)
- mls qos command [2-242](#)
- mls qos cos command [2-246](#)
- mls qos dscp-mutation command [2-248](#)
- mls qos enhanced command [2-250](#)
- mls qos map command [2-252](#)
- mls qos queue-set output buffers command [2-255](#)
- mls qos queue-set output threshold command [2-257](#)
- mls qos srr-queue input bandwidth command [2-261](#)
- mls qos srr-queue input buffers command [2-263](#)
- mls qos-srr-queue input cos-map command [2-265](#)
- mls qos srr-queue input dscp-map command [2-267](#)
- mls qos srr-queue input priority-queue command [2-269](#)
- mls qos srr-queue input threshold command [2-271](#)
- mls qos-srr-queue output cos-map command [2-273](#)
- mls qos srr-queue output dscp-map command [2-275, 2-277](#)
- mls qos trust command [2-279](#)
- mls qos vlan-based command [2-282](#)
- mode, MVR [2-292](#)
- Mode button, and password recovery [2-373](#)
- modes, commands [1-1](#)
- monitor session command [2-283](#)

more (boot loader) command [A-16](#)

## MPLS

MTU [2-290](#)

VCs [2-287, 2-741](#)

mpls l2transport route command [2-287, 2-528](#)

mpls ldp holdtime command [2-289](#)

mpls mtu command [2-290](#)

## MSTP

displaying [2-555](#)

interoperability [2-52](#)

link type [2-610](#)

### MST region

aborting changes [2-616](#)

applying changes [2-616](#)

configuration name [2-616](#)

configuration revision number [2-616](#)

current or pending display [2-616](#)

displaying [2-555](#)

MST configuration mode [2-616](#)

VLANs-to-instance mapping [2-616](#)

path cost [2-618](#)

protocol mode [2-614](#)

restart protocol migration process [2-52](#)

### root port

loop guard [2-608](#)

preventing from becoming designated [2-608](#)

restricting which can be root [2-608](#)

root guard [2-608](#)

### root switch

affects of extended system ID [2-607](#)

hello-time [2-621, 2-629](#)

interval between BPDU messages [2-622](#)

interval between hello BPDU messages [2-621, 2-629](#)

max-age [2-622](#)

maximum hop count before discarding BPDU [2-623](#)

port priority for selection of [2-626](#)

primary or secondary [2-629](#)

## MSTP (continued)

switch priority [2-628](#)

### state changes

blocking to forwarding state [2-635](#)

enabling BPDU filtering [2-599, 2-633](#)

enabling BPDU guard [2-601, 2-633](#)

enabling Port Fast [2-633, 2-635](#)

forward-delay time [2-620](#)

length of listening and learning states [2-620](#)

rapid transition to forwarding [2-610](#)

shutting down Port Fast-enabled ports [2-633](#)

state information display [2-554](#)

## MTU

configuring size [2-693](#)

displaying global setting [2-562](#)

for MPLS [2-290](#)

multicast group address, MVR [2-295](#)

multicast groups, MVR [2-293](#)

multicast router learning method [2-175](#)

multicast router ports, configuring [2-175](#)

multicast storm control [2-650](#)

multicast VLAN, MVR [2-292](#)

multicast VLAN registration

See MVR

multiple hosts on authorized port [2-85](#)

Multiple Spanning Tree Protocol

See MSTP

multiplexing, UNI [2-117](#)

multi VPN routing/forwarding instances in customer edge devices

See multi-VRF CE

multi-VRF CE [2-188, 2-190](#)

## MVR

and address aliasing [2-293](#)

configuring [2-292](#)

configuring interfaces [2-295](#)

debug messages, display [B-25](#)

displaying [2-532](#)

MVR (continued)

- displaying interface information [2-534](#)
- members, displaying [2-536](#)

mvr (global configuration) command [2-292](#)

mvr (interface configuration) command [2-295](#)

mvr vlan group command [2-296](#)

---

## N

native VLANs [2-684](#)

nonnegotiate, DTP messaging [2-671](#)

nonhierarchical single-level policy maps [2-321](#)

non-IP protocols

- denying [2-73](#)
- forwarding [2-304](#)

non-IP traffic

- access lists [2-213](#)
- denying [2-73](#)
- permitting [2-304](#)

normal-range VLANs [2-709, 2-715](#)

note, description [xx](#)

no vlan command [2-709, 2-719](#)

---

## O

OAM PDUs [2-115](#)

OAM protocol [2-299](#)

oam protocol cfm svlan command [2-299](#)

operation, administration, and maintenance protocol

- See OAM

---

## P

PAGP

- See EtherChannel

pagp learn-method command [2-300](#)

pagp port-priority command [2-302](#)

password, VTP [2-733, 2-737](#)

password-recovery mechanism, enabling and disabling [2-373](#)

permit (ARP access-list configuration) command [2-307](#)

permit command [2-304](#)

per-VLAN spanning-tree plus

- See STP

physical-port learner [2-300](#)

PID, displaying [2-453](#)

PIM-DVMRP, as multicast router learning method [2-175](#)

police aggregate command [2-311](#)

police cir command [2-313](#)

police cir percent command [2-316](#)

police command [2-309](#)

policed-DSCP map [2-252](#)

policers

- aggregate [2-244, 2-311](#)
- displaying [2-514](#)
- policed-DSCP map [2-252](#)
- single-rate ingress [2-309](#)
- two-rate hierarchical [2-313, 2-316](#)

policy-map command [2-320](#)

policy maps

- applying to an interface [2-375](#)
- creating [2-320](#)
- displaying [2-543](#)
- dual-level [2-321](#)
- marking [2-380](#)
- nonhierarchical and single-level [2-321](#)
- See also policers
- See also QoS, hierarchical policies
- traffic classification
  - defining the class [2-35](#)
  - defining trust states [2-700](#)

Port Aggregation Protocol

- See EtherChannel

- port-based authentication
    - 802.1x AAA accounting methods [2-1](#)
    - AAA method list [2-3](#)
    - configuring violation modes [2-99](#)
    - debug messages, display [B-7](#)
    - enabling 802.1x
      - globally [2-94](#)
      - per interface [2-90](#)
    - guest VLAN [2-83](#)
    - host modes [2-85](#)
    - initialize an interface [2-87, 2-96](#)
    - manual control of authorization state [2-90](#)
    - multiple hosts on authorized port [2-85](#)
    - periodic re-authentication
      - enabling [2-93](#)
      - time between attempts [2-97](#)
    - quiet period between failed authentication exchanges [2-97](#)
    - re-authenticating 802.1x-enabled ports [2-92](#)
    - resetting configurable 802.1x parameters [2-82](#)
    - statistics and status display [2-417](#)
    - switch-to-authentication server retransmission time [2-97](#)
    - switch-to-client frame-retransmission number [2-88, 2-89](#)
    - switch-to-client retransmission time [2-97](#)
    - test for IEEE 802.1x readiness [2-95](#)
  - port-channel load-balance command [2-323](#)
  - Port Fast, for spanning tree [2-635](#)
  - port ranges, defining [2-68, 2-70](#)
  - ports, debugging [B-65](#)
  - ports, protected [2-683](#)
  - port security
    - aging [2-677](#)
    - debug messages, display [B-67](#)
    - enabling [2-673](#)
    - violation error recovery [2-108](#)
  - port trust states for QoS [2-279](#)
  - port types, MVR [2-295](#)
  - power information, displaying [2-422](#)
  - priority command [2-325](#)
  - priority-queue command [2-327](#)
  - private-vlan command [2-329](#)
  - private-vlan mapping command [2-332](#)
  - private VLANs
    - association [2-681](#)
    - configuring [2-329](#)
    - configuring ports [2-669](#)
    - displaying [2-568](#)
    - host ports [2-669](#)
    - mapping
      - configuring [2-681](#)
      - promiscuous ports [2-669](#)
  - privileged EXEC mode [1-2, 1-3](#)
  - product identification information, displaying [2-453](#)
  - promiscuous ports, private VLANs [2-669](#)
  - protected ports, displaying [2-442](#)
  - pruning
    - VLANs [2-684](#)
    - VTP
      - displaying interface information [2-437](#)
      - enabling [2-733, 2-737](#)
  - pruning-eligible VLAN list [2-686](#)
  - PVST+
    - See STP
- 
- ## Q
- QoS
    - and 802.1Q tunneling guidelines [2-238, 2-248, 2-280](#)
    - applying bandwidth to only one ES port [2-250](#)
    - auto-QoS
      - configuring [2-15](#)
      - debug messages, display [1-5, B-2](#)
      - displaying [2-394](#)
    - class maps
      - creating [2-39](#)
      - defining the match criteria [2-237](#)
      - displaying [2-400](#)

## QoS (continued)

- defining the CoS value for an incoming packet [2-246](#)
- displaying configuration information [2-394, 2-513](#)
- DSCP trusted ports
  - applying DSCP-to-DSCP-mutation map to [2-248](#)
  - defining DSCP-to-DSCP-mutation map [2-252](#)
- egress queues
  - displaying queue-set settings [2-525](#)
- egress queue-sets
  - allocating buffers [2-255](#)
  - defining the CoS output queue threshold map [2-273](#)
  - defining the DSCP output queue threshold map [2-277](#)
  - displaying buffer allocations [2-517](#)
  - displaying CoS output queue threshold map [2-520](#)
  - displaying DSCP output queue threshold map [2-520](#)
  - displaying queueing strategy [2-517](#)
  - displaying queue-set settings [2-523](#)
  - enabling bandwidth shaping and scheduling [2-646](#)
  - enabling bandwidth sharing and scheduling [2-648](#)
  - enabling the priority queue [2-327](#)
  - limiting the maximum output on a port [2-644](#)
  - mapping a port to a queue-set [2-336](#)
  - mapping CoS values to a queue and threshold [2-273](#)
  - mapping DSCP values to a queue and threshold [2-277](#)
  - setting maximum and reserved memory allocations [2-257](#)
  - setting WTD thresholds [2-257](#)
  - SRR and priority queue interaction [2-327](#)
- enabling [2-242](#)

## QoS (continued)

- hierarchical policies
  - applying to an interface [2-375](#)
  - average-rate traffic shaping on a class [2-387](#)
  - bandwidth allocation for a class [2-20](#)
  - class-based weighted fair queuing [2-20, 2-36](#)
  - creating a service policy [2-378](#)
  - displaying [2-543](#)
  - DSCP-based WRED [2-340](#)
  - IP precedence-based WRED [2-347](#)
  - marking [2-380](#)
  - strict priority queuing (LLQ) [2-325](#)
  - tail drop [2-334](#)
  - two-rate policers [2-313, 2-316](#)
  - WRED [2-337](#)
  - WRED average queue size calculation [2-344](#)
- ingress queues
  - allocating buffers [2-263](#)
  - assigning SRR scheduling weights [2-261](#)
  - defining the CoS input queue threshold map [2-265](#)
  - defining the DSCP input queue threshold map [2-267](#)
  - displaying buffer allocations [2-517](#)
  - displaying CoS input queue threshold map [2-520](#)
  - displaying DSCP input queue threshold map [2-520](#)
  - displaying queueing strategy [2-517](#)
  - displaying settings for [2-515](#)
  - enabling the priority queue [2-269](#)
  - mapping CoS values to a queue and threshold [2-265](#)
  - mapping DSCP values to a queue and threshold [2-267](#)
  - setting WTD thresholds [2-271](#)
- maps
  - defining [2-252, 2-265, 2-267, 2-273, 2-277](#)
  - displaying [2-520](#)

## QoS (continued)

## policy maps

- applying an aggregate policer [2-311](#)
- applying to an interface [2-375](#)
- creating [2-320](#)
- defining aggregate policers [2-244](#)
- defining single-rate ingress policers [2-309](#)
- displaying policers [2-514](#)
- displaying policy maps [2-543](#)
- dual-level [2-321](#)
- hierarchical on non-ES ports [2-321](#)
- marking [2-380](#)
- policed-DSCP map [2-252](#)
- traffic classifications [2-35](#)
- trust states [2-700](#)

port trust states [2-279](#)

## statistics

- in-profile and out-of-profile packets [2-517](#)
- packets enqueued or dropped [2-517](#)
- sent and received CoS values [2-517](#)
- sent and received DSCP values [2-517](#)

trusted boundary for IP phones [2-279](#)VLAN-based [2-282](#)

## quality of service

See QoS

querytime, MVR [2-292](#)queue-limit command [2-334](#)queue-set command [2-336](#)**R**random-detect command [2-337](#)random-detect dscp command [2-340](#)random-detect exponential-weighting-constant command [2-344](#)random-detect precedence command [2-347](#)

## rapid per-VLAN spanning-tree plus

See STP

## rapid PVST+

See STP

rcommand command [2-350](#)re-authenticating 802.1x-enabled ports [2-92](#)

## re-authentication

- periodic [2-93](#)
- time between attempts [2-97](#)

receiver ports, MVR [2-295](#)receiving flow-control packets [2-120](#)

## recovery mechanism

- causes [2-108](#)
- display [2-423, 2-427](#)
- timer interval [2-108](#)

redundancy for cluster switches [2-65](#)remote-span command [2-352](#)

## Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [A-17](#)renew ip dhcp snooping database command [2-354](#)rep admin vlan command [2-355](#)rep block port command [2-356](#)rep lsl-age-timer command [2-359](#)rep preempt delay command [2-360](#)rep preempt segment command [2-362](#)rep segment command [2-363](#)rep stcn command [2-366](#)reset (boot loader) command [A-18](#)reset command [2-724](#)resource templates, displaying [2-551](#)

## restricted VLAN

See dot1x auth-fail vlan

rmdir (boot loader) command [A-19](#)rmon collection stats command [2-369](#)root guard, for spanning tree [2-608](#)route distinguisher [2-189](#)

## routed ports

- IP addresses on [2-132](#)
- number supported [2-132](#)

route-target command [2-189](#)

routing template [2-370](#)

## RSPAN

configuring [2-283](#)

displaying [2-526](#)

filter RSPAN traffic [2-283](#)

### sessions

add interfaces to [2-283](#)

displaying [2-526](#)

start new [2-283](#)

VLAN [2-352](#)

## S

sdm prefer command [2-370](#)

secure ports, limitations [2-674](#)

sending flow-control packets [2-120](#)

service instance command [2-372](#)

service instances, displaying [2-433](#)

service password-recovery command [2-373](#)

service-policy command (interface configuration) [2-375](#)

service-policy command (policy-map class) [2-378](#)

set (boot loader) command [A-20](#)

set command [2-380](#)

setup command [2-382](#)

setup express command [2-385](#)

shape command [2-387](#)

show access-lists command [2-389](#)

show archive status command [2-392](#)

show arp access-list command [2-393](#)

show auto qos command [2-394](#)

show boot command [2-398](#)

show changes command [2-724](#)

show class-map command [2-400](#)

show cluster candidates command [2-403](#)

show cluster command [2-401](#)

show cluster members command [2-405](#)

show controllers cpu-interface command [2-407](#)

show controllers ethernet-controller command [2-409](#)

show controllers team command [2-413](#)

show cpu traffic qos [2-415](#)

show current command [2-724](#)

show dot1q-tunnel command [2-416](#)

show dot1x command [2-417](#)

show dtp command [2-420](#)

show env command [2-422](#)

show errdisable detect command [2-423](#)

show errdisable flap-values command [2-425](#)

show errdisable recovery command [2-427](#)

show etherchannel command [2-429](#)

show ethernet service evc command [2-432](#)

show ethernet service instance command [2-433](#)

show ethernet service interface command [2-435](#)

show interface rep command [2-448](#)

show interfaces command [2-437](#)

show interfaces counters command [2-445](#)

show interface transceivers command [2-450](#)

show inventory command [2-453](#)

show ip arp inspection command [2-454](#)

show ip dhcp snooping binding command [2-459](#)

show ip dhcp snooping command [2-458](#)

show ip dhcp snooping database command [2-461, 2-463](#)

show ip igmp profile command [2-466](#)

show ip igmp snooping command [2-467](#)

show ip igmp snooping groups command [2-469](#)

show ip igmp snooping mrouter command [2-471](#)

show ip igmp snooping querier command [2-473](#)

show ip source binding command [2-475](#)

show ip verify source command [2-476](#)

show l2protocol-tunnel command [2-478](#)

show lacp command [2-480](#)

show link state group command [2-484](#)

show location [2-486](#)

show location command [2-486](#)

show mac access-group command [2-488](#)

show mac address-table address command [2-492](#)

show mac address-table aging time command [2-494](#)

show mac address-table command [2-490](#)

show mac address-table count command [2-496](#)



- show mac address-table dynamic command [2-498](#)
- show mac address-table interface command [2-500](#)
- show mac address-table learning command [2-502](#)
- show mac address-table move update [2-503](#)
- show mac address-table move update command [2-503](#)
- show mac address-table multicast command [2-505](#)
- show mac address-table notification command [2-48, 2-507, B-21](#)
- show mac address-table static command [2-509](#)
- show mac address-table vlan command [2-511](#)
- show mls qos aggregate-policer command [2-514](#)
- show mls qos command [2-513](#)
- show mls qos input-queue command [2-515](#)
- show mls qos interface command [2-517](#)
- show mls qos maps command [2-520](#)
- show mls qos queue-set command [2-523](#)
- show monitor command [2-526](#)
- show mvr command [2-532](#)
- show mvr interface command [2-534](#)
- show mvr members command [2-536](#)
- show pagp command [2-538](#)
- show parser macro command [2-540](#)
- show platform acl command [C-2](#)
- show platform cfm command [C-3](#)
- show platform configuration command [C-4](#)
- show platform etherchannel command [C-5](#)
- show platform forward command [C-6](#)
- show platform igmp snooping command [C-8](#)
- show platform ipc trace command [C-14](#)
- show platform ip multicast command [C-10](#)
- show platform ip policy command [C-11](#)
- show platform ip unicast command [C-12](#)
- show platform layer4op command [C-15](#)
- show platform mac-address-table command [C-16](#)
- show platform messaging command [C-17](#)
- show platform monitor command [C-18](#)
- show platform mvr table command [C-19](#)
- show platform pm command [C-20](#)
- show platform port-asic command [C-22](#)
- show platform port-security command [C-26](#)
- show platform qos command [C-27](#)
- show platform resource-manager command [C-28](#)
- show platform snmp counters command [C-30](#)
- show platform spanning-tree command [C-31](#)
- show platform stp-instance command [C-32](#)
- show platform tb command [C-33](#)
- show platform team command [C-34](#)
- show platform vlan command [C-37](#)
- show policy-map command [2-543](#)
- show port security command [2-546](#)
- show proposed command [2-724](#)
- show rep topology command [2-549](#)
- show sdm prefer command [2-551](#)
- show setup express command [2-553](#)
- show spanning-tree command [2-554](#)
- show storm-control command [2-560](#)
- show system mtu command [2-562](#)
- show trust command [2-700](#)
- show udd command [2-563](#)
- show version command [2-566](#)
- show vlan access-map command [2-573](#)
- show vlan command [2-568](#)
- show vlan command, fields [2-570](#)
- show vlan filter command [2-574](#)
- show vmps command [2-575](#)
- show vtp command [2-578](#)
- shutdown command [2-583](#)
- shutdown threshold, Layer 2 protocol tunneling [2-192](#)
- shutdown vlan command [2-584](#)
- small violation-rate command [2-585](#)
- Smartports macros
  - See macros
- SNMP host, specifying [2-592](#)
- SNMP informs, enabling the sending of [2-588](#)
- snmp mib rep trap-rate command [2-587](#)
- snmp-server enable traps command [2-588](#)
- snmp-server host command [2-592](#)
- snmp trap mac-notification command [2-597](#)

- SNMP traps
  - enabling MAC address notification trap [2-597](#)
  - enabling the MAC address notification feature [2-220](#)
  - enabling the sending of [2-588](#)
- SoftPhone
  - See Cisco SoftPhone
- software images
  - deleting [2-72](#)
  - downloading [2-7](#)
  - monitoring status of [2-392](#)
  - upgrading [2-7](#)
  - uploading [2-12](#)
- software version, displaying [2-566](#)
- source ports, MVR [2-295](#)
- SPAN
  - configuring [2-283](#)
  - debug messages, display [B-22](#)
  - displaying [2-526](#)
  - filter SPAN traffic [2-283](#)
  - sessions
    - add interfaces to [2-283](#)
    - displaying [2-526](#)
    - start new [2-283](#)
- spanning-tree backbonefast command [2-598](#)
- spanning-tree bpdudfilter command [2-599](#)
- spanning-tree bpduguard command [2-601](#)
- spanning-tree cost command [2-603](#)
- spanning-tree etherchannel command [2-605](#)
- spanning-tree extend system-id command [2-607](#)
- spanning-tree guard command [2-608](#)
- spanning-tree link-type command [2-610](#)
- spanning-tree loopguard default command [2-612](#)
- spanning-tree mode command [2-614](#)
- spanning-tree mst configuration command [2-616](#)
- spanning-tree mst cost command [2-618](#)
- spanning-tree mst forward-time command [2-620](#)
- spanning-tree mst hello-time command [2-621](#)
- spanning-tree mst max-age command [2-622](#)
- spanning-tree mst max-hops command [2-623](#)
- spanning-tree mst port-priority command [2-626](#)
- spanning-tree mst pre-standard command [2-625](#)
- spanning-tree mst priority command [2-628](#)
- spanning-tree mst root command [2-629](#)
- spanning-tree portfast (global configuration) command [2-633](#)
- spanning-tree portfast (interface configuration) command [2-635](#)
- spanning-tree port-priority command [2-631](#)
- Spanning Tree Protocol
  - See STP
- spanning-tree uplinkfast command [2-637](#)
- spanning-tree vlan command [2-639](#)
- speed command [2-642](#)
- srr-queue bandwidth limit command [2-644](#)
- srr-queue bandwidth shape command [2-646](#)
- srr-queue bandwidth share command [2-648](#)
- SSH, configuring version [2-181](#)
- static-access ports, configuring [2-655](#)
- statistics, Ethernet group [2-369](#)
- sticky learning, enabling [2-673](#)
- storm-control command [2-650](#)
- STP
  - BackboneFast [2-598](#)
  - counters, clearing [2-51](#)
  - debug messages, display
    - BackboneFast events [B-72](#)
    - MSTP [B-75](#)
    - optimized BPDU handling [B-74](#)
    - spanning-tree activity [B-70](#)
    - switch shim [B-77](#)
    - transmitted and received BPDU [B-73](#)
    - UplinkFast [B-79](#)
  - detection of indirect link failures [2-598](#)
  - enabling protocol tunneling for [2-192](#)
  - EtherChannel misconfiguration [2-605](#)
  - extended system ID [2-607](#)
  - path cost [2-603](#)
  - protocol modes [2-614](#)

## STP (continued)

## root port

- accelerating choice of new [2-637](#)
- loop guard [2-608](#)
- preventing from becoming designated [2-608](#)
- restricting which can be root [2-608](#)
- root guard [2-608](#)
- UplinkFast [2-637](#)

## root switch

- affects of extended system ID [2-607, 2-640](#)
- hello-time [2-639](#)
- interval between BPDU messages [2-639](#)
- interval between hello BPDU messages [2-639](#)
- max-age [2-639](#)
- port priority for selection of [2-631](#)
- primary or secondary [2-639](#)
- switch priority [2-639](#)

## state changes

- blocking to forwarding state [2-635](#)
- enabling BPDU filtering [2-599, 2-633](#)
- enabling BPDU guard [2-601, 2-633](#)
- enabling Port Fast [2-633, 2-635](#)
- enabling timer to recover from error state [2-108](#)
- forward-delay time [2-639](#)
- length of listening and learning states [2-639](#)
- shutting down Port Fast-enabled ports [2-633](#)

state information display [2-554](#)VLAN options [2-628, 2-639](#)SVIs, creating [2-126](#)

## Switched Port Analyzer

See SPAN

## switching characteristics

- modifying [2-653, 2-671](#)
- returning to interfaces [2-653, 2-671](#)

switchport access command [2-655](#)switchport backup interface command [2-657, 2-660](#)switchport block command [2-664](#)switchport command [2-653](#)switchport host command [2-665](#)switchport mode command [2-666](#)switchport mode private-vlan command [2-669](#)switchport nonegotiate command [2-671](#)switchport port-security aging command [2-677](#)switchport port-security command [2-673](#)switchport priority extend command [2-679](#)switchport private-vlan command [2-681](#)switchport protected command [2-683](#)switchports, displaying [2-437](#)switchport trunk command [2-684](#)switchport vlan mapping command [2-688](#)switchport voice vlan command [2-691](#)system message logging, save message to flash [2-209](#)system mtu command [2-693](#)system resource templates [2-370](#)


---

**T**
tar files, creating, listing, and extracting [2-9](#)Telnetting to cluster switches [2-350](#)temperature information, displaying [2-422](#)templates, system resources [2-370](#)traceroute mac command [2-695](#)traceroute mac ip command [2-698](#)trunking, VLAN mode [2-666](#)trunk mode [2-666](#)trunk ports [2-666](#)trunks, to non-DTP device [2-667](#)trusted boundary for QoS [2-279](#)trusted port states for QoS [2-279](#)

## tunneling

drop threshold [2-194](#)PAGP, LACP, and UDLD packets [2-193](#)shutdown threshold [2-194](#)tunnel ports, Layer 2 protocol, displaying [2-478](#)type (boot loader) command [A-23](#)

---

**U**

## UDLD

- aggressive mode [2-702, 2-704](#)
- debug messages, display [B-86](#)
- enable globally [2-702](#)
- enable per interface [2-704](#)
- error recovery timer [2-108](#)
- message timer [2-702](#)
- normal mode [2-702, 2-704](#)
- reset a shutdown interface [2-706](#)
- status [2-563](#)

udd (global configuration) command [2-702](#)

udd (interface configuration) command [2-704](#)

udd reset command [2-706](#)

## UNI

- bundling and multiplexing [2-117](#)
- Ethernet [2-117](#)

unicast storm control [2-650](#)

uni count command [2-707](#)

## UniDirectional Link Detection

See UDLD

UNI ID, Ethernet [2-119](#)

unknown multicast traffic, preventing [2-664](#)

unknown unicast traffic, preventing [2-664](#)

unset (boot loader) command [A-24](#)

upgrading, software images [2-7](#)

upgrading information

See release notes [xx](#)

UplinkFast, for STP [2-637](#)

user EXEC mode [1-2](#)

---

**V**

## VCs

- assigning interfaces to [1-5, 2-741](#)
- configuring [2-287](#)
- MPLS, displaying [2-528](#)

version (boot loader) command [A-26](#)

virtual circuits

See VCs

## VLAN

enabling guest VLAN supplicant [2-79](#)

vlan (global configuration) command [2-709](#)

vlan (VLAN configuration) command [2-715](#)

vlan access-map command [2-721](#)

VLAN access map configuration mode [2-721](#)

VLAN access maps

actions [2-5](#)

displaying [2-573](#)

VLAN-based QoS [2-282](#)

VLAN configuration

rules [2-712, 2-717](#)

saving [2-709, 2-719](#)

VLAN configuration mode

commands

VLAN [2-715](#)

VTP [2-737](#)

description [1-4](#)

entering [2-723](#)

summary [1-2](#)

vlan database command [2-723](#)

vlan filter command [2-726](#)

VLAN filters, displaying [2-574](#)

VLAN ID range [2-709, 2-715](#)

VLAN mapping, command [2-689](#)

VLAN maps

applying [2-726](#)

creating [2-721](#)

defining [2-235](#)

displaying [2-573](#)

VLAN Query Protocol

See VQP

## VLANs

- adding [2-709](#)
- configuring [2-709, 2-715](#)
- debug messages, display
  - ISL [B-83](#)
  - VLAN IOS file system error tests [B-82](#)
  - VLAN manager activity [B-80](#)
  - VTP [B-84](#)
- displaying configurations [2-568](#)
- extended-range [2-709](#)
- MAC addresses
  - displaying [2-511](#)
  - number of [2-496](#)
- media types [2-712, 2-717](#)
- normal-range [2-709, 2-715](#)
- private [2-669](#)
  - configuring [2-329](#)
  - displaying [2-568](#)
  - See also private VLANs
- restarting [2-584](#)
- saving the configuration [2-709](#)
- shutting down [2-584](#)
- SNMP traps for VTP [2-590, 2-594](#)
- suspending [2-584](#)
- variables [2-715](#)

VLAN template [2-370](#)

## VLAN Trunking Protocol

See VTP

## VMPS

- configuring servers [2-731](#)
- displaying [2-575](#)
- error recovery timer [2-108](#)
- reconfirming dynamic VLAN assignments [2-728](#)
- vmmps reconfirm (global configuration) command [2-729](#)
- vmmps reconfirm (privileged EXEC) command [2-728](#)
- vmmps retry command [2-730](#)
- vmmps server command [2-731](#)

## voice VLAN

- configuring [2-691](#)
- setting port priority [2-679](#)

## VPN routing/forwarding table

See VRF

## VQP

- and dynamic-access ports [2-655](#)
- clearing client statistics [2-53](#)
- displaying information [2-575](#)
- per-server retry count [2-730](#)
- reconfirmation interval [2-729](#)
- reconfirming dynamic VLAN assignments [2-728](#)

## VRF

- associating to an interface [2-190](#)
- configuring [2-188](#)

## VTP

- changing characteristics [2-733](#)
- clearing pruning counters [2-54](#)
- configuring
  - domain name [2-733, 2-737](#)
  - file name [2-733](#)
  - mode [2-733, 2-737](#)
  - password [2-733, 2-737](#)
- counters display fields [2-579](#)
- displaying information [2-578](#)
- enabling
  - pruning [2-733, 2-737](#)
  - tunneling for [2-192](#)
  - version 2 [2-733, 2-737](#)
- mode [2-733, 2-737](#)
- pruning [2-733, 2-737](#)
- saving the configuration [2-709, 2-719](#)
- statistics [2-578](#)
- status [2-578](#)
- status display fields [2-580](#)
- vtp (global configuration) command [2-733](#)
- vtp (VLAN configuration) command [2-737](#)

---

**X**

xconnect command [2-741](#)