


## **Monitoring UDLD**

• UDLD Status, page 1

## **UDLD Status**

This option displays the UDLD status of the ports.



## **UDLD** port status

- **UDLD Admin State**: The current port state of the logical port, *Enabled* if any of the state(*Normal, Aggressive*) is enabled.
- Device ID(local): The ID of Device.
- Device Name(local): Name of the Device.
- Bidirectional State: The current state of the port.

## **Neighbour Status**

- Port: The current port of neighbour device.
- Device ID: The current ID of neighbour device.
- Link Status: The current link status of neighbour port.
- Device Name: Name of the Neighbour Device.

**Related Topics** 

Configuring UDLD