



## INDEX

---

### A

access control entries  
    See ACEs

access control lists  
    See ACLs

access groups  
    IP [2-82](#)  
    MAC, displaying [2-305](#)  
    matching for QoS classification [2-142, 2-145](#)

access mode [2-431](#)

access ports [2-431](#)

ACEs [2-53, 2-174](#)

ACLs  
    as match criteria for QoS classes [2-142](#)  
    deny [2-51](#)  
    displaying [2-230](#)  
    for non-IP protocols [2-122](#)  
    IP [2-83](#)  
    on Layer 2 interfaces [2-83](#)  
    permit [2-172](#)

action command [2-1](#)

aggregate-port learner [2-168](#)

alarm-contact command [2-3](#)

alarm-contact status, displaying [2-253](#)

allowed VLANs [2-433](#)

archive download-sw command [2-5](#)

archive tar command [2-8](#)

archive upload-sw command [2-11](#)

arp (boot loader) command [A-2](#)

attaching policy maps to interfaces [2-210](#)

autonegotiation of duplex mode [2-59](#)

---

### B

backup interfaces, configuring [2-424](#)

bandwidth command [2-13](#)

BITS clock controller [2-45](#)

BITS clock output [2-43](#)

boot (boot loader) command [A-3](#)

boot config-file command [2-16](#)

boot helper command [2-17](#)

boot helper-config file command [2-18](#)

booting  
    Cisco IOS image [2-21](#)  
    displaying environment variables [2-234](#)  
    manually [2-19](#)

boot loader  
    accessing [A-1](#)  
    booting  
        Cisco IOS image [A-3](#)  
        helper image [2-17](#)

directories  
    creating [A-18](#)  
    displaying a list of [A-8](#)  
    removing [A-25](#)

displaying  
    available commands [A-13](#)  
    memory heap utilization [A-14](#)  
    version [A-34](#)

environment variables  
    described [A-26](#)  
    displaying settings [A-26](#)  
    location of [A-27](#)  
    setting [A-26](#)  
    unsetting [A-32](#)

- files
  - copying [A-6](#)
  - deleting [A-7](#)
  - displaying a list of [A-8](#)
  - displaying the contents of [A-5, A-19, A-31](#)
  - renaming [A-23](#)
- file system
  - formatting [A-11](#)
  - initializing flash [A-10](#)
  - running a consistency check [A-12](#)
- prompt [A-1](#)
- resetting the system [A-24](#)
- boot manual command [2-19](#)
- boot private-config-file command [2-20](#)
- boot system command [2-21](#)
- BPDU filtering, for spanning tree [2-408](#)
- BPDU guard, for spanning tree [2-378, 2-408](#)
- bridge domains, displaying the MAC address table [2-313](#)
- broadcast storm control [2-417](#)
- burst bytes, in QoS policers [2-175](#)

---

## C

- cat (boot loader) command [A-5](#)
- CBWFQ, configuring [2-13](#)
- CFM [2-167](#)
- CFM as OAM protocol [2-167](#)
- channel-group command [2-22](#)
- channel-protocol command [2-25](#)
- class-based traffic shaping [2-228](#)
- class-based weighted fair queuing
  - See CBWFQ
- class command [2-26](#)
- classification, per-port per VLAN [2-154](#)
- class-map command [2-28](#)
- class-map configuration mode [2-28](#)
- class maps
  - creating [2-28](#)
  - defining the match criteria [2-143](#)

- displaying [2-238](#)
  - matching in [2-28](#)
- class of service
  - See CoS
- clear ipc command [2-30](#)
- clear lacp command [2-31](#)
- clear logging onboard command [2-32](#)
- clear mac address-table command [2-33](#)
- clear pagp command [2-35, 2-36](#)
- clear spanning-tree counters command [2-37](#)
- command modes defined [1-1](#)
- committed information rate in QoS policers [2-175](#)
- configuration files
  - password recovery disable considerations [A-1](#)
  - specifying the name [2-16, 2-20](#)
- configuring multiple interfaces [2-78](#)
- conform-action command [2-39](#)
- controller BITS input applique command [2-41](#)
- controller BITS output applique command [2-43](#)
- controller BITS shutdown command [2-45](#)
- copy (boot loader) command [A-6](#)
- copy logging onboard module command [2-46](#)
- CoS
  - as match criteria for QoS groups [2-143](#)
  - for QoS classification [2-212](#)
  - setting value in policy maps [2-212](#)
- CPU ASIC statistics, displaying [2-240](#)
- cpu traffic qos qos-group command [2-48](#)

---

## D

- debug bridge-domain command [B-2](#)
- debug etherchannel command [B-3](#)
- debug ethernet service command [B-4](#)
- debug interface command [B-6](#)
- debug ip igmp filter command [B-7](#)
- debug ip igmp max-groups command [B-8](#)
- debug ip igmp snooping command [B-9](#)
- debug lacp command [B-10](#)

debug mac-notification command [B-11](#)  
 debug matm command [B-12](#)  
 debug matm move update command [B-13](#)  
 debug nvram command [B-14](#)  
 debug pagp command [B-15](#)  
 debug pm command [B-16](#)  
 debug qos command [B-19](#)  
 debug rep command [B-18](#)  
 debug spanning-tree bpdu command [B-22](#)  
 debug spanning-tree bpdu-opt command [B-23](#)  
 debug spanning-tree command [B-20](#)  
 debug spanning-tree mstp command [B-24](#)  
 debug spanning-tree switch command [B-26, B-28](#)  
 debug sw-vlan command [B-30](#)  
 debug sw-vlan ifs command [B-31](#)  
 debug sw-vlan notification command [B-32](#)  
 debug udd command [B-34](#)  
 debug vfi command [B-36](#)  
 debug vrrp command [B-37](#)  
 debug xconnect command [B-38](#)  
 define interface-range command [2-48](#)  
 delete (boot loader) command [A-7](#)  
 delete command [2-50](#)  
 deny command [2-51](#)  
 detect mechanism, causes [2-60](#)  
 diagnostic schedule test command [2-54](#)  
 diagnostic start test command [2-56](#)  
 differentiated service code point  
     See DSCP  
 Digital Optical Monitoring  
     see DoM  
 dir (boot loader) command [A-8](#)  
 directories, deleting [2-50](#)  
 DoM  
     displaying supported transceivers [2-280](#)  
     enabling traps for [2-368](#)  
     transceivers traps [2-369](#)  
 domains, CFM [2-167](#)  
 dropping packets, with ACL matches [2-1](#)

DSCP  
     as match criteria for QoS groups [2-146, 2-150, 2-154](#)  
     for QoS traffic marking [2-215](#)  
     setting in policy maps [2-215](#)  
 duplex command [2-58](#)

---

## E

E-LMI, enabling [2-66](#)  
 environment variables, displaying [2-234](#)  
 EoMPLS, configuring [2-460](#)  
 errdisable detect cause command [2-60](#)  
 errdisable recovery command [2-62](#)  
 error conditions, displaying [2-258](#)  
 error disable detection [2-60](#)  
 error-disabled interfaces, displaying [2-268](#)  
 EtherChannel  
     creating port-channel logical interface [2-76](#)  
     debug EtherChannel/PAGP, display [B-3](#)  
     displaying [2-262](#)  
     interface information, displaying [2-268](#)  
 LACP  
     debug messages, display [B-10](#)  
     displaying [2-294](#)  
     modes [2-22](#)  
     port priority for hot-standby ports [2-109](#)  
     system priority [2-111](#)  
 load-distribution methods [2-182](#)  
 PAGP  
     aggregate-port learner [2-168](#)  
     clearing channel-group information [2-35](#)  
     debug messages, display [B-15](#)  
     displaying [2-332](#)  
     error detection for [2-60](#)  
     error recovery timer [2-62](#)  
     learn method [2-168](#)  
     modes [2-22](#)  
     physical-port learner [2-168](#)  
 Ethernet controller, internal register display [2-242](#)

ethernet evc command [2-65](#)

ethernet lmi ce-vlan map command [2-66](#)

ethernet lmi command [2-66](#)

ethernet lmi global command [2-66](#)

Ethernet Local Management Interface

- See E-LMI

ethernet oam remote-failure command [2-68](#)

Ethernet service

- debugging [B-4](#)
- displaying [2-265](#)

Ethernet service instance [2-206](#)

Ethernet statistics, collecting [2-205](#)

ethernet uni id command [2-69](#)

Ethernet virtual connections

- See EVCs

EVC configuration mode [2-65](#)

EVCs

- creating [2-65](#)
- service instances [2-206](#)
- UNI counts [2-447](#)

EVC service

- point-to-multipoint [2-447](#)
- point-to-point [2-447](#)

exceed-action command [2-70](#)

exit command, VFI configuration mode [2-107](#)

extended-range VLANs

- and allowed VLAN list [2-433](#)
- configuring [2-452](#)

extended system ID for STP [2-384](#)

external alarms, configuring [2-3](#)

---

## F

failure logging data

- clearing [2-32](#)
- copying [2-46](#)

fan information, displaying [2-253](#)

files, deleting [2-50](#)

flash\_init (boot loader) command [A-10](#)

Flex Links

- configuring [2-424](#)
- configuring preferred VLAN [2-426](#)

flowcontrol command [2-72](#)

format (boot loader) command [A-11](#)

forwarding packets, with ACL matches [2-1](#)

fsck (boot loader) command [A-12](#)

---

## G

global configuration mode [1-2, 1-3](#)

---

## H

hardware ACL statistics [2-230](#)

help (boot loader) command [A-13](#)

hierarchical virtual private LAN service

- See H-VPLS

host connection, port configuration [2-430](#)

H-VPLS [2-107](#)

- configuring [2-107](#)
- displaying [2-356](#)

hw-module module logging onboard command [2-74](#)

---

## I

IEEE 802.1ag Connectivity Fault Management

- See CFM

IEEE 802.1Q trunk ports and native VLANs [2-457](#)

IGMP filters

- applying [2-87](#)
- debug messages, display [B-7](#)

IGMP groups, setting maximum [2-88](#)

IGMP maximum groups, debugging [B-8](#)

IGMP profiles

- creating [2-90](#)
- displaying [2-284](#)

IGMP snooping

- adding ports as a static member of a group [2-102](#)
  - displaying [2-285, 2-289](#)
  - enabling [2-92](#)
  - enabling the configurable-leave timer [2-93](#)
  - enabling the Immediate-Leave feature [2-99](#)
  - flooding query count [2-97](#)
  - interface topology change notification behavior [2-98](#)
  - multicast table [2-287](#)
  - query solicitation [2-97](#)
  - report suppression [2-95](#)
  - switch topology change notification behavior [2-97](#)
  - images
    - See software images
  - immediate-leave processing [2-99](#)
  - input policy maps
    - and ACL classification [2-142](#)
    - commands not supported in [2-180](#)
    - configuration guidelines [2-180](#)
  - interface configuration mode [1-2, 1-4](#)
  - interface port-channel command [2-76](#)
  - interface range command [2-78](#)
  - interface-range macros [2-48](#)
  - interfaces
    - configuring [2-58](#)
    - configuring multiple [2-78](#)
    - creating port-channel logical [2-76](#)
    - debug messages, display [B-6](#)
    - disabling [2-363](#)
    - displaying the MAC address table [2-319](#)
    - restarting [2-363](#)
  - interface speed, configuring [2-415](#)
  - interface vlan command [2-80](#)
  - internal registers, displaying [2-242](#)
  - Internet Group Management Protocol
    - See IGMP
  - invalid GBIC
    - error detection for [2-60](#)
    - error recovery timer [2-62](#)
  - ip address command [2-85](#)
  - IP addresses, setting [2-85](#)
  - IP address matching [2-140](#)
  - ip igmp filter command [2-87](#)
  - ip igmp max-groups command [2-88](#)
  - ip igmp profile command [2-90](#)
  - ip igmp snooping command [2-92](#)
  - ip igmp snooping last-member-query-interval command [2-93](#)
  - ip igmp snooping report-suppression command [2-95](#)
  - ip igmp snooping tcn command [2-97](#)
  - ip igmp snooping tcn flood command [2-98](#)
  - ip igmp snooping vlan immediate-leave command [2-99](#)
  - ip igmp snooping vlan mrouter command [2-100](#)
  - ip igmp snooping vlan static command [2-102](#)
  - IP precedence, as match criteria for QoS groups [2-148](#)
  - ip ssh command [2-104](#)
- 
- ## L
- l2protocol command [2-105](#)
  - l2 vfi command [2-107](#)
  - lacp port-priority command [2-109](#)
  - lacp system-priority command [2-111](#)
  - Layer 2 mode, enabling [2-420](#)
  - Layer 2 traceroute
    - IP addresses [2-440](#)
    - MAC addresses [2-437](#)
  - Layer 3 mode, enabling [2-420](#)
  - line configuration mode [1-2, 1-4](#)
  - link flap
    - error detection for [2-60](#)
    - error recovery timer [2-62](#)
  - load-distribution methods for EtherChannel [2-182](#)
  - location (global configuration) command [2-113](#)
  - location (interface configuration) command [2-115](#)
  - logging event command [2-117](#)
  - logging file command [2-118](#)
  - logical interface [2-76](#)
  - loopback error

detection for [2-60](#)  
 recovery timer [2-62](#)  
 loop guard, for spanning tree [2-385, 2-389](#)

## M

mac access-group command [2-120](#)  
 MAC access-groups, displaying [2-305](#)  
 MAC access list configuration mode [2-122](#)  
 mac access-list extended command [2-122](#)  
 MAC access lists [2-51](#)  
 MAC addresses  
   disabling MAC address learning per VLAN [2-126](#)  
   displaying  
     aging time [2-311](#)  
     all [2-309](#)  
     dynamic [2-317](#)  
     MAC address-table move updates [2-322](#)  
     notification settings [2-321, 2-324](#)  
     number of addresses in a VLAN [2-315](#)  
     per bridge domain [2-313](#)  
     per interface [2-319](#)  
     per VLAN [2-328](#)  
     static [2-326](#)  
     static and dynamic entries [2-307](#)  
   dynamic  
     aging time [2-124](#)  
     deleting [2-33](#)  
     displaying [2-317](#)  
   enabling MAC address notification [2-130](#)  
   enabling MAC address-table move update [2-128](#)  
   matching [2-140](#)  
   static  
     adding and removing [2-132](#)  
     displaying [2-326](#)  
     dropping on an interface [2-132](#)  
   tables [2-309](#)  
 MAC address notification, debugging [B-11](#)  
 mac address-table aging-time [2-120, 2-140](#)

mac address-table aging-time command [2-124](#)  
 mac address-table learning command [2-126](#)  
 mac address-table move update command [2-128](#)  
 mac address-table notification command [2-130](#)  
 mac address-table static command [2-132](#)  
 macro description command [2-136](#)  
 macro global command [2-137](#)  
 macro global description command [2-139](#)  
 macros  
   adding a description [2-136](#)  
   adding a global description [2-139](#)  
   applying [2-137](#)  
   displaying [2-334](#)  
   interface range [2-48, 2-78](#)  
   specifying parameter values [2-137](#)  
   tracing [2-137](#)  
 maintenance end points [2-447](#)  
 maps  
   class, creating [2-28](#)  
   VLAN  
     creating [2-455](#)  
     defining [2-140](#)  
     displaying [2-361](#)  
 match access-group command [2-142](#)  
 match cos command [2-143](#)  
 match discard-class command [2-145](#)  
 match ip dscp command [2-146](#)  
 match ip precedence command [2-148](#)  
 match mpls experimental topmost command [2-150](#)  
 match qos-group command [2-152](#)  
 match vlan command [2-154](#)  
 maximum transmission unit  
   See MTU  
 mdix auto command [2-156](#)  
 memory (boot loader) command [A-14](#)  
 mgmt\_clr (boot loader) command [A-15](#)  
 mgmt\_init (boot loader) command [A-16, A-17](#)  
 mkdir (boot loader) command [A-18](#)  
 modes, commands [1-1](#)

more (boot loader) command [A-19](#)

## MPLS

displaying VFI [2-356](#)

experimental field [2-217](#)

VCs [2-460](#)

VFI configuration [2-107](#)

## MSTP

displaying [2-345](#)

interoperability [2-37](#)

link type [2-387](#)

### MST region

aborting changes [2-392](#)

applying changes [2-392](#)

configuration name [2-392](#)

configuration revision number [2-392](#)

current or pending display [2-392](#)

displaying [2-345](#)

MST configuration mode [2-392](#)

VLANs-to-instance mapping [2-392](#)

path cost [2-394](#)

protocol mode [2-391](#)

restart protocol migration process [2-37](#)

### root port

loop guard [2-385](#)

preventing from becoming designated [2-385](#)

restricting which can be root [2-385](#)

root guard [2-385](#)

### root switch

affects of extended system ID [2-384](#)

hello-time [2-397, 2-404](#)

interval between BPDU messages [2-398](#)

interval between hello BPDU messages [2-397, 2-404](#)

max-age [2-398](#)

maximum hop count before discarding BPDU [2-399](#)

port priority for selection of [2-400](#)

primary or secondary [2-404](#)

switch priority [2-403](#)

### state changes

blocking to forwarding state [2-410](#)

enabling BPDU filtering [2-376, 2-408](#)

enabling BPDU guard [2-378, 2-408](#)

enabling Port Fast [2-408, 2-410](#)

forward-delay time [2-396](#)

length of listening and learning states [2-396](#)

rapid transition to forwarding [2-387](#)

shutting down Port Fast-enabled ports [2-408](#)

state information display [2-344](#)

MTU, configuring size [2-158](#)

mtu command [2-158](#)

multicast router ports, configuring [2-100](#)

multicast storm control [2-417](#)

## Multiple Spanning Tree Protocol

See MSTP

## multiprotocol label switching

See MPLS

---

## N

native VLANs [2-433](#)

native VLAN tagging [2-457](#)

neighbor command, VFI configuration mode [2-107](#)

network-clock\_select command [2-41, 2-43](#)

network clock priority [2-165](#)

network-clock-select command [2-159](#)

network-clock-select hold-off timeout command [2-160](#)

network-clock-select hold-timeout command [2-161](#)

network-clock-select mode command [2-163](#)

network-clock-select option command [2-164](#)

network-clock-select output command [2-165](#)

network-clock-select wait-to-restore command [2-166](#)

nonegotiate, speed [2-415](#)

### non-IP protocols

denying [2-51](#)

forwarding [2-172](#)

non-IP traffic access lists [2-122](#)

non-IP traffic forwarding

denying [2-51](#)  
 permitting [2-172](#)  
 normal-range VLANs [2-452](#)  
 no vlan command [2-452](#)

---

## O

OAM PDUs [2-68](#)  
 OAM protocol [2-167](#)  
 oam protocol cfm svlan command [2-167](#)  
 on-board failure logging, displaying [2-301](#)  
 on-board failure logging, enabling [2-74](#)  
 online diagnostics  
   global configuration mode  
     clearing test-based testing schedule [2-54](#)  
     setting test-based testing [2-54](#)  
     setting up test-based testing [2-54](#)  
   removing scheduling [2-54](#)  
   scheduled switchover  
     disabling [2-54](#)  
     enabling [2-54](#)  
   scheduling [2-54](#)  
   setting test interval [2-54](#)  
   starting testing [2-56](#)  
 online diagnostic tests  
   displaying results [2-249](#)  
   starting [2-56](#)  
 operation, administration, and maintenance protocol  
   See OAM  
 output policy maps  
   and QoS group classification [2-152](#)  
   and traffic shaping [2-228](#)  
   configuration guidelines [2-180](#)  
   queue limit in [2-188](#)  
   pagp port-priority command [2-170](#)  
   password-recovery mechanism, enabling and disabling [2-208](#)  
   peek (boot loader) command [A-20](#)  
   permit command [2-172](#)  
   per-port per VLAN policing [2-154](#)  
   per-VLAN spanning-tree plus  
     See STP  
   physical-port learner [2-168](#)  
   PID, displaying [2-283](#)  
   PIM-DVMRP, as multicast router learning method [2-100](#)  
   ping (boot loader) command [A-21](#)  
   poke (boot loader) command [A-22](#)  
   police  
     multiple conform actions for a class [2-39](#)  
     multiple exceed actions for a class [2-70](#)  
     multiple violate actions for a class [2-450](#)  
   police command [2-175](#)  
   policers, configuring [2-175](#)  
   policy-map class, configuring multiple actions [2-39, 2-70, 2-450](#)  
   policy-map class configuration mode [2-26](#)  
   policy-map class police configuration mode [2-39, 2-177](#)  
   policy-map command [2-179](#)  
   policy-map configuration mode [2-179](#)  
   policy maps  
     and CoS classification [2-143](#)  
     and DSCP classification [2-146](#)  
     and IP precedence classification [2-149](#)  
     and MPLS classification [2-150](#)  
     applying [2-210](#)  
     applying to an interface [2-210, 2-225](#)  
     creating [2-179](#)  
     displaying [2-336](#)  
     policers [2-175](#)  
     setting priority [2-185](#)  
     setting QoS group identifier [2-223](#)  
     traffic classification, defining [2-26](#)  
     traffic marking

---

## P

pagp learn-method command [2-168](#)



- setting CoS values [2-212](#)
  - setting DSCP values [2-215](#)
  - setting IP precedence values [2-221](#)
- port-channel load-balance command [2-182](#)
- Port Fast, for spanning tree [2-410](#)
- port ranges, defining [2-32, 2-46, 2-48](#)
- ports, debugging [B-16](#)
- port-type command [2-184](#)
- power information, displaying [2-253](#)
- power-supply status, displaying [2-253](#)
- precedence
  - for QoS traffic marking [2-221](#)
  - setting in policy maps [2-221](#)
- priority command [2-185](#)
- privileged EXEC mode [1-2, 1-3](#)
- product identification information, displaying [2-283](#)
- PVST+
  - See STP

---

## Q

- ql-enabled rep-segment command [2-187](#)
- QoS
  - classification based on VLAN IDs [2-154](#)
  - class maps
    - creating [2-28](#)
    - defining the match criteria [2-143](#)
    - displaying [2-238](#)
  - conform actions, configuring [2-40](#)
  - displaying statistics for [2-336](#)
  - exceed actions, configuring [2-71](#)
  - per-port, per-VLAN hierarchical policy maps [2-154](#)
  - policy maps
    - applying to an interface [2-210, 2-225](#)
    - creating [2-179](#)
    - defining policers [2-175](#)
    - displaying policy maps [2-336](#)
    - setting CoS values [2-212](#)
    - setting DSCP values [2-215](#)

- setting IP precedence values [2-221](#)
  - setting QoS group identifier [2-223](#)
  - traffic classifications [2-26](#)
- violate actions, configuring [2-451](#)
- QoS groups
  - as match criteria [2-152](#)
  - classification [2-154](#)
  - for QoS traffic classification [2-223](#)
  - setting in policy maps [2-223](#)
- QoS match criteria
  - ACLs [2-142](#)
  - CoS value [2-143](#)
  - discard class value [2-145](#)
  - DSCP value [2-146, 2-150, 2-154](#)
  - precedence value [2-148](#)
  - QoS group number [2-152](#)
  - topmost MPLS experimental label [2-150](#)
- quality of service
  - See QoS
- queue-limit command [2-188](#)

---

## R

- rapid per-VLAN spanning-tree plus
  - See STP
- rapid PVST+
  - See STP
- receiving flow-control packets [2-72](#)
- recovery mechanism
  - causes [2-62](#)
  - display [2-236, 2-256, 2-260](#)
  - timer interval [2-63](#)
- rename (boot loader) command [A-23](#)
- rep admin vlan command [2-191](#)
- rep block port command [2-192](#)
- rep lsl-age-timer command [2-195](#)
- rep preempt delay command [2-197](#)
- rep preempt segment command [2-199](#)
- rep segment command [2-200](#)

rep stcn command [2-203](#)  
 reserved-only command [2-204](#)  
 reset (boot loader) command [A-24](#)  
 rmdir (boot loader) command [A-25](#)  
 rmon collection stats command [2-205](#)  
 root guard, for spanning tree [2-385](#)

## S

scheduled switchover  
     disabling [2-54](#)  
     enabling [2-54](#)  
 scheduling diagnostic tests [2-54](#)  
 sending flow-control packets [2-72](#)  
 service instance command [2-206](#)  
 service password-recovery command [2-208](#)  
 service policy (policy-map class configuration) command [2-212](#)  
 service-policy interface configuration command [2-210](#)  
 set (boot loader) command [A-26](#)  
 set\_param (boot loader) command [A-29](#)  
 set cos command [2-212](#)  
 set discard-class command [2-214](#)  
 set dscp command [2-215](#)  
 set mpls command [2-217](#)  
 set network-clocks command [2-219](#)  
 set precedence command [2-221](#)  
 set qos-group command [2-223](#)  
 setup command [2-225](#)  
 SFPs, displaying information about [2-283](#)  
 shape average command [2-228](#)  
 show access-lists command [2-230](#)  
 show archive status command [2-233](#)  
 show boot command [2-234](#)  
 show class-map command [2-238](#)  
 show controllers bits command [2-239](#)  
 show controllers cpu-interface command [2-240](#)  
 show controllers ethernet-controller command [2-242](#)  
 show controller utilization command [2-247](#)  
 show diagnostic command [2-249](#)  
 show env command [2-253](#)  
 show errdisable detect command [2-256](#)  
 show errdisable flap-values command [2-258](#)  
 show errdisable recovery command [2-260](#)  
 show etherchannel command [2-262](#)  
 show ethernet service evc command [2-265](#)  
 show flowcontrol command [2-266](#)  
 show interface rep command [2-278](#)  
 show interfaces command [2-268](#)  
 show interfaces counters command [2-275](#)  
 show interfaces rep command [2-278](#)  
 show interface transceivers command [2-280](#)  
 show inventory command [2-283](#)  
 show ipc command [2-290](#)  
 show ip igmp profile command [2-284](#)  
 show ip igmp snooping command [2-285](#)  
 show ip igmp snooping groups command [2-287](#)  
 show ip igmp snooping mrouter command [2-289](#)  
 show ip sla standards command [2-290](#)  
 show ip sla twamp session command [2-290](#)  
 show lacp command [2-294](#)  
 show location command [2-298](#)  
 show logging onboard command [2-301](#)  
 show mac access-group command [2-305](#)  
 show mac address-table address command [2-309](#)  
 show mac address-table aging time command [2-311](#)  
 show mac address-table bridge-domain command [2-313](#)  
 show mac address-table command [2-307](#)  
 show mac address-table count command [2-315](#)  
 show mac address-table dynamic command [2-317](#)  
 show mac address-table interface command [2-319](#)  
 show mac address-table learning command [2-321](#)  
 show mac address-table move update command [2-322](#)  
 show mac address-table notification command [2-324, B-13](#)  
 show mac address-table static command [2-326](#)  
 show mac address-table vlan command [2-328](#)  
 show network-clocks command [2-330](#)  
 show pagp command [2-332](#)

- show parser macro command [2-334](#)
- show policy-map command [2-336](#)
- show policy-map interface output fields [2-338](#)
- show port-type command [2-339](#)
- show rep topology command [2-341](#)
- show spanning-tree command [2-344](#)
- show storm-control command [2-350](#)
- show uddl command [2-352](#)
- show version command [2-354](#)
- show vfi command [2-356](#)
- show vlan access-map command [2-361](#)
- show vlan command [2-358](#)
- show vlan command, fields [2-359](#)
- show vlan filter command [2-362](#)
- shutdown command [2-363](#)
- shutdown command, VFI configuration mode [2-107](#)
- shutdown vlan command [2-364](#)
- sleep (boot loader) command [A-30](#)
- SNMP host, specifying [2-370](#)
- SNMP informs, enabling the sending of [2-366](#)
- snmp mib rep trap-rate command [2-365](#)
- snmp-server enable traps command [2-366](#)
- snmp-server host command [2-370](#)
- snmp trap mac-notification change command [2-374](#)
- SNMP traps
  - enabling MAC address notification trap [2-374](#)
  - enabling the MAC address notification feature [2-130](#)
  - enabling the sending of [2-366](#)
- software images
  - deleting [2-50](#)
  - downloading [2-5](#)
  - upgrading [2-5](#)
  - uploading [2-11](#)
- software version, displaying [2-354](#)
- spanning-tree bpdufilter command [2-376](#)
- spanning-tree bpduguard command [2-378](#)
- spanning-tree cost command [2-380](#)
- spanning-tree etherchannel command [2-382](#)
- spanning-tree extend system-id command [2-384](#)
- spanning-tree guard command [2-385](#)
- spanning-tree link-type command [2-387](#)
- spanning-tree loopguard default command [2-389](#)
- spanning-tree mode command [2-391](#)
- spanning-tree mst configuration command [2-392](#)
- spanning-tree mst cost command [2-394](#)
- spanning-tree mst forward-time command [2-396](#)
- spanning-tree mst hello-time command [2-397](#)
- spanning-tree mst max-age command [2-398](#)
- spanning-tree mst max-hops command [2-399](#)
- spanning-tree mst port-priority command [2-400](#)
- spanning-tree mst pre-standard command [2-402](#)
- spanning-tree mst priority command [2-403](#)
- spanning-tree mst root command [2-404](#)
- spanning-tree portfast (global configuration) command [2-408](#)
- spanning-tree portfast (interface configuration) command [2-410](#)
- spanning-tree port-priority command [2-406](#)
- Spanning Tree Protocol
  - See STP
- spanning-tree vlan command [2-412](#)
- speed command [2-415](#)
- SSH, configuring version [2-104](#)
- static-access ports, configuring [2-422](#)
- statistics, Ethernet group [2-205](#)
- storm-control command [2-417](#)
- STP
  - counters, clearing [2-37](#)
  - debug messages, display
    - MSTP [B-24](#)
    - optimized BPDUs handling [B-23](#)
    - spanning-tree activity [B-20](#)
    - switch shim [B-26, B-28](#)
    - transmitted and received BPDUs [B-22](#)
  - EtherChannel misconfiguration [2-382](#)
  - extended system ID [2-384](#)
  - path cost [2-380](#)
  - protocol modes [2-391](#)

- root port
  - loop guard [2-385](#)
  - preventing from becoming designated [2-385](#)
  - restricting which can be root [2-385](#)
  - root guard [2-385](#)
- root switch
  - affects of extended system ID [2-384, 2-413](#)
  - hello-time [2-412](#)
  - interval between BDPUs messages [2-412](#)
  - interval between hello BDPUs messages [2-412](#)
  - max-age [2-412](#)
  - port priority for selection of [2-406](#)
  - primary or secondary [2-412](#)
  - switch priority [2-412](#)
- state changes
  - blocking to forwarding state [2-410](#)
  - enabling BPDU filtering [2-408](#)
  - enabling BPDU guard [2-378, 2-408](#)
  - enabling Port Fast [2-408, 2-410](#)
  - enabling timer to recover from error state [2-62](#)
  - forward-delay time [2-412](#)
  - length of listening and learning states [2-412](#)
  - shutting down Port Fast-enabled ports [2-408](#)
- state information display [2-344](#)
- VLAN options [2-403, 2-412](#)
- SVIs, creating [2-80](#)
- switching characteristics
  - modifying [2-420](#)
  - returning to interfaces [2-420](#)
- switchport access command [2-422](#)
- switchport backup interface command [2-424](#)
- switchport block command [2-428](#)
- switchport command [2-420](#)
- switchport host command [2-430](#)
- switchport mode command [2-431](#)
- switchport port-security aging command [2-433](#)
- switchports, displaying [2-268](#)
- switchport trunk command [2-433](#)
- SyncE clock configuration [2-330](#)

- SyncE input clock [2-159](#)
- Synchronous Ethernet
  - See SyncE
- system env temperature threshold yellow command [2-435](#)
- system message logging, save message to flash [2-118](#)

---

## T

- tar files, creating, listing, and extracting [2-8](#)
- TDR, running [2-436](#)
- temperature information, displaying [2-253](#)
- temperature status, displaying [2-253](#)
- test cable-diagnostics tdr command [2-436](#)
- traceroute mac command [2-437](#)
- traceroute mac ip command [2-440](#)
- traffic shaping, QoS [2-228](#)
- trunking, VLAN mode [2-431](#)
- trunk mode [2-431](#)
- trunk ports [2-431](#)
- type (boot loader) command [A-31](#)

---

## U

- UDLD
  - aggressive mode [2-442, 2-444](#)
  - debug messages, display [B-34](#)
  - enable globally [2-442](#)
  - enable per interface [2-444](#)
  - error recovery timer [2-62](#)
  - message timer [2-442](#)
  - normal mode [2-442, 2-444](#)
  - reset a shutdown interface [2-446](#)
  - status [2-352](#)
- udld command [2-442](#)
- udld port command [2-444](#)
- udld reset command [2-446](#)
- unicast storm control [2-417](#)
- uni count command [2-447](#)

UniDirectional Link Detection

See UDLD

UNI ID, Ethernet [2-69](#)

uni-vlan command [2-449](#)

unknown multicast traffic, preventing [2-428](#)

unknown unicast traffic, preventing [2-428](#)

unset (boot loader) command [A-32](#)

upgrading software images

configuring [2-5](#)

monitoring status of [2-233](#)

user EXEC mode [1-2](#)

---

## V

VCs, assigning interfaces to [2-460](#)

version (boot loader) command [A-34](#)

VFI

configuration mode commands [2-107](#)

creating [2-107, 2-460](#)

displaying [2-356](#)

VPN ID for [2-459](#)

violate-action command [2-450](#)

virtual forwarding infrastructure

See VFI

virtual private networks

See VPNs

vlan access-map command [2-455](#)

VLAN access map configuration mode [2-455](#)

VLAN access maps

actions [2-2](#)

displaying [2-361](#)

vlan command [2-452](#)

VLAN configuration mode

commands [2-452](#)

description [1-4](#)

entering [2-452](#)

summary [1-2](#)

vlan dot1q tag native command [2-457](#)

vlan filter command [2-458](#)

VLAN filters, displaying [2-362](#)

VLAN ID range [2-452](#)

VLAN maps

applying [2-458](#)

creating [2-455](#)

defining [2-140](#)

displaying [2-361](#)

VLANs

adding [2-452](#)

configuring [2-452](#)

debug messages, display

activation of [B-32](#)

VLAN IOS file system error tests [B-31](#)

VLAN manager activity [B-30](#)

displaying configurations [2-358](#)

extended-range [2-452](#)

MAC addresses

displaying [2-328](#)

number of [2-315](#)

normal-range [2-452](#)

restarting [2-364](#)

saving the configuration [2-452](#)

shutting down [2-364](#)

suspending [2-364](#)

VPN

configuring [2-459](#)

specifying in VFI configuration mode [2-107](#)

vpn id command [2-459](#)

---

## W

Weighted Tail Drop

See WTD

WTD, queue-limit command [2-188](#)

---

## X

xconnect [2-460](#)

xconnect command [2-460](#)









