



Preface

Revised: December 2, 2011, OL-21178-01

Introduction

The *Cisco TelePresence System 3210 Assembly, Use & Care, and Field-Replaceable Unit Guide* outlines the steps and best practices for assembling and installing the Cisco TelePresence 3210.

This guide is intended primarily for installers of the Cisco TelePresence System 3210. Site planners, network administrators, and facility maintenance personnel may also find this document useful.

This preface provides the following information for using this guide and for accessing other resources.

- [Conventions, page xi](#)
- [Obtaining Documentation, Obtaining Support, and Security Guidelines, page xii](#)
- [Related Documentation, page xii](#)

Conventions

This document uses the following conventions to convey information and alert the user to conditions requiring special awareness.



Warning

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, you must be aware of the hazards involved with electrical circuitry and familiar with standard practices for preventing accidents.



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the publication.

**Tip**

Means the information contains useful tips.

Obtaining Documentation, Obtaining Support, and Security Guidelines

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.

Related Documentation

The Cisco TelePresence system documentation set includes a variety of online and printed guides designed to aid the assemblers, installers, system administrators, and users in the setup, configuration, administration, and use of the Cisco TelePresence. These documents include:

- *Cisco TelePresence System 1000 Assembly, Use & Care, and Field Replacement Unit Guide*, OL-16247-01. There is also a pointer document for this guide, OL-17800-02
- *Cisco TelePresence and Cisco Unified Communications Manager Installation and Configuration Guide*, OL-11326-02
- *Cisco TelePresence System Release 1.4 Administrator's Guide*, OL-13676-03
- *Release Notes for Cisco TelePresence System, Release 1.4*, OL-12074-05
- *Cisco TelePresence Meeting User's Guide*, 78-17791-01
- *Cisco TelePresence System Release 1.4 Meeting Quick Reference*, 78-17792-02

All of these documents are available at the Cisco documentation website.